



Air-Conditioners For Building Application


2004

TECHNICAL & SERVICE MANUAL


Series PFFY Floor Standing Type

<Indoor unit>

Models PFFY-P20VLEM-E,PFFY-P20VLRM-E
PFFY-P25VLEM-E,PFFY-P25VLRM-E
PFFY-P32VLEM-E,PFFY-P32VLRM-E
PFFY-P40VLEM-E,PFFY-P40VLRM-E
PFFY-P50VLEM-E,PFFY-P50VLRM-E
PFFY-P63VLEM-E,PFFY-P63VLRM-E



Exposed type



Concealed type

CONTENTS

SAFETY PRECAUTIONS	1
1. FEATURES	3
2. PART NAMES AND FUNCTIONS	4
3. SPECIFICATION	6
4. OUTLINES AND DIMENSIONS	8
5. WIRING DIAGRAM	10
6. REFRIGERANT SYSTEM DIAGRAM	11
7. TROUBLE SHOOTING	12
8. DISASSEMBLY PROCEDURE	17

CITY MULTI

For use with the R410A & R407C & R22

SAFETY PRECAUTIONS

1. Before installation and electric work

- ▶ **Before installing the unit, make sure you read all the “Safety precautions”.**
- ▶ **The “Safety precautions” provide very important points regarding safety. Make sure you follow them.**
- ▶ **This equipment may cause the adverse effect on the same supply system.**
- ▶ **Please report to or take consent by the supply authority before connection to the system.**

Symbols used in the text

Warning:

Describes precautions that should be observed to prevent danger of injury or death to the user.

Caution:

Describes precautions that should be observed to prevent damage to the unit.

Symbols used in the illustrations



: Indicates an action that must be avoided.



: Indicates that important instructions must be followed.



: Indicates a part which must be grounded.



: Indicates that caution should be taken with rotating parts. (This symbol is displayed on the main unit label.) <Color: Yellow>



: Beware of electric shock (This symbol is displayed on the main unit label.) <Color: Yellow>

Warning:

Carefully read the labels affixed to the main unit.

Warning:

- **Ask the dealer or an authorized technician to install the air conditioner.**
 - Improper installation by the user may result in water leakage, electric shock, or fire.
- **Install the air unit at a place that can withstand its weight.**
 - Inadequate strength may cause the unit to fall down, resulting in injuries.
- **Use the specified cables for wiring. Make the connections securely so that the outside force of the cable is not applied to the terminals.**
 - Inadequate connection and fastening may generate heat and cause a fire.
- **Prepare for typhoons and other strong winds and earthquakes and install the unit at the specified place.**
 - Improper installation may cause the unit to topple and result in injury.
- **Always use an air cleaner, humidifier, electric heater, and other accessories specified by Mitsubishi Electric.**
 - Ask an authorized technician to install the accessories. Improper installation by the user may result in water leakage, electric shock, or fire.

- **Never repair the unit. If the air conditioner must be repaired, consult the dealer.**
 - If the unit is repaired improperly, water leakage, electric shock, or fire may result.
- **Do not touch the heat exchanger fins.**
 - Improper handling may result in injury.
- **If refrigerant gas leaks during installation work, ventilate the room.**
 - If the refrigerant gas comes into contact with a flame, poisonous gases will be released.
- **Install the air conditioner according to this Installation Manual.**
 - If the unit is installed improperly, water leakage, electric shock, or fire may result.
- **Have all electric work done by a licensed electrician according to “Electric Facility Engineering Standard” and “Interior Wire Regulations” and the instructions given in this manual and always use a special circuit.**
 - If the power source capacity is inadequate or electric work is performed improperly, electric shock and fire may result.
- **Keep the electric parts away from water (washing water etc.).**
 - It might result in electric shock, catching fire or smoke.
- **Securely install the cover of control box and the panel.**
 - If the cover and panel are not installed properly, dust or water may enter the outdoor unit and fire or electric shock may result.
- **When installing and moving the air conditioner to another site, do not charge the it with a refrigerant different from the refrigerant specified on the unit.**
 - If a different refrigerant or air is mixed with the original refrigerant, the refrigerant cycle may malfunction and the unit may be damaged.
- **If the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration from exceeding the safety limit even if the refrigerant should leak.**
 - Consult the dealer regarding the appropriate measures to prevent the safety limit from being exceeded. Should the refrigerant leak and cause the safety limit to be exceeded, hazards due to lack of oxygen in the room could result.
- **When moving and reinstalling the air conditioner, consult the dealer or an authorized technician.**
 - If the air conditioner is installed improperly, water leakage, electric shock, or fire may result.
- **After completing installation work, make sure that refrigerant gas is not leaking.**
 - If the refrigerant gas leaks and is exposed to a fan heater, stove, oven, or other heat source, it may generate noxious gases.
- **Do not reconstruct or change the settings of the protection devices.**
 - If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Mitsubishi Electric are used, fire or explosion may result.
- **To dispose of this product, consult your dealer.**
- **Do not use a leak detection additive.**


2. Precautions for devices that use R410A or R407C refrigerant

Caution:


- **Do not use the existing refrigerant piping.**
 - The old refrigerant and refrigerator oil in the existing piping contains a large amount of chlorine which may cause the refrigerator oil of the new unit to deteriorate.
- **Use refrigerant piping made of C1220 (Cu-DHP) phosphorus deoxidized copper as specified in the *JIS H3300 "Copper and copper alloy seamless pipes and tubes". In addition, be sure that the inner and outer surfaces of the pipes are clean and free of hazardous sulphur, oxides, dust/dirt, shaving particles, oils, moisture, or any other contaminant.**
 - Contaminants on the inside of the refrigerant piping may cause the refrigerant residual oil to deteriorate.

*JIS: Japanese Industrial Standard
- **Store the piping to be used during installation indoors and keep both ends of the piping sealed until just before brazing. (Store elbows and other joints in a plastic bag.)**
 - If dust, dirt, or water enters the refrigerant cycle, deterioration of the oil and compressor trouble may result.
- **Use ester oil, ether oil or alkylbenzene (small amount) as the refrigerator oil to coat flares and flange connections.**
 - The refrigerator oil will degrade if it is mixed with a large amount of mineral oil.
- **Use liquid refrigerant to fill the system.**
 - If gas refrigerant is used to seal the system, the composition of the refrigerant in the cylinder will change and performance may drop.
- **Do not use a refrigerant other than R410A or R407C.**
 - If another refrigerant (R22, etc.) is used, the chlorine in the refrigerant may cause the refrigerator oil to deteriorate.
- **Use a vacuum pump with a reverse flow check valve..**
 - The vacuum pump oil may flow back into the refrigerant cycle and cause the refrigerator oil to deteriorate.
- **Do not use the following tools that are used with conventional refrigerants.**
(Gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, refrigerant recovery equipment)
 - If the conventional refrigerant and refrigerator oil are mixed in the R410A or R407C, the refrigerant may deteriorate.
 - If water is mixed in the R410A or R407C, the refrigerator oil may deteriorate.
 - Since R410A or R407C does not contain any chlorine, gas leak detectors for conventional refrigerants will not react to it.
- **Do not use a charging cylinder.**
 - Using a charging cylinder may cause the refrigerant to deteriorate.
- **Be especially careful when managing the tools.**
 - If dust, dirt, or water gets in the refrigerant cycle, the refrigerant may deteriorate.

Series PFFY Floor Standing Type




Exposed type



Concealed type

Models	Cooling capacity/Heating capacity
	kW
PFFY-P20VLEM-E,PFFY-P20VLRM-E	2.2 / 2.5
PFFY-P25VLEM-E,PFFY-P25VLRM-E	2.8 / 3.2
PFFY-P32VLEM-E,PFFY-P32VLRM-E	3.6 / 4.0
PFFY-P40VLEM-E,PFFY-P40VLRM-E	4.5 / 5.0
PFFY-P50VLEM-E,PFFY-P50VLRM-E	5.6 / 6.3
PFFY-P63VLEM-E,PFFY-P63VLRM-E	7.1 / 8.0

● Indoor (Main) Unit




● Remote controller

[PAR-20MAA]

- Once the controls are set, the same operation mode can be repeated by simply pressing the ON/OFF button.


[Operation buttons]



- | | |
|--|---|
| ① [Room temperature adjustment] Button | ⑦ [Up/down airflow direction] Button |
| ② [Timer/continuous] Button | ⑧ [Ventilation] Button |
| ③ [Selecting operation] Button | ⑨ [Checking/built-in] Button |
| ④ [Time selection] Button | ⑩ [Test run] Button |
| ⑤ [Time-setting] Button | ⑪ [Filter] Button |
| ⑥ [Louver] Button | ⑫ [ON/OFF] Button |
| | ⑬ Position of built-in room temperature |

- Never expose the remote controller to direct sunlight. Doing so can result in the erroneous measurement of room temperature.
- Never place any obstacle around the lower right-hand section of the remote controller. Doing so can result in the erroneous measurement of room temperature.

[Display]



- Ⓐ Current time/Timer
- Ⓑ Centralized control
- Ⓒ Timer ON
- Ⓓ Abnormality occurs
- Ⓔ Operation mode: COOL, DRY, AUTO, FAN, HEAT
- Ⓕ Preparing for Heating mode
- Ⓖ Defrost mode
- Ⓗ Set temperature
- Ⓘ Power ON
- Ⓙ Louver
- Ⓚ Not available function
- Ⓛ Ventilation
- Ⓜ Function setting mode
- Ⓝ Test run mode
- Ⓞ Error check mode
- Ⓟ Filter sign
- Ⓠ Set effective for 1 hr.
- Ⓡ Sensor position
- Ⓢ Room temperature
- Ⓣ Airflow
- Ⓤ Fan speed

3-1. Specification

Item \ Model			PFFY-P20 VLEM-E		PFFY-P25 VLEM-E		PFFY-P32 VLEM-E		PFFY-P40 VLEM-E		PFFY-P50 VLEM-E		PFFY-P63 VLEM-E				
Power source	Voltage	~V	220-240	208-230	220-240	208-230	220-240	208-230	220-240	208-230	220-240	208-230	220-240	208-230			
	Frequency	Hz	50	60	50	60	50	60	50	60	50	60	50	60			
Cooling capacity			kW		2.2		2.8		3.6		4.5		5.6		7.1	Note:1	
Heating capacity			kW		2.5		3.2		4.0		5.0		6.3		8.0		Note:1
Power consumption	Cooling	kW	0.04	0.06	0.04	0.06	0.06	0.07	0.065	0.075	0.085	0.09	0.10	0.11	Note:2		
	Heating	kW	0.04	0.06	0.04	0.06	0.06	0.07	0.065	0.075	0.085	0.09	0.10	0.11			
Current	Cooling	A	0.19	0.25	0.19	0.25	0.29	0.30	0.32	0.33	0.40	0.41	0.46	0.47	Note:2		
	Heating	A	0.19	0.25	0.19	0.25	0.29	0.30	0.32	0.33	0.40	0.41	0.46	0.47			
External finish (Munsel No.)			Galvanized steel plate (5Y 8/1)														
Dimension	Height	mm	630														
	Width	mm	1050					1170					1410				
	Depth	mm	220														
Net weight			kg		23		23		25		26		30		32		
Heat exchanger			Cross fin(Aluminium plate fin and copper tube)														
Fan	Type		Sirocco fanX1							Sirocco fanX2							Note:2
	Airflow rate (Low-High)	m³/min	5.5-6.5		5.5-6.5		7.0-9.0		9.0-11.0		12.0-14.0		12.0-15.5				
	External static pressure	Pa	0														
Motor	Type		Single phase induction motor														
	Output	kW	0.015		0.015		0.018		0.030		0.035		0.050				
Air filter			PP Honeycomb fabric														
Refrigerant pipe dimension	Gas(Flare)	mm	ø 12.7									ø12.7(R410A) ø15.88(R22,R407C)		ø 15.88			
	Liquid(Flare)	mm	ø 6.35									ø6.35(R410A) ø9.52(R22,R407C)		ø 9.52			
Drain pipe dimension			Accessory hose (top end:20)														
Noise level	(Low-High)		34-40					35-40		38-43				40-46		Note:2	

Item \ Model			PFFY-P20 VLRM-E		PFFY-P25 VLRM-E		PFFY-P32 VLRM-E		PFFY-P40 VLRM-E		PFFY-P50 VLRM-E		PFFY-P63 VLRM-E			
Power source	Voltage	~V	220-240	208-230	220-240	208-230	220-240	208-230	220-240	208-230	220-240	208-230	220-240	208-230		
	Frequency	Hz	50	60	50	60	50	60	50	60	50	60	50	60		
Cooling capacity			kW		2.2		2.8		3.6		4.5		5.6		7.1	Note:1
Heating capacity			kW		2.5		3.2		4.0		5.0		6.3		8.0	Note:1
Power consumption	Cooling	kW	0.04	0.06	0.04	0.06	0.06	0.07	0.065	0.075	0.085	0.09	0.10	0.11		
	Heating	kW	0.04	0.06	0.04	0.06	0.06	0.07	0.065	0.075	0.085	0.09	0.10	0.11		
Current	Cooling	A	0.19	0.25	0.19	0.25	0.29	0.30	0.32	0.33	0.40	0.41	0.46	0.47		
	Heating	A	0.19	0.25	0.19	0.25	0.29	0.30	0.32	0.33	0.40	0.41	0.46	0.47		
External finish (Munsel No.)			Galvanized steel plate													
Dimension	Height	mm	639													
	Width	mm	886				1006				1246					
	Depth	mm	220													
Net weight			kg		18.5		18.5		20		21		25		27	
Heat exchanger			Cross fin(Aluminium plate fin and copper tube)													
Fan	Type		Sirocco fanX1						Sirocco fanX2						Note:2	
	Airflow rate (Low-High)	m³/min	5.5-6.5		5.5-6.5		7.0-9.0		9.0-11.0		12.0-14.0		12.0-15.5			
	External static pressure	Pa	0													
Motor	Type		Single phase induction motor													
	Output	kW	0.015		0.015		0.018		0.030		0.035		0.050			
Air filter			PP Honeycomb fabric													
Refrigerant pipe dimension	Gas(Flare)	mm	ø 12.7									ø12.7(R410A) ø15.88(R22,R407C)		ø 15.88		
	Liquid(Flare)	mm	ø 6.35									ø6.35(R410A) ø9.52(R22,R407C)		ø 9.52		
Drain pipe dimension			Accessory hose (top end:20)													
Noise level	(Low-High)		34-40				35-40		38-43				40-46			Note:2

Note: 1. Cooling / Heating capacity indicates the maximum value at operation under the following condition.

Cooling :Indoor 27°CDB/19°CWB
:Outdoor 35°CDB

Heating :Indoor 20°C
:Outdoor 7°CDB/6°CWB

2. The figures represent a 240V/50Hz or 230V/60Hz unit measured at a point which is 1m away from the front of the unit and at a height of 1m from the floor.


The noise is approximately 1dB(A) less for a 230V/50Hz or 220V/60Hz unit and approximately 2dB(A) less for a 220V/50Hz or 208V/60Hz unit. The noise is approximately 3dB(A) less when the measurement point is 1.5m away from the front of the unit and at a height of 1.5m from the floor.

3-2. Electrical parts specification

Model Parts name	Symbol	PFFY-P20 (VLEM-E VLRM-E)	PFFY-P25 (VLEM-E VLRM-E)	PFFY-P32 (VLEM-E VLRM-E)	PFFY-P40 (VLEM-E VLRM-E)	PFFY-P50 (VLEM-E VLRM-E)	PFFY-P63 (VLEM-E VLRM-E)
Transformer	T	(Primary) 50/60Hz 220-240V (Secondary) (18.4V 1.7A)					
Room temperature thermistor	TH21	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ					
Liquid pipe thermistor	TH22	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ					
Gas pipe thermistor	TH23	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ					
Fuse (Indoor controller board)	FUSE	250V 6.3A					
Fan motor (with Inner-thermostat)	MF1,2	4-pole OUTPUT 15W CU-0206B-A	4-pole OUTPUT 15W CU-0206B-A	4-pole OUTPUT 18W CU-0207B-A	4-pole OUTPUT 30W CU-0303B-A	4-pole OUTPUT 35W CRC4415AB	4-pole OUTPUT 50W CU-0507B-A
Inner-thermostat/ thermal fuse (Fan motor)		OFF 130°C±5°C ON 90°C±20°C					FUSE 152°C ^{+5°C} ₀ CUT OFF
Fan motor capacitor	C1	1.5μF X 440V				2.0μF X 440V	2.5μF X 440V
Linear expansion valve	LEV	DC12V Stepping motor drive port dimension ø3.2 (0~1800pulse <at R410A outdoor unit>, 0~2000pulse <at the other outdoor unit>)					
Power supply terminal bed	TB2	(L,N,⊕) 330V 30A					
Transmission terminal bed	TB5 TB15	(1,2),(M1,M2,S) 300V 10A					

PFFY-P20-25-32-40-50-63VLEM-E

Unit:mm




Note: 1. On Model :50, you would use flare nut packed with the Indoor Unit, when connecting the Outdoor Unit for R407C, R22.

2. In order to increase the strength of the flare nut, the size of some of them has been increased.

Dimensions

Model	A	B	C	D	E (Gas)	F (Liquid)	G (Liquid)	G (Gas)
PFFY-P20VLEM-E	1050	640	600	610	ϕ 12.7	ϕ 6.35	17	27
PFFY-P25VLEM-E	1050	640	600	610	ϕ 12.7	ϕ 6.35	17	27
PFFY-P32VLEM-E	1170	760	720	730	ϕ 12.7	ϕ 6.35	17	27
PFFY-P40VLEM-E	1170	760	720	730	ϕ 12.7	ϕ 6.35	17	27
PFFY-P50VLEM-E	1410	1000	960	970	*1: ϕ 12.7 *2: ϕ 15.88	*1: ϕ 6.35 *2: ϕ 9.52	*1: 22 *2: 22	*1: 29 *2: 29
PFFY-P63VLEM-E	1410	1000	960	970	ϕ 15.88	ϕ 9.52	22	29


*1: R410A outdoor unit
*2: The other outdoor unit



Note: 1. On Model :50, you would use flare nut packed with the Indoor Unit, when connecting the Outdoor Unit for R407C, R22.
2. In order to increase the strength of the flare nut, the size of some of them has been increased.


Dimensions												
Model	A	B	C	D	E	F	G (Gas)	H (Liquid)	J (Liquid)	J (Gas)		
PFFY-P20VLRM-E	886	640	572	610	360	4	ø12.7	ø6.35	17	27		
PFFY-P25VLRM-E	886	640	572	610	360	4	ø12.7	ø6.35	17	27		
PFFY-P32VLRM-E	1006	760	692	730	480	5	ø12.7	ø6.35	17	27		
PFFY-P40VLRM-E	1006	760	692	730	480	5	ø12.7	ø6.35	17	27		
PFFY-P50VLRM-E	1246	1000	932	970	720	7	*1 ø12.7 *2 ø15.88	*1 ø6.35 *2 ø9.52	*1 22 *2 22	*1 29 *2 29		
PFFY-P63VLRM-E	1246	1000	932	970	720	7	ø15.88	ø9.52	22	29		

*1:R410A outdoor unit
*2:The other outdoor unit







SYMBOL EXPLANATION

SYMBOL	NAME	SYMBOL	NAME
M F	Fan motor	T H 2 2	Thermistor (piping temp. detection/liquid)
C	*Capacitor (for MF)	T H 2 3	Thermistor (piping temp. detection/gas)
I . B	Indoor controller board	S W 1 1 (A . B)	Switch (1st digit address set)
A . B	Address board	S W 1 2 (A . B)	Switch (2nd digit address set)
T B 2	Power source terminal bed	S W 1 4 (A . B)	Switch (connection No.set)
T B 5	Transmission terminal bed	S W 1 (A . B)	Switch(for mode selection)
T B 1 5	Transmission terminal bed	S W 2 (I . B)	Switch(for capacity code)
F	Fuse AC250V 6.3A F	S W 3 (I . B)	Switch(for mode selection)
T	Transformer	S W 4 (I . B)	Switch(for model selection)
L E V	Electronic linear expan. valve	S W 5 (A . B)	Switch(for voltage selection)
S . B	Surge absorber board	X O 4 ~ 0 6	Aux. relay
T H 2 1	Thermistor (inlet temp. detection)		



Item	PFFY-P20,25,32,40VLEM-E PFFY-P20,25,32,40VLRM-E	PFFY-P50VLEM-E PFFY-P50VLRM-E	PFFY-P63VLEM-E PFFY-P63VLRM-E
Gas pipe	ø 12.7 <1/2F>	ø 12.7 <1/2F> (R410A) ø 15.88 <5/8F> (R22,R407C)	ø 15.88 <5/8F>
Liquid pipe	ø 6.35 <1/4F>	ø 6.35 <1/4F> (R410A) ø 9.52 <3/8F> (R22,R407C)	ø 9.52 <3/8F>

7-1. How to check the parts

Parts name	Check points																																			
Room temperature thermistor (TH21) Liquid pipe thermistor (TH22) Gas pipe thermistor (TH23)	Disconnect the connector, then measure the resistance using a tester. (Surrounding temperature 10°C~30°C)																																			
	<table><tr><td>Normal</td><td>Abnormal</td></tr><tr><td>4.3kΩ~9.6kΩ</td><td>Open or short</td></tr></table>		Normal	Abnormal	4.3kΩ~9.6kΩ	Open or short	(Refer to the thermistor characteristic graph on next page.)																													
Normal	Abnormal																																			
4.3kΩ~9.6kΩ	Open or short																																			
Transformer	Disconnect the connector and measure the resistance using a tester.																																			
	<table><tr><td></td><td>Normal</td><td>Abnormal</td></tr><tr><td>CNT(1)-(3)</td><td>App.15Ω</td><td rowspan="2">Open or short</td></tr><tr><td>CN3T(1)-(3)</td><td>App.4Ω</td></tr></table>				Normal	Abnormal	CNT(1)-(3)	App.15Ω	Open or short	CN3T(1)-(3)	App.4Ω																									
	Normal	Abnormal																																		
CNT(1)-(3)	App.15Ω	Open or short																																		
CN3T(1)-(3)	App.4Ω																																			
Linear expansion valve	Disconnect the connector then measure the resistance valve using a tester. Refer to the next page for a detail.																																			
	<table><tr><td colspan="4">Normal</td><td>Abnormal</td></tr><tr><td>(1)-(5) White-Red</td><td>(2)-(6) Yellow-Blown</td><td>(3)-(5) Orange-Red</td><td>(4)-(6) Blue-Brown</td><td rowspan="2">Open or short</td></tr><tr><td colspan="4">150Ω ±10%</td></tr></table>			Normal				Abnormal	(1)-(5) White-Red	(2)-(6) Yellow-Blown	(3)-(5) Orange-Red	(4)-(6) Blue-Brown	Open or short	150Ω ±10%																						
Normal				Abnormal																																
(1)-(5) White-Red	(2)-(6) Yellow-Blown	(3)-(5) Orange-Red	(4)-(6) Blue-Brown	Open or short																																
150Ω ±10%																																				
Fan motor PFFY-P20~50 VLEM-E/VLRM-E	Measure the resistance between the terminals using a tester. (at 20°C)																																			
	<table><tr><td>Motor terminal or Relay connector</td><td colspan="4">Normal</td><td>Abnormal</td></tr><tr><td></td><td>P20,P25</td><td>P32</td><td>P40</td><td>P50</td><td rowspan="5">Open or short</td></tr><tr><td>Black - White</td><td>335.0</td><td>294.0</td><td>114.0</td><td>101.4</td></tr><tr><td>Red - Yellow</td><td>174.0</td><td>150.0</td><td>80.0</td><td>60.3</td></tr><tr><td>Yellow - Blue</td><td>56.8</td><td>52.0</td><td>30.0</td><td>15.1</td></tr><tr><td>Blue - Black</td><td>99.6</td><td>78.0</td><td>42.0</td><td>29.4</td></tr></table>				Motor terminal or Relay connector	Normal				Abnormal		P20,P25	P32	P40	P50	Open or short	Black - White	335.0	294.0	114.0	101.4	Red - Yellow	174.0	150.0	80.0	60.3	Yellow - Blue	56.8	52.0	30.0	15.1	Blue - Black	99.6	78.0	42.0	29.4
Motor terminal or Relay connector	Normal				Abnormal																															
	P20,P25	P32	P40	P50	Open or short																															
Black - White	335.0	294.0	114.0	101.4																																
Red - Yellow	174.0	150.0	80.0	60.3																																
Yellow - Blue	56.8	52.0	30.0	15.1																																
Blue - Black	99.6	78.0	42.0	29.4																																
PFFY-P63 VLEM-E/VLRM-E	Measure the resistance between the terminals using a tester. (at 20°C)																																			
	<table><tr><td>Motor terminal or Relay connector</td><td>Normal</td><td>Abnormal</td></tr><tr><td></td><td>P63</td><td rowspan="5">Open or short</td></tr><tr><td>Black - White</td><td>112.0</td></tr><tr><td>Red - Yellow</td><td>78.0</td></tr><tr><td>Yellow - Blue</td><td>12.7</td></tr><tr><td>Blue - Black</td><td>50.8</td></tr></table>				Motor terminal or Relay connector	Normal	Abnormal		P63	Open or short	Black - White	112.0	Red - Yellow	78.0	Yellow - Blue	12.7	Blue - Black	50.8																		
Motor terminal or Relay connector	Normal	Abnormal																																		
	P63	Open or short																																		
Black - White	112.0																																			
Red - Yellow	78.0																																			
Yellow - Blue	12.7																																			
Blue - Black	50.8																																			

<Thermistor Characteristic graph>


Thermistor for lower temperature

Room temperature thermistor(TH21)
Liquid pipe thermistor(TH22)
Gas pipe temperature thermistor(TH23)
Drain sensor(DS)

Thermistor $R_0=15k\Omega \pm 3\%$
Fixed number of $B=3480k\Omega \pm 2\%$

$$R_t=15\exp\left\{3480\left(\frac{1}{273+t}-\frac{1}{273}\right)\right\}$$

0°C	15kΩ
10°C	9.6kΩ
20°C	6.3kΩ
25°C	5.2kΩ
30°C	4.3kΩ
40	3.0kΩ




Linear expansion valve

① Operation summary of the linear expansion valve.

- Linear expansion valve open/close through stepping motor after receiving the pulse signal from the indoor controller board.
- Valve position can be changed in proportion to the number of pulse signal.

<Connection between the indoor controller board and the linear expansion valve>



<Output pulse signal and the valve operation>

Output (Phase)	Output			
	1	2	3	4
ø1	ON	OFF	OFF	ON
ø2	ON	ON	OFF	OFF
ø3	OFF	ON	ON	OFF
ø4	OFF	OFF	ON	ON


Closing a valve : 1 → 2 → 3 → 4 → 1

Opening a valve : 4 → 3 → 2 → 1 → 4

The output pulse shifts in above order.

- * 1. When linear expansion valve operation stops, all output phase become OFF.
- 2. At phase interruption or when phase does not shift in order, motor does not rotate smoothly and motor will locks and vibrates.

② Linear expansion valve operation



- * When the switch is turned on, 2200 pulse closing valve signal will be send till it goes to ① point in order to define the valve position.

When the valve move smoothly, there is no noise or vibration occurring from the linear expansion valve : however, when the pulse number moves from ⑤ to ① or when the valve is locked, more noise can be heard than normal situation.

- * Noise can be detected by placing the ear against the screw driver handle while putting the screw driver to the linear expansion valve.


*1:1800pulse at R410A outdoor unit.
2000pulse at the other outdoor unit.

③ Trouble shooting

Symptom	Check points	Countermeasures
Operation circuit failure of the micro processor.	Disconnect the connector on the controller board, then connect LED for checking. 1kΩ LED Pulse signal will be sent out for 10 seconds as soon as the main switch is turn on. If there is LED with lights on or lights off, it means the operation circuit is abnormal.	Exchange the indoor controller board at drive circuit failure.
Linear expansion valve mechanism is locked.	Motor will idle and make ticking noise when motor is operated while the linear expansion valve is locked. This ticking sound is the sign of the abnormality.	Exchange the linear expansion vale.
Short or breakage of the motor coil of the linear expansion valve.	Measure the resistance between the each coil (red-white, red-orange, brown-yellow, brown-blue) using a tester. It is normal if the resistance is in the range of $150\Omega \pm 10\%$.	Exchange the linear expansion valve.
Valve doesn't close completely (thermistor leaking).	To check the linear expansion valve, operate the indoor unit in fan mode and at the same time operate other indoor units in cooling mode, then check the pipe temperature <liquid pipe temperature> of the indoor unit by the outdoor multi controller board operation monitor. During fan operation, linear expansion valve is closed completely and if there are some leaking, detecting temperature of the thermistor will go lower. If the detected temperature is much lower than the temperature indicated in the remote controller, it means the valve is not closed all the way. It is not necessary to exchange the linear expansion valve, if the leakage is small and not making any trouble. Thermistor (TH21) Linear expansion valve	If large amount of refrigeration is leaked, exchange the linear expansion valve.
Wrong connection of the connector or contact failure.	Check the color of lead wire and missing terminal of the connector.	Disconnect the connector at the controller board, then check the continuity.

7-2. Setting of address switch

Make sure that power source is turning off.



1) In case using network remote controller, address is set by rotary switches.(SW11,SW12)

* It is not necessary setting address in case of using unit remote controller.

Indoor unit do not run without address setting in field.

2) Indoor unit address setting rule is different by each field work.

Refer to install manual of outdoor unit , operate the address setting.

3) Setting the address is combination of SW11(1st digit address setting) and SW12(2nd digit address setting).

Address " 3 " setting is composed SW11 " 3 " and SW12 " 0 " .

Address " 25 " setting is composed SW11 " 5 " and SW12 " 2 " .

7-3. Function of Dip-switch

Switch	Pole	Function	Operation by switch		Remarks																													
			ON	OFF																														
SW1 Mode Selection	1	Thermistor<Intake temperature detection>position	Built-in remote controller	Indoor unit	Address board <At delivery> ON OFF 12345678910																													
	2	Filter crogging detection	Provided	Not provided																														
	3	Filter life	2,500hr	100hr																														
	4	Air intake	Effective	Not effective																														
	5	Remote indication switching	Thermostat ON signal indication	Fan output indication																														
	6	Humidifier control	Always operated while the heat is ON	Operated depends on the condition																														
	7	Air flow st	Low	Extra low																														
	8	Heat thermostat OFF	Setting air flow	Reset to SW1-7																														
	9	Auto reset function	Effective	Not effective																														
	10	Power ON/OFF	Effective	Not effective																														
SW2 Capacity code setting	1~6	<table><tr><th>MODELS</th><th>SW2</th><th>MODELS</th><th>SW2</th><th>MODELS</th><th>SW2</th></tr><tr><td>PFFY-P20VLEM-E</td><td> ON OFF 123456 </td><td>PFFY-P25VLEM-E</td><td> ON OFF 123456 </td><td>PFFY-P32VLEM-E</td><td> ON OFF 123456 </td></tr><tr><td>PFFY-P40VLEM-E</td><td> ON OFF 123456 </td><td>PFFY-P50VLEM-E</td><td> ON OFF 123456 </td><td>PFFY-P63VLEM-E</td><td> ON OFF 123456 </td></tr><tr><td>PFFY-P20VLRM-E</td><td> ON OFF 123456 </td><td>PFFY-P25VLRM-E</td><td> ON OFF 123456 </td><td>PFFY-P32VLRM-E</td><td> ON OFF 123456 </td></tr><tr><td>PFFY-P40VLRM-E</td><td> ON OFF 123456 </td><td>PFFY-P25VLRM-E</td><td> ON OFF 123456 </td><td>PFFY-P63VLRM-E</td><td> ON OFF 123456 </td></tr></table>	MODELS	SW2	MODELS	SW2	MODELS	SW2	PFFY-P20VLEM-E	ON OFF 123456	PFFY-P25VLEM-E	ON OFF 123456	PFFY-P32VLEM-E	ON OFF 123456	PFFY-P40VLEM-E	ON OFF 123456	PFFY-P50VLEM-E	ON OFF 123456	PFFY-P63VLEM-E	ON OFF 123456	PFFY-P20VLRM-E	ON OFF 123456	PFFY-P25VLRM-E	ON OFF 123456	PFFY-P32VLRM-E	ON OFF 123456	PFFY-P40VLRM-E	ON OFF 123456	PFFY-P25VLRM-E	ON OFF 123456	PFFY-P63VLRM-E	ON OFF 123456	Indoor controller board Set while the unit is off. <At delivery> Set for each capacity.	
		MODELS	SW2	MODELS	SW2	MODELS	SW2																											
		PFFY-P20VLEM-E	ON OFF 123456	PFFY-P25VLEM-E	ON OFF 123456	PFFY-P32VLEM-E	ON OFF 123456																											
		PFFY-P40VLEM-E	ON OFF 123456	PFFY-P50VLEM-E	ON OFF 123456	PFFY-P63VLEM-E	ON OFF 123456																											
		PFFY-P20VLRM-E	ON OFF 123456	PFFY-P25VLRM-E	ON OFF 123456	PFFY-P32VLRM-E	ON OFF 123456																											
PFFY-P40VLRM-E	ON OFF 123456	PFFY-P25VLRM-E	ON OFF 123456	PFFY-P63VLRM-E	ON OFF 123456																													
SW3 Function Selection	1	Heat pump/Cool only	Cooling only	Heat pump	Indoor controller board Set while the unit is off. <At delivery> ON OFF 12345678 Note:1 At cooling mode, each angle can be used only 1 hour.																													
	2	Louver	Available	Not available																														
	3	Vane	Available	Not available																														
	4	Vane swing function	Available	Not available																														
	5	Vane horizontal angle	Second setting	First setting																														
	6	Vane cooling limit angle setting	Horizontal angle	Down blow																														
	7	—	—	—																														
	8	Heating 4deg up	Not effective	Effective																														
SW4 Unit Selection	1~4	ON OFF 12345 <At delivery>		Indoor controller board Set while the unit is off.																														
SW5 Voltage Selection	2	220V240V If the unit is used at the 230V or 240V area, set the voltage to 240V. If the unit is used at the 220V, set the voltage to 220V.		Address board <At delivery> 220V240V																														

Note 1:The DipSW setting is effective during unit stopping (remote controller OFF) for SW1,2,3 and 4 commonly and the power source is not required to reset.

2:The DipSW setting is effective during unit stopping (remote controller OFF) for SW11,12,14 and 5.

7-4. Function the LED of the indoor unit service board

Symbol	Silk display	LED operation under normal state
LED1	Main power source	At applying main power source (indoor unit 200V) → Lighting
LED2	Transmission power source	At receiving M-NET transmission power source → Lighting

8-1 CONTROL BOX (Exposed type PFFY-P-VLEM)

Be careful removing heavy parts.

OPERATING PROCEDURE

1.Removing the front panel (A)

(1)Remove the fixing screws(two) of the front panel(A).(Fig.1)

(2)Hold the bottom of the front panel with your hands,and gently lift it. The front panel should fall down forward.(Fig.2)

2.Removing the control box cover (B)

(1)Remove the fixing screws(two) of the cover(B) and remove the cover.(Fig.3)

PHOTOS




Fig.1




Fig.2








Fig.3

8-2 THERMISTOR (Gas and liquid piping temperature detection)

Be careful removing heavy parts.

OPERATING PROCEDURE	PHOTOS
1.Removing the side casing (1)Open the control panel cover(A), remove the fixing screws(two) of the securing cover. (Fig. 1) (2)Pull up the side casing(B). (Fig. 2) 2.Removing the thermistor (1)Remove the fixing screws (three), remove the cover (C) and (D). (Fig. 3) (2)Remove the thermistor (gas)(E) and the thermistor (liquid)(F). (Fig. 4)	 Fig.1  Fig.2  Fig.3  Fig.4

8-3 THERMISTOR (Intake air temperature detection)

Be careful removing heavy parts.

OPERATING PROCEDURE	PHOTOS
1.Removing the thermistor (1)Remove the thermistor under the control box.	 Thermistor Fig.1

8-4 DRAINPAN

OPERATING PROCEDURE	PHOTOS
1.Removing the drainpan (1)Remove the fixing screw of the side frame by the control box. (Fig. 1) (2)Slide the drainpan in the direction of the arrow ①.	 Fig.1  Fig.2

8-5 FAN and FAN MOTOR

Be careful removing heavy parts.

OPERATING PROCEDURE

1.Sliding the fan section (Fig.1)

- (1)Remove the fixing screws(two) (a).
- (2)Slide the fan section in direction of the arrow ①.

2.Removing the fan motor (Fig.2)

- (1)Remove the fixing screws (two)(b) of the fan casing(A).
- (2)Remove the fan motor shaft fixing screw and remove the fan casing(A) and sirroco fan.
- (3)Remove the fixing screws(two) (c) of the motor fixtures (two) and remove the motor.

Notice:In case of the Model(PFFY-P32~63) stick out the motor shafts on both side of the motor.

PHOTOS




Fig.1




Fig.2

8-6 HEAT EXCHANGER

Be careful removing heavy parts.

OPERATING PROCEDURE

1.Removing the casing

(1)Remove the fixing screws(six) and remove the casing. (Fig. 1)

2.Removing the cover1,2 with procedure 8-2

(Fig. 2)

3.Removing the Heat exchanger

(1)Remove the fixing screws(four) and remove the heat exchanger support. (Fig. 3)

(2)Remove the heat exchanger, moving from side to side.

PHOTOS




Fig.1




Fig.2







Fig.3

8-7 CASING (Concealed type PFFY-P.VLRM)

Be careful removing heavy parts.

OPERATING PROCEDURE	PHOTOS
1.Removing the casing ass'y (1)Remove the fixing screws (nine) of the plate(A) and remove the plate. (Fig. 1) 2.Removing the air diffuser ass'y (1)Remove the fixing screws (eight) of the air diffuser ass'y(B) and remove it. (Fig. 2) Note: Without this section, almost the disassembly procedures are same as Exposed type (PFFY-P.VLEM) and Concealed type (PFFY-P.VLRM).	 Fig.1  Fig.2  Fig.3



HEAD OFFICE: MITSUBISHI DENKI BLDG., 2-2-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
