


## Mitsubishi Electric Air-conditioner Network System

# Central Controller Model: G-50A

*Installation Manual*



### Contents

1. Safety precautions to be observed without fail .....	1
2. Confirmation of parts .....	2
3. Outline dimensions .....	2
4. System diagram .....	3
5. Installation method .....	4
1. Part prepared at site .....	4
2. Installation method .....	4
6. Initial setting .....	5
1. Address setting method .....	5
2. Function selection method .....	5
3. IP address setting method .....	6
4. Group setting .....	6
5. Others .....	6
7. Test run .....	7
8. Example for system configuration .....	7
1. To control a K control model .....	7
9. External input/output usage method .....	7
1. External signal input function .....	7
2. External signal output function .....	8
3. LAN connection function .....	9

Before using the controller, please read this Installation Manual carefully to ensure proper operation. Keep this manual for future reference.





This manual describes the installation of the central controller and wiring to the air conditioner. Before using the controller, read the **1 Safety precautions to be observed without fail** section carefully to ensure proper installation.

# 1 Safety precautions to be observed without fail

## Safety symbols used in this manual

The following symbols are used in this manual to indicate the type and severity of potential consequences that may result when given instructions are not followed exactly as stated.

 <b>WARNING</b>	Indicates a risk of death or serious injury.
 <b>CAUTION</b>	Indicates a risk of injury or damage to the controller.

Keep this Installation Manual and the Instruction Book for future reference. Make sure both this Installation Manual and the Instruction Book are given to the next user.

## WARNING

**Have the controller professionally installed.**

Improper installation by an unqualified person may result in a risk of electric shock or fire.

**Make sure the controller is securely mounted so that it will not fall.**

**Only use specified cables. Securely connect each cable so that the weight of the cable is not applied to the connectors.**

Loose or improper connections may result in heat generation or fire.

**Do not attempt to modify or repair the controller.**

Modification or improper repair may result in electric shock or fire.

Consult your dealer when repairs are necessary.

**Securely install the controller according to the installation manual.**

Improper installation may result in electric shock or fire.

**Electric work must be performed by authorized personnel according to the local regulations and the installation manual.**

Inadequate circuit capacity or improper installation may result in electric shock or fire.

**Ask your dealer or an authorized technician to move the controller.**

Improper installation may result in electric shock or fire or damage to the controller.

## CAUTION

**Do not install the controller where there is a risk of leakage of flammable gas.**

If the leaked gas accumulates around the controller, it may be ignited and result in an explosion.

**Do not use the controller in an environment high in oil, steam, or sulfuric gas.**

These substances may have adverse effects on the performance of the controller or damage its parts.

**When installing the controller in a hospital or communication facility, take appropriate measures to reduce noise interference.**

Inverter equipment, generators, high-frequency medical equipment, or radio communication equipment may interfere with the normal operation of the controller, or the noise from the controller may interfere with the medical practice or cause image distortion and static noise.

**To prevent over-heating and fire, perform wiring so that the weight of the cable will not strain the connectors.**

**Seal the wire lead-in port with putty to prevent the entry of dew, water, and insects to avoid electric shock or malfunction of the controller.**

**Do not wet the controller.**

Water may damage the controller and cause an electric shock.

**Do not install this controller where the ambient temperature exceeds 40°C (104°F) or drops below 0°C (32°F).**

To prevent deformation and malfunction, install the controller out of direct sunlight.

**To avoid the risk of electric shock or malfunction of the controller, install the controller in a non-condensing environment.**

Do not install this controller in a steamy place, such as a bathroom or kitchen.

**Do not install this controller where an acid or alkaline solution or special chemical spray is used frequently to avoid electric shock or malfunction.**

**Use specified wires with the proper current carrying capacity to prevent current leakage, over-heating, or fire.**

**Do not touch the PCB (Printed Circuit Board) either with your hand or a tool.**

Keep the PCB dust-free to prevent fire or malfunction.

**To avoid the risk of electric shock or damage to the controller, do not touch the switches with wet hands.**

**To avoid the risk of electric shock or damage to the controller, do not press the switches with sharp objects.**

**Do not apply an AC voltage or a voltage higher than 30VDC to the M-NET or the Power (12VDC) terminal blocks on the controller to avoid damage to these parts or fire.**

## 2 Confirmation of parts

\* Please confirm that in addition to this Installation Manual the following items are enclosed in the box.

No.	Part name	Qty.
①	Central controller	1
②	Installation plate	1
③	Wood screw 4.1×16 (use when directly installing on the wall)	2
④	M4 round head screw for main unit installation	2
⑤	M3 round head screw for cover fixing	1
⑥	M4 countersunk screw (M4×40) for installation plate fixing	3
⑦	Instruction book	1






\* If the screw enclosed for installation plate fixing cannot be used because the wall is thick, prepare an M4 countersunk screw with a length matching the wall thickness.

\* Besides the above parts, purchase a power supply unit (PAC-SC50KUA) that supplies power (DC12V) to the central controller and (DC24V) to the M-NET transmission line.


\* If connected to an R410-A compatible model of CITY MULTI outdoor unit (except the S series), G-50A can be powered from the outdoor unit. Note, however, that while the power to the connected outdoor unit is turned off, the G-50A cannot perform a schedule operation, collect charge data, or perform energy save control.

## 3 Outline dimensions

Unit: mm (in)



## 4 System diagram



\* Address setting for each M-NET device (The same address cannot be duplicated).

\* The K transmission converter (PAC-SC25KAA) and OA processing unit (LOSSNAY) are not included in systems shipped to North America (USA & Canada).

	Address setting method	Address
Indoor unit	Set the indoor unit you want to make the master unit in the same group to the minimum address, and sequentially set the indoor unit addresses in the same group.	1~50
Outdoor unit	Min.indoor unit address in same refrigerant system + No.50 unit.	51~100
BC controller/OS controller	Outdoor unit address in same refrigerant system + No.1 unit. However, for Sub-BC controller, minimum indoor unit address that connects the local refrigerant piping + 50.	52~100
K control side remote controller	Same address as indoor unit master unit	1~50
M-NET remote controller	Set to the minimum indoor unit master address in the same group + 100.	101~200
MA remote controller	Address setting is unnecessary.	-
OA processing unit/LOSSNAY	After setting all the indoor units, set an arbitrary address.	1~50
K transmission converter	Min.address of K control indoor unit + No.200 unit.	201~250

### NOTE

\* The following precautions will apply when using the K transmission converter (model: PAC-SC25KAA) and controlling the M-NET model and K control model with the same controller.

Refer to the K transmission converter installation manual for details.

① Central controller address

Always set the controller address to "000".

(Refer to section (6) Initial setting.)

② Central controller function selects

Always set the No.3 function selects of the controller to "ON"

(Refer to section (6) Initial setting.)

③ Indoor unit address

Set all M-NET model indoor units from the No.1 unit, and then set the K control model addresses.

Indoor unit No.1 unit ~M-NET indoor unit max. address->K control indoor unit min. address ~50

④ K control model group No.

The min.indoor address No. of that group becomes the group No. (Same for K control side local remote controller.)

## 5 Installation method


Unit: mm (in)

### 1. Parts prepared at site

- ① Prepare an electric box.
- ② Prepare lock nuts and bushing that match the conduit.
- ③ Prepare an M-NET transmission line CVVS(2-wire): 1.25mm<sup>2</sup> (AWG 16) or equivalent.
- ④ DC power supply line (3-conductor): Provide 0.75mm<sup>2</sup> (AWG 18) or greater.

### 2. Installation method

- ① Secure the space shown on the right when installing the electric box.
- ② When installing the controller on the electric box, the controller will be shifted by 1mm (1/32 in) to the left as shown above.




### NOTE

- \* When installing two controllers horizontally in parallel, secure a clearance of 30mm (1-3/16 in) or more between the products. When installing vertically with the same clearance, removing of the cover will be difficult.
- \* When connecting a LAN and RS-232C, a space for the connector and wiring is required. Provide this space between this unit and the rear of the electric box.

It varies depending on the specifications of the LAN cable that is procured, but the LAN connector may protrude approximately 20mm (25/32 in) from the bottom of the unit cabinet. Provide a cable with the smallest possible connector to secure space.

Reference example) Example of installation when a 67mm (2-5/8 in) deep electric box is used with a 30mm (1-3/16 in) thick wall.



- ③ Connect the M-NET transmission line (centralized control line which is connected to TB7 of the outdoor unit) to M-NET transmission line terminal A and B. (Non Polarity)  
Connect the DC power line from the power supply unit (PAC-SC50KUA) to the DC power supply terminal block of this device. There is a 12VDC and a GND polarity.

- \* Type of wire. Use the cables which comply with the following specifications or equivalent.

M-NET transmission line:

CVVS 1.25mm<sup>2</sup>/AWG 16 (PVC-insulated, PVC-sheathed shield control cable)


CPEVS  $\phi$ 1.2mm/AWG 17 (PE-insulated, PVC-sheathed shield communication cable)

MVVS 1.25mm<sup>2</sup>/AWG 16 (PVC-insulated, PVC-sheathed shield control cable)

DC power line: 0.75mm<sup>2</sup>/AWG 18 or greater 3-conductor power line


### CAUTION

- \* Do not connect the AC power line to the M-NET and POWER (DC12V) terminal blocks of this device. It may cause a failure.
- \* Do not connect to the M-NET transmission line of indoor unit control line which is connected to TB3 of the outdoor unit.
- \* The conduit outlet faces only vertically. When leading the line out from above, seal the port so that water does not enter along the transmission line and DC power supply line.




- ④ Securely seal the line lead-in port with putty to prevent the entry of dew, water and insects, etc.

- \* Seal the connecting section of the electric box and conduit with putty.



- ⑤ Remove the controller's cover and install on to the electric box.


(NOTE)  
The cover fixing screw is packaged with the other enclosed screws.  
Insert a flat-tip screwdriver and rotate it to remove the cover.



<Installation on to electric box>

**NOTE**

- \* When installing the controller directly on to a wall instead of using the electric box, do not use the installation plate.
- \* If the screw enclosed for the installation plate, fixing cannot be used because of the wall thickness, prepare an M4 countersunk screw that matches the wall thickness.
- \* When using an LAN and external signal I/O, refer to section (9 External input/output usage method).




## 6 Initial setting

**NOTE**

- \* Initial settings can be made in one of the following three ways: 1) on the unit, 2) by using the Initial Setting Web via the LAN connection, or 3) by using the Initial Seeing Tool via the LAN connection. In this manual, how to make the initial settings on the unit are described.

- \* Turn on the power supply unit (PAC-SC50KUA) power and run and initially set this unit. When the power is first turned on, the startup screen shown at the right is displayed.  
(When changing the initially set contents after various initial settings were performed and the system was already started, the initial setting menu screen is displayed by pressing the  $\uparrow$  and  $\downarrow$  switches simultaneously for 2 seconds or longer during user operation menu screen display.)  
At the end of various initial settings, return to the user operation menu screen by pressing the  $\uparrow$  and  $\downarrow$  switches simultaneously for 2 seconds or longer.  
Refer to the attached instruction book section 5.Initial setting for further information.



### 1. Address setting method

- ① When the startup screen is displayed at power on, press the  $\boxed{1}$  switch to select "1 ADDRESS SETTING".
- ② Press the  $\boxed{0}$  ~  $\boxed{9}$  switches, and set the address of this unit. (000,201~250)
- ③ When the  $\boxed{\text{BACK SCREEN}}$  switch is pressed after setting, the screen returns.

- \* Always set to [000] when using K transmission converter.
- \* The M-NET address initial value of this unit is [000].

### 2. Function selection method

- ① On the startup screen, press the  $\boxed{2}$  switch to select "2 FUNCTION SETTING".
- ② Switch the function by pressing the  $\boxed{1}$  ~  $\boxed{8}$  switch of the same No. as the function No. you want to change.  
Each time the switch is pressed, the ON/OFF state of that No. is changed.  
No.1 and No.2 cannot be changed.

When Function No. 3 is set to ON, set the K transmission converter address.  
Move the address and Function setting using the  $\uparrow$ ,  $\downarrow$ ,  $\rightarrow$ , and  $\leftarrow$  keys.

<Operation example>

- 1) When the  $\boxed{3}$  switch was pressed
- ON  $\boxed{3}$

OFF  $\boxed{3}$

(OFF)

$\leftrightarrow$

ON  $\boxed{3}$

OFF  $\boxed{3}$

(ON)

- ③ When the  $\boxed{\text{BACK SCREEN}}$  switch is pressed, the screen is returned.


<Function Selection Display>

- No. 1 — OFF: Not used (Fixed to OFF)
- No. 2 — OFF: Not used (Fixed to OFF)
- No. 3 — OFF: K transmission converter not provided/ON: K transmission converter provided
- No. 4 — OFF: Operation prohibit transmission valid/ON: Operation prohibit transmission invalid
- No. 5 — OFF: Emergency stop broadcast enabled/ON: Emergency stop broadcast disabled
- No. 6 —
- No. 7  $\boxed{\phantom{0}}$  External input changeover
- No. 8 — The range of a controller which the operation is prohibited.  
OFF: Both of the systems controller and the local remote controller/ON: Only the local remote controller

<Meanings of function selects>


Function	State	Name	Details
No.1	Fixed to OFF		Not used. Always set this to "OFF"
No.2	Fixed to OFF		Not used. Always set this to "OFF"
No.3 *1	OFF	K transmission converter not provided	The packaged air conditioner to be used is only an M-NET model.
	ON	K transmission converter provided	K control model is included in the packaged air conditioner being used. (In this case, set the controller address "000".) Set the K transmission converter address at this screen. Prepare the K transmission converter (PAC-SC25KAA) separately.
No.4	OFF	Operation prohibit valid	Set this when using as a system controller for which local remote operation prohibit can be set. A system controller set to this can be used only for external input. Note that only one unit can be used in the system.
	ON	Operation prohibit invalid	Set this when using as a system controller for which local remote operation prohibit cannot be used. Set only one unit in the system to the operation prohibit transmission valid setting, and set all other units to the invalid setting.
No.5	OFF	Emergency stop broadcast enabled.	Please be sure to make it "OFF" setting.
	ON	Emergency stop broadcast disabled.	
No.6,7	OFF/ON	External input changeover	This changes the input when using CN3 (external input I/F). (Refer to section (9) External input/output usage method for details.)
No.8	OFF	The range of a controller which the operation is prohibited.	Both of the system controller and the local remote controller.
	ON		Only the local remote controller.

\*1 The K transmission converter (PAC-SC25KAA) is not included in systems shipped to North America (USA & Canada) Always set this to "OFF".



When G-50A controls another system controller or when the system contains only G-50A: G-50A is set as the master system controller.

\* G-50A performs the group setting in this configuration.



\* G-50A does not support slaves.

When G-50A is controlled by another system controller: G-50A is set as the slave system controller.

\* The group setting is performed by Master system controller.

### 3. IP address setting method

When connecting an LAN to this unit, set the IP ADDRESS and MASK ADDRESS.

- ① On the startup screen, press the  3  switch to select "3 IP ADDRESS SETTING".
- ② When the  → (↓) or  ← (↑) switch is pressed, the cursor moves to right or left.
- ③ Set both addresses using the  1  ~  8  switches.
- ④ When the  BACK SCREEN  switch is pressed, the screen is returned.

### 4. Group setting

\* Set the group configuration with indoor units, local remote controllers (only when M-NET type used) and slave system controller to be controlled by this unit.

\* Select "4 (or 1) GROUP SETTING" on the menu screen in the initial setting mode, and set the group configuration.

\* Refer to the attached instruction book section 5 Initial Setting for the initial setting method.

### 5. Others

\* Since the screen switches from the startup screen to the initial setting menu screen after group setting, choose the menu and perform setting and monitoring, as required.

- Interlocked setting (Sets interlocking between ventilator and indoor unit.)
- Refrigerant monitor (Outdoor unit and indoor unit refrigeration connection can be monitored.)
- Malfunction monitor (Past abnormality history can be monitored.)
- User setting (Real-time display information selection and setting.)

Refer to the attached instruction book sections 5-5 Interlocked operation setting to 6-2 Malfunction log monitor function for a detailed description of the functions and settings.

When all the initial settings are complete, initiate startup communication by holding down the  ↑  and  ↓  switches on the initial setting menu screen simultaneously for at least 2 seconds. After a while, the display shifts to the user operation menu screen.

Refer to the attached instruction book section 5 Initial setting for further information.



## 7 Test run


- \* After setting the group or interlocked setting, confirm that the controller has started up, and then perform a test run.
  - \* It may take approx. 10 minutes for local remote controller operation to be enabled after the power is turned ON. In this case, press the ON/OFF button on the controller to enable immediate local remote controller operation.
- (Test run procedure)

1. Turn ON the Power to the controller and all the units.
  2. When the “INITIAL SETTING (PLEASE WAIT)” blink on the controller LCD stops, press the “① ON/OFF switch” and the “temperature setting switch ▲” at the same time.
  3. Confirm the run state (indoor unit outlet air temperature, cool air, confirmation, etc.) during the test run.
  4. When each unit has been confirmed, stop the unit with the controller or local remote controller. Even if the units are not stopped, the test run will stop automatically after approx. 2 hours.
- \* Refer to the installation manual for the connected indoor unit for details on the test run method.

## 8 Example for system configuration

### 1. To control a K control model

- \* Set G-50A address to “000” When a K transmission converter is connected. Always set to the master system controller when the address is “000”.
- \* Make the address of the K-control models of indoor units larger than that of the M-transmission models of indoor units.
- \* When using a group setting for the K control model, set only the indoor unit that belongs to that group.
- \* Set the min.indoor unit address in the group for the K control model group No.
- \* When connected to a K-transmission converter, set the function setting switch No.3 to “ON” (with connection to K-transmission converter).
- \* Set the master system controller function select No.4 to “OFF” (operation prohibit transmission valid) when the K transmission controller is connected.



## 9 External input/output usage method

### 1. External signal input function

- \* External signal input requires the external I/O adapter (Model: PAC-YG10HA-E) sold separately.


#### (1) External input

Emergency stop/normal, run/stop and prohibit/enable of local remote controller operation can be controlled for all air conditioners being controlled by using a voltage (DC12V or DC24V) contact signal from an external source. (Select with the function select setting.)


No.	External signal input function	Function		Remarks
		No.6	No.7	
1	Do not use external input signal (factory setting)	OFF	OFF	
2	Execute emergency stop/normal with level signal	OFF	ON	The local remote controller ON/OFF operations, and the controller ON/OFF operation and prohibit/enable change operations will be prohibited during emergency stop. Timer operation will also be prohibited.
3	Perform ON/OFF with level signal	ON	OFF	The local remote controller ON/OFF operations, and the controller ON/OFF operations and prohibit/enable change operations will be prohibited. Timer operation will also be prohibited.
4	Perform ON/OFF, prohibit/enable with pulse signals.	ON	ON	Set the pulse width while the contact is ON to 0.5 to 1 sec.

#### (2) Level signal and pulse signal (DC12V or DC24V)

##### (A) Level signal



##### (B) Pulse signal (Example) for ON/OFF



\*The prohibit/enable input is the same.

(3) External input specifications

CN2	Lead wire	Emergency stop/normal level signal	ON/OFF, level signal	ON/OFF, prohibit/enable pulse signal
No.5	Orange	Emergency stop/normal input	ON/OFF input	ON input
No.6	Yellow	Not used	Not used	OFF input
No.7	Blue	Not used	Not used	Local remote controller operation prohibit input
No.8	Gray	Not used	Not used	Local remote controller operation enable input
No.9	Red	External DC source "+ DC12V" or "+ DC24V"		

(A) For level signal


- ① When the emergency stop/normal signal is selected, the status will change from normal to emergency stop when the external input signal contact changes from OFF to ON, and will change from emergency stop to normal when the contact changes from ON to OFF. Air conditioning units that came to an emergency stop will remain stopped after the emergency stop is cancelled. Manually start up each unit to restore the previous operation.
- ② When the ON/OFF signal is selected, the status will change from OFF to ON when the external input signal contact changes from OFF to ON, and will change from ON to OFF when the contact changes from ON to OFF.

(B) For pulse signal


- ① Even if the ON signal is input during ON, the status will remain ON.
- ② If the local remote controller is prohibited, the ON/OFF operation mode and temperature setting operations by the local remote controller will be prohibited.
- ③ Set the pulse width (contact ON time) to 0.5 to 1 sec.

(4) Recommended circuit example

(A) For level signal



(B) For pulse signal



Use relays X1, X2, Y1, and Y2 that meet the following specifications.

- Operating coil
- Rated voltage : DC12V, DC24V
- Power consumption: 0.9 W or less

(\*1) Prepare a power supply separately according to the relay being used. (DC12V or DC24V)

- ① The contact relay, DC power source, extension cable, etc., must be prepared separately at the site.
- ② The connection cable can be extended up to 10m (32 ft). (Use a 0.3mm<sup>2</sup> (AWG 22) or larger wire.)
- ③ Strip the extra cable near the connector, and securely insulate the exposed section with tape, etc.

2. External signal output function

\* External signal output requires the external I/O adapter (Model: PAC-YG10HA-E) sold separately.

(1) External output


When one or more air conditioners are running, the "ON" signal will be output and if a malfunction occurs in one or more air conditioners, the "Malfunction" signal will be output.

(2) External output specifications

CN 2	Lead wire	Details of each terminal
No.1	Green	Common (External ground)
No.2	Black	ON/OFF
No.3	Brown	Malfunction/normal

- ① The "ON" signal is output even while the "Malfunction" signal is being output.

(3) Recommended circuit example



Use Z1 and Z2 relays that meet the following specifications.

Operation coil

Rated voltage : DC12V, DC24V

Power Consumption: 0.9W or less


(\*1) Prepare a power supply separately according to the relay being used. (DC12V or DC24V)

(\*2) Always insert a diode on both ends of the relay coil.

- ① Each element will turn on while ON operation or a malfunction occurs.
- ② The connection cable can be extended up to 10m (32 ft).
- ③ The relays, lamps, diodes and extension cables, etc, must be prepared separately at the site.

**NOTE**

\* When connecting the external input/output cables to connector CN2 on the controller, Peel off the label on the controller connector section.




**3. LAN connection function**

When using the LAN connection function, connect the LAN cable to the Ethernet connector of this device.

\* Procure the LAN cable at the site, and use 10 BASE-T Straight cable.

\* For a description of the IP address setting method, refer to section (6 Initial setting).

\* LAN is 10 BASE-T Specification.



**CAUTION**

- \* Perform the LAN wiring before installation, and wire up to the body by the same method as wiring the M-NET transmission line.
- \* When a LAN is already connected, decide the IP address by consultation with the system administrator and connect to the LAN body after changing the IP address.
- \* When connecting an LAN connector, space for the connector and wiring is required. Provide this space at this unit and the rear of the electric box. Refer to section (5 Installation method).
- \* When the G-50A cover is opened, the LAN status lamp and LAN changeover switch are accessed. For detailed information, refer to sections 3-2 and 5-9 of the Instruction Book.

This product is designed and intended for use in the residential,  
commercial and light -industrial environment.

The product at hand is  
based on the following  
EU regulations:

- Low Voltage Directive 73/23/EEC
- Electromagnetic Compatibility Directive 89/  
336/EEC