

1. THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SAFETY

- Please provide an exclusive circuit for the air conditioner and do not connect other electrical appliances to it.
- Be sure to read "THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SAFETY" before installing the air conditioner.
- Be sure to observe the cautions specified here as they include important items related to safety.
- The indications and meanings are as follows.

WARNING
 Could lead to death, serious injury, etc.

CAUTION
 Could lead to serious injury in particular environments when operated incorrectly.

After reading this manual, be sure to keep it together with the OPERATING INSTRUCTIONS in a handy place on the customer's site.

WARNING

- Do not install the unit by yourself (customer).
- Incomplete installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or special installer.

- Install the unit securely in a place which can bear the weight of the unit.
- When installed in an insufficient strong place, the unit could fall causing injury.
- Use the specified wires to connect the indoor and outdoor units securely and attach the wires firmly to the terminal block connecting sections so the stress of the wires is not applied to the sections.
- Incomplete connecting and living could cause fire.

- Do not use intermediate connection of the power cord or the extension cord and do not connect many devices to one AC outlet.
- It could cause a fire or an electric shock due to electrical contact, defective insulation, exceeding the permissible current, etc.
- Check that the refrigerant gas do not leak after installation has completed.

- If refrigerant gas leaks indoors, and comes into contact with the fire of a fan heater, space heater, stove, etc., harmful substances will be generated.
- Perform the installation securely referring to the installation manual.

- Incomplete installation could cause a personal injury due to fire, electric shock, the unit falling or leakage of water.
- Perform electrical work according to the installation manual and be sure to use an exclusive circuit.
- If the capacity of the power circuit is insufficient or there is incomplete electrical work, it could result in a fire or an electric shock.

- Attach the electrical cover to the indoor unit and the service panel to the outdoor unit securely.
- If the electrical cover in the indoor unit and/or the service panel in the outdoor unit are not attached securely, it could result in a fire or an electric shock due to dust, water, etc.

- Be sure to use the part provided or specified parts for the installation work.
- The use of defective parts could cause an injury or leakage of water due to a fire, an electric shock, the unit falling, etc.
- Be sure to cut off the main power in case of setting up the indoor electronic control P.C. board or wiring works.
- It could cause an electric shock.
- The appliance shall be installed in accordance with national wiring regulations.



3. INSTALLATION DIAGRAM & ACCESSORIES

FLARED CONNECTIONS
 This unit has flared connections on both indoor and outdoor sides.
 • Remove the outdoor units valve cover, then connect the pipes.
 • Refrigerant pipes are used to connect the indoor and outdoor units.
 • Be careful not to crush or bend the pipe in pipe bending.

Limits

Pipe length	20 m max.
Height difference	12 m max.
No. of bends	10 max.

Refrigerant adjustment... If pipe length exceeds 7 m, additional refrigerant (R410A) charge is required.
 (The outdoor unit is charged with refrigerant for pipe length up to 7 m.)

Pipe length	Up to 7 m	No additional charge is required.
	Exceeding 7 m	Additional charge is required. (Refer to the table below.)
Refrigerant to be added		30 g/m × (refrigerant piping length (m) - 5)

ACCESSORIES

Check the following parts before installation.

<Indoor unit>


Installation plate	1
Installation plate fixing screw (4 × 25 mm)	7
Remote controller holder	1
Fixing screw for 3.5 × 16 mm (Black)	2
Battery (AAA) for remote controller	2
Wireless remote controller	1
Felt tape (Used for left or left-rear piping)	1
Air cleaning filter	2

<Outdoor unit: For VV type only>

Drain socket	1
--------------	---

PART TO BE PROVIDED AT YOUR SITE

Optional extension pipe	
Indoor/outdoor unit connecting wire (4-core 1.0 mm ²)	1
Extension pipe	1
Wall hole sleeve	1
Wall hole cover	1
Pipe fixing band (The quantity depends on the pipe length)	2 to 5
Fixing screw for 3 × 20 mm (The quantity depends on the pipe length)	2 to 5
Piping tape	1
Putty	1
Drain hose (or soft PVC hose, 15 mm inner dia. or hard PVC pipe VP16)	1 or 2
Refregiration oil	1





Note: When operating the air conditioner in low outside temperature, be sure to follow the instructions described below.
 • Never install the outdoor unit in a place where its inlet/outlet side may be exposed directly to wind.
 • To prevent exposure to wind, install the outdoor unit with its inlet side facing the wall.
 • To prevent exposure to wind, it is recommended to install a baffle board on the air outlet side of the outdoor unit.

Units should be installed by licensed contractor according to local code requirement.

4. INDOOR UNIT INSTALLATION

4-1 FIXING OF INSTALLATION PLATE



- Find a structural material (such as a stud) in the wall and fix installation plate horizontally.



When bolts recessed in the concrete wall are to be utilized, secure the installation plate using 11 × 30 (11 × 28 steel hole (450 mm pitch)). If the recessed bolts is too long, change it for a shorter one available in the market.


4-2 WALL HOLE DRILLING

- 1 Determine the wall hole position.
- 2 Drill a 75 mm hole so that outside can be lower than inside.
- 3 Insert the wall hole sleeve.



Be sure to use wall hole sleeve to prevent the outdoor connecting wires from contacting with metal part in the wall and to prevent damage by rat in case the wall is hollow.

Wall hole sealing and fixing pipe to wall



6. INDOOR/OUTDOOR UNIT CONNECTION FINISHING AND TEST RUN

INSTALLATION INFORMATION FOR THE AIR CONDITIONER WITH R410A REFRIGERANT

- This room air conditioner adopts an HFC refrigerant (R410A) which will never destroy the ozone layer.
- Pay particular attention to the following points, though the basic installation procedure is same as that for R22 air conditioners.
- As R410A has a working pressure approx. 1.6 times as high as that of R22, some special tools and piping parts/materials are required. (Refer to the table below.)
- Take sufficient care not to allow water and other contaminants to enter the R410A refrigerant during storage and installation, since it is more susceptible to contaminants than R22.
- For refrigerant piping, use clean, pressure-proof parts/materials specifically designed for R410A. (Refer to 2. Refrigerant piping.)
- Compositon change may occur in R410A since it is a mixed refrigerant. When charging, charge liquid refrigerant to prevent composition change.

6-1 Tools dedicated for the air conditioner with R410A refrigerant

The following tools are required for R410A refrigerant. Some R22 tools can be substituted for R410A tools.


R410A tools	Can R22 tools be used?	Description
Gauge manifold	No	R410A has high pressures beyond the measuring range of existing gauges. Port diameters have been changed to prevent any other refrigerant from being charged into the unit.
Charge hose	No	Hose material and cap size have been changed to improve the pressure resistance.
Gas leak detector	No	Dedicated for HFC refrigerant.
Torque wrench	Yes	14 and 3/8
Flare tool	Yes	Clamp bar hole has been enlarged to reinforce the spring strength in the tool.
Flare gauge	New	Provided for flaring work (to be used with R22 flare tool).
Vacuum pump adaptor	New	Provided to prevent the back flow of oil. This adaptor enables you to use existing vacuum pumps.
Electronic scale for refrigerant charging	New	It is difficult to measure R410A with a charging cylinder because the refrigerant bubbles due to high pressure and high-speed vaporization.

No: Not substitutable for R410A. Yes: Substitutable for R410A


6-2 FLARING WORK

- Main cause of gas leakage is defect in flaring work.
- Carry out correct flaring work in the following procedure.


- 1 Pipe cutting
- 2 Burrs removal



- 3 Burrs removal
- 4 Flaring work



- 5 Outdoor unit connection
- 6 Tightening torque



Insulation and taping
 • Cover piping joints with pipe cover.
 • For outdoor unit side, surely insulate every piping including valves.
 • Using piping tape, apply taping starting from the entry of outdoor unit.
 • Stop the end of piping tape with tape (with adhesive agent attached).
 • When piping have to be arranged through above ceiling, closet or where the temperature and humidity are high, wind additional commercially sold insulation for prevention of condensation.

4-3 POWER SUPPLY AND CONNECTING WIRE SPECIFICATIONS

- Use special room air conditioning circuit.

Power supply cord length (Lead to left/Lead to right)	0.3 m/1 m
Indoor/outdoor unit connecting wire Specification	Cable 4-core 1.0 mm ² , in conformity with Design 245 IEC 57.

- Take out power supply cord from the left or right bottom corner of the indoor unit.

Connect to the power switch which has a gap of 3 mm or more when open to interrupt the source power phase. (When the power switch is shut off, it must interrupt all phases.) (Rated Voltage/Frequency: 220 V/50 Hz) (Input capacity Main switch/Fuse:10 A) (This plug has to be the one meets the Standards.)
 Power supply cord
 Blue: N
 Brown: L

WARNING

Never cut the indoor and outdoor unit connecting wire and connect to other wires. It may cause a fire.


Do not bundle the spare wire, but put it as shown below.



4-4 INDOOR AND OUTDOOR CONNECTING WIRE CONNECTION

You can connect indoor/outdoor lead wire without removing the front panel.

- 1 Open the front panel.
- 2 Remove one screw holding the electrical cover, then remove the cover.
- 3 Remove the VA clamp.
- 4 Pass the indoor/outdoor unit connecting wire from the back of the indoor unit and process the end of the wire, then connect it to the terminal block.
- 5 Replace the future and electrical cover securely.




Indoor/outdoor unit connecting wire

WARNING

- Use the indoor/outdoor unit connecting wire that meets the Standards to connect the indoor and outdoor units and fix the wire to the terminal block securely so that no external force is conveyed to the connecting section of the terminal block.
- Incomplete connection or fraying of the wire could cause a fire.
- Attach the electrical cover due to safety. If it is attached incorrectly, it could result in a fire or an electric shock due to dust, water, etc.




Loosen terminal screw. Insert the indoor/outdoor unit connecting wire into the terminal block. Tighten terminal screw.



Indoor/outdoor unit connecting wire

WARNING


- Use the indoor/outdoor unit connecting wire that meets the Standards to connect the indoor and outdoor units and fix the wire to the terminal block securely so that no external force is conveyed to the connecting section of the terminal block.
- Incomplete connection or fraying of the wire could cause a fire.
- Attach the electrical cover due to safety. If it is attached incorrectly, it could result in a fire or an electric shock due to dust, water, etc.



Indoor/outdoor unit connecting wire


FOR REAR, RIGHT OR DOWNWARD PIPING

- Pipe arrangement
- Put the refrigerant piping and the drain hose together, then apply piping tape to them.



Be careful drain hose is not heated. Firmly apply piping tape from the end. Cut off in case of right piping. Cut off in case of downward piping.

- Insert the piping and the drain hose into the wall hole sleeve, and hook the upper part of the indoor unit on the installation plate.
- Check if the indoor unit is hooked securely on the installation plate by moving the unit to left and right.
- Thrust the lower part of the indoor unit into the installation plate.



Be careful drain hose is not heated. Firmly apply piping tape from the end. Cut off in case of right piping. Cut off in case of downward piping.


- Carry out flaring work using flaring tool as shown below.



Clutch type Wing nut type
 Copper pipe Flare nut Copper pipe

Flaring work
 Carry out flaring work using flaring tool as shown below.

Check
 • Compare the flared work with figure below.
 • If flare is noted to be defective, cut off the flared section and do flaring work again.



Smooth all around Inside is shining without any scratches. Even length all around

6-3 PIPE CONNECTION

- Fasten a flare nut with a torque wrench as specified in the table below.
- When fastened too tight, a flare nut may broken after a long period and cause a leakage of refrigerant.
- Apply a thin coat of refrigeration oil on the seat surface of the pipe.
- For this connection first align the center, then tighten the first 3 to 4 turns of flare nut.
- Use tightening torque table below as a guideline for indoor unit side union joint section, and tighten using two wrenches. Excessive tightening damages the flare section.

Pipe diameter	Tightening torque
mm	N·m
kgf·cm	
6.35	13.7 to 17.7
9.52	34.5 to 41.2

Insulation and taping
 • Cover piping joints with pipe cover.
 • For outdoor unit side, surely insulate every piping including valves.
 • Using piping tape, apply taping starting from the entry of outdoor unit.
 • Stop the end of piping tape with tape (with adhesive agent attached).
 • When piping have to be arranged through above ceiling, closet or where the temperature and humidity are high, wind additional commercially sold insulation for prevention of condensation.



Insulation and taping
 • Cover piping joints with pipe cover.
 • For outdoor unit side, surely insulate every piping including valves.
 • Using piping tape, apply taping starting from the entry of outdoor unit.
 • Stop the end of piping tape with tape (with adhesive agent attached).
 • When piping have to be arranged through above ceiling, closet or where the temperature and humidity are high, wind additional commercially sold insulation for prevention of condensation.

CAUTION

- Be careful not to make mis-wiring.
- Firmly tighten the terminal screws to prevent them from loosening.
- After tightening, pull the wires lightly to confirm that they do not move.
- If the connecting wire is incorrectly connected to the terminal block, the unit does not operate normally.
- If an earth is incorrect, it may cause an electric shock.

4-5 AUTO RESTART FUNCTION

- These models are equipped with an auto restart function. If you do not want to use this function, please consult the service representative because the setting of the unit needs to be changed.
- When the indoor unit is controlled with the remote controller, the operation mode, the set temperature, and the fan speed are memorized by the indoor electronic control P.C. board. The auto restart function sets to work the moment the power has restored after power failure, then, the unit will restart automatically. If the unit is operated in "F.EEL..." or "AUTO" mode before power failure, the operation mode (COOL, DRY or HEAT) is not stored in the memory. When the main power is turned on, the unit decides the operation mode by the initial room temperature at restart and starts operation again.


Operation

- If the main power has been cut, the operation settings remain.
- When three minutes have passed after power was restored, the unit will restart automatically according to the memory.

Notes:
 • The operation settings are memorized when 10 seconds have passed after the remote controller was operated.
 • If the main power is turned off or a power failure occurs while AUTO START/STOP timer is active, the timer setting is cancelled. As these models are equipped with an auto restart function, the air conditioner starts operating with timer cancelled at the same time that power is restored.
 • If the unit has been off with the remote controller before power failure, the auto restart function does not work as the power button of the remote controller is off.
 • To prevent breaker off due to the rush of starting current, systematize other home appliances not to turn on at the same time.


4-6 PIPE FORMING

- Place the drain hose below the refrigerant piping.
- Make sure that the drain hose is not heated or snaked.
- Do not pull the hose to apply the tape.
- When the drain hose passes the room, be sure to wrap insulating material (obtainable at a store) around it.
- Wrap the felt tape around the pipe and the drain hose, then put the pipe in the back space of the indoor unit.




Be careful drain hose is not heated. Firmly apply piping tape from the end. Cut off in case of right piping. Cut off in case of downward piping.

- Insert the piping and the drain hose into the wall hole sleeve, and hook the upper part of the indoor unit on the installation plate.
- Check if the indoor unit is hooked securely on the installation plate by moving the unit to left and right.
- Thrust the lower part of the indoor unit into the installation plate.



Be careful drain hose is not heated. Firmly apply piping tape from the end. Cut off in case of right piping. Cut off in case of downward piping.

- Carry out flaring work using flaring tool as shown below.



Clutch type Wing nut type
 Copper pipe Flare nut Copper pipe

Flaring work
 Carry out flaring work using flaring tool as shown below.

Check
 • Compare the flared work with figure below.
 • If flare is noted to be defective, cut off the flared section and do flaring work again.



Smooth all around Inside is shining without any scratches. Even length all around

6-4 PURGING PROCEDURES-LEAK TEST

PURGING PROCEDURES
 Connect the refrigerant pipes (both liquid pipe and the gas pipe) between the indoor and the outdoor unit.

Remove the service port cap of the stop valve on the side of the outdoor unit gas pipe. (The stop valve will not work in its initial state: fresh out of the factory (totally closed with cap on).)

Connect the gauge manifold valve and the vacuum pump to the service port of the stop valve on the gas pipe side of the outdoor unit.

Run the vacuum pump. (Vacuumize for more than 15 minutes.)

Check the vacuum with the gauge manifold valve, then close the gauge manifold valve, and stop the vacuum pump.

Leave as it is for one or two minutes. Make sure the pointer gauge manifold valve remains in the same position. Confirm that the pressure gauge shows ~0.101 Mpa (Gauge) (~760 mmHg).



*4 to 5 turns
 Remove the gauge manifold valve quickly from the service port of the stop valve.

After refrigerant pipes are connected and evacuated, fully open all stop valves on both sides of gas pipe and liquid pipe. Operating without fully opening lowers the performance and this causes trouble.

Pipe length up to 7 m
 No gas charge is needed.

Pipe length exceeding 7 m
 Charge the prescribed amount of gas. (refer to 3)

Tighten the cap to the service port to obtain the initial status.

Relighten the cap.

Leak test

Tightening torque

Cap for service port	N·m	kgf·cm
	13.7 to 17.7	140 to 180
Cap for stop valve	19.6 to 29.4	200 to 300

Insulation and taping
 • Cover piping joints with pipe cover.
 • For outdoor unit side, surely insulate every piping including valves.
 •