
# LOSSNAY HANDBOOK

Model : VL-100U5-E VL-100EU5-E



Repair work must be performed by the manufacturer, its service agent or a similarly qualified person in order to avoid hazards.

## MITSUBISHI ELECTRIC CORPORATION


## Contents

1. Safety precautions ······3
2. Names and functions of components4
3. Specifications4
4. Outside dimensions
5. Electrical wiring diagrams6
6. Troubleshooting ······7-8
7. How to call
8. Service inspection list ······9
9. Overhauling procedures
10. Parts catalog ······16-24
VL-100U5-E ····· 17-20
VL-100EU5-E ····· 21-24

## 1. Safety precautions

- Read the following precautions thoroughly before the maintenance, and then inspect and repair the product in a safe manner.
- The types and levels of danger that may arise if the product is handled incorrectly are described with the warning symbols shown below.


	ncorrect handling of the product may esult in serious injury or death.
<ul> <li>Electric shock</li> <li>If you must inspect the circuitry while the power is on, do not touch the live parts.</li> <li>(Failure to heed this warning may result in electric shock.)</li> <li>Modification is prohibited</li> </ul>	
<ul> <li>(Failure to heed this warning may result in electric shock, fire and/or injury.)</li> </ul>	
Proper electric work Use the electric wires designated for electric work and conduct electric work in accordance with the "Electric Installation Engineering Standard", the "Indoor Wiring Regulations" and the installation instructions.	electric shock, fire and/or injury.)       Be sure to follo <b>Replace damaged and/or degraded parts</b> Be sure to replace the power cord and lead wires if         they are damaged and/or degraded.         (Failure to heed this warning may result         in electric shock and/or fire.)
may result in electric shock and/or fire.) Be sure to this instru	



## **Request for repair**

- Inspect the grounding, and repair it if it is incomplete. Make sure that a power supply isolator or an overload protection device is installed, if it is not installed, recommend the dealer to install one.
- Make sure that the product operates properly upon completion of repair. Clean the product and the surrounding area, and then notify the customer of the completion of repair.

## 2. Names and functions of components



### \*About the filters


			Features
Exhaust air filter	-	Exhaust air side	The filter prevents clogging of the internal parts.
Outside air filter (Replacement filter)	(P-100F5-E: Optional parts)	Supply air side	When Lossnay takes in outside air to a room, the filter collects dust, sand, pollen or the likes from outside air. Note: Some fine particles or tiny insects may pass through the filter. The high performance filter is recommended for higher collecting effect.
Outside air filter can	be replaced with the	e following hig	gh performance filter.
High performance filter (Optional parts)	(P-100HF5-E)	Supply air side	The filter collects dust more efficiently than the outside air filter. Note: When using the high performance filter, install it in the filter frame without using the filter stopper.

## 3. Specifications


	Power	supply		Power con-	Air volume	Temperature	Sound level	Weight
Model	Frequency (Hz)	Voltage (V)	Notch	sumption (W)	ption (m <sup>3</sup> /h)	exchange efficiency (%)	(dB)	(kg)
		220	Hi	30	100	73	36.5	
		220	Lo	13	55	80	24	
VL-100U₅-E	50	50 230 240	Hi	31	105	73	37	7.5
			Lo	15	60	80	25	
VL-100EU₅-E			Hi	34	106	72	38	7.5
			Lo	17	61	79	27	
	60 220	Hi	34	103	73	38		
		220	Lo	17	57	80	25	

\* The testing methods are based on Japanese Industrial Standard B 8628.

## 4. Outside dimensions



## 5. Electrical wiring diagrams




## 6. Troubleshooting

- Work precautions
- When servicing, be sure to recreate the malfunction two or three times before starting repairs.
- When servicing, always keep proper footing.
- When servicing, always unplug the power cord from the outlet, or turn off the circuit breaker. Sufficient care must be taken to avoid electric shock or injury.
- Always connect the power wires properly.

### (1) Service Flowchart

After checking the check items below, follow the troubleshooting 1 and 2 for servicing.



### (2) Checklist

Troubleshooting 1 Lossnay does not operate, or it stops by itself.

①Initialization checklist from installation to operation (Table 1)

No.	Error	Checkpoint
1	The Lossnay operation is disabled or improper.	Check the main power connection. <for vl-100u₅-e=""></for>
	Lossnay stops irregularly.	<ul> <li>Is the power plug connected to the power supply of rated voltage?</li> <li><for vl-100eu<sub="">5-E&gt;</for></li> </ul>
		<ul><li>Is the rated voltage supplied to the terminal block?</li><li>Is there a poor connection?</li></ul>

Troublesheating 2	Lossnay operates irregularly.
moubleshouling z	Lussnay operates inegularly.

#### 2 Lossnay checklist (Table 2)

No.	Error	Cause	Action
1	The shutter does not open. The shutter does not close.	Is there any foreign matter or obstruction around the shutter?	Remove it.
2	The fan does not rotate.	Do the fan blades touch other parts? Is there any foreign matter around the fan? Is there something wrong with the motor?	Check for an abnormal area. Replace the parts of the abnormal area. Remove it. Check the basic checklist for the major components (Table 3).
3	An unusual noise comes from the fan.	Is there any foreign matter around the fan? Can you rotate the fan manually? Is there an odd feeling when rotating the fan?	

No.	Error	Cause	Action
3	An unusual	Is there something wrong with the motor?	Check the basic checklist for the major
	noise comes		components (Table 3).
	from the fan.		Replace the abnormal parts.
4	High/Low lamp	Is Lossnay operating at the High or Low	If the lamp does not illuminate during the
	does not illumi-	fan speed?	High or Low fan speed operation, replace
	nate.		the neon lamp.

3 Basic checklist for the major components (Table 3)

\*Make sure to unplug the power cord or turn off the circuit breaker, before performing the procedures No. 2 to 4.

No.	Parts		Judging instructions				
1	_	Check th	Check that the fan rotate while the rated voltage is supplied.				
2	Fuse	Check if	the fuse is blown o	ut.			
		If the fus	e is blown out, repl	ace the fuse			
3	Switch with a pull		the switch from the			sistance at the	e weld for the
	cord		nection on the back				
	(VL-100U5-E only)	If the res	sistance differs from	the value lis	sted below, repl	ace the switc	n.
			Color of wires	Notch	Resist	ance	
			White - Red	High	Approx. 0.1 Ω	(conducted)	
			White - Blue	Low	Applox. 0.1 12	(conducted)	
4	Motor	Measure <for vl-<br="">Measure minals o • If the tors. • If the</for>	<ul> <li>If the resistance is approximately equal to the value listed below, replace the capacitors.</li> </ul>				
	Notch         Resistance           High         Approx. 490 Ω						
			Low		prox. 0.1 Ω		
			OFF (VL-100U₅-E onl		Open		

## 7. How to call

Symptom	Remedy
The incoming air feels cold.	<ol> <li>Stop the operation, and close the shutter.</li> <li>Adjust the louver in a horizontal position.</li> <li>Change the fan speed to Low.</li> </ol>
Unusual noise occurs. (Noise became louder.)	<ol> <li>Clean the filters.</li> <li>Securely attach the front panel and filters.</li> </ol>
Small insects intrude into the unit.	<ol> <li>Place the filter (outside air filter) properly inside the filter frame.</li> <li>Replace the filter (outside air filter) with the high performance filter (optional parts).</li> </ol>

## 8. Service inspection list

Location	Inspection Item	Check Result
Electric	Are the power lead wires securely connected to the terminal block? (VL-100EU5-E)	
wiring	Is the wiring correct? (VL-100EU5-E)	
Is the main unit securely mounted?		
	Does Lossnay operate as described in the Operating Instructions when oper- ating the switch?	
Appliance	Is the fan operating?	
	Does the shutter work?	
	Does Lossnay operate without abnormal vibration or noise?	


## 9. Overhauling procedures

#### Work precautions

- Before replacing parts, follow the instructions described in the troubleshooting.
- When servicing, always keep proper footing.
- When servicing, always unplug the power cord from the outlet, or turn off the circuit breaker. Sufficient care must be taken to avoid electric shock or injury.
- Always connect the power wires properly.
- After completing repairs, verify that the product operates properly.
- Always wear gloves when servicing.

### (1) Turning power off

- 1 Stop the operation by the switch.
- ②Unplug the power cord from the outlet, or turn off the circuit breaker.






### (2) Power lead wires to the terminal block


For VL-100EU5-E

①Open the front panel.




Front panel

②Unhook the claw of the cover, and remove the cover.



Cover

3 Unscrew the terminal block (TB) case cover clamping screw (one PT screw 4 × 8, indicated by O), and remove the TB case cover.





TB case cover


(4) Loosen the screws of the terminal block (three screws, indicated by O) with a screwdriver, and disconnect the power lead wires.



①Unscrew the main unit clamping screws (two black PTT screws  $4 \times 8$ , indicated by  $\bigcirc$ ).

②Slightly lift the main unit, and then take it down.






\*The illustration shows VL-100U5-E.

## (4) Front panel

• Open the front panel all the way (approx. 90 degrees), and pull it up to unhook the claws (indicated by O).

#### Precaution Pay attention not to damage the front surface of the removed panel.

Front panel







### (5) Lossnay core

• Hold the core handle, and pull it out in the direction of the arrow while holding down the hook part.


Hook part



<Reassembly procedure>

• When installing the Lossnay core, first fit the lower part of the core handle (indicated by "a") into "b" position of the front casing, and then hook the ledge of the core handle to the concave portion of the front casing (indicated by □).

Core handle



Ledge





<Installed state>

Reassembly precaution Check that both edges of the Lossnay core (indicated by  $\bigcirc$ ) are securely fitted.



### (6) Front casing

(1) Unscrew the screws (six PTT screws  $4 \times 14$ , indicated by O).



Front casing


②Unscrew the lamp cover clamping screw (one PTT screw 4 × 14, indicated by O), and remove the lamp cover.



Lamp cover

③Remove the neon lamp from the front casing.

④Pass the neon lamp through the hole of the front casing, and then remove the front casing.






Neon lamp Hole of the front casing

### (7) Air exhaust (EA) fan

①Remove the special nut (8) and tab washer, and then remove the EA fan.




Special nut (8)

Tab washer

2 Remove the special (spl) washer (40 mm in outer diameter).

Reassembly precaution Be aware of the size difference between each washer for EA fan and SA fan. Incorrect installation may cause unusual noise.



Spl washer

## (8) Air supply (SA) fan

the SA fan.

(1)Unscrew the motor fix plate clamping screw (one PTT screw 4  $\times$  14, indicated by O).

<sup>2</sup>Turn the motor fix plate upside down, and put it on the main unit.

③Remove the special nut (8) and tab washer, and then remove

Motor fix plate







Special nut (8)

Tab washer

④Remove the special (spl) washer (8) (16 mm in outer diameter).

Reassembly precaution Be aware of the size difference between each washer for EA fan and SA fan. Incorrect installation may cause unusual noise.



Spl washer (8)

### (9) Motor

• Unscrew the screws that clamps motor and lead cover (six PTT screws 4 × 10, indicated by O), and then remove the motor.

### Reassembly precaution

When installing the lead cover, make sure to place it under the motor (indicated by  $\Box$ ).



Lead cover

Motor

### (10) Terminal block case (TB case)

①Unscrew the TB case clamping screw (one PT screw 4 × 8, indicated by O), and remove the TB case.



TB case


②Unscrew the TB fix plate clamping screws (two PTT screws 4 × 8, indicated by O), and remove the TB fix plate.



TB fix plate

## (11) Fan casing

• Remove the fan casing (made of styrene foam).



### \* When reassembling

- Reassemble the unit in the reverse order of disassembly.
- After reassembly, always make a test run to make sure that the unit operates properly.

## 10. Parts catalog


## Please note the following when using the parts catalog.

- 1. When ordering parts, always indicate the part number, part name, and the number of parts required.
- 2. Parts are not always available, and it may take time for you to receive them.
- 3. There may be specification improvements.
- 4. Parts marked  $\triangle$  are critical for safety. To maintain safety and performance, always replace these parts with the parts prescribed.

## Description of screw abbreviations


	$\underline{\underline{4}} \times \underline{\underline{16}}$		
Scre	ew diameter Length		
Abbreviation	Description		
PC screw	Cross recess flat head machine screw		
PRC screw	Cross recess oval head machine screw		
PP screw	Cross recess pan head machine screw		
SW · PP screw	Cross recess pan head screw with spring washer		
PPT screw	Cross recess tapping screw		
PCT screw	Cross recess flat head tapping screw		
PTT screw	Cross recess truss head tapping screw		
PT screw	Cross recess truss head machine screw		
SET screw	Slotted head stop screw		
SQ · SET screw	Square head stop screw		
P · SET screw	Pan head stop screw		
PMT screw	Primer truss head screw		
HS · SET screw	Hexagon head stop screw		
$P \cdot R \cdot W$ screw	Cross recess round wood screw		
P · C · W screw	Cross recess flat head wood screw		
$P \cdot R \cdot C \cdot W$ screw	Cross recess round and flat wood screw		
R · W screw	Slotted round wood screw		
PW · PP screw	Cross recess pan head screw with small washer		
SW-PW · PP screw	Cross recess pan head machine screw with spring washer and flat washer		

## VL-100U5-E



## VL-100U5-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Front panel	Y36 004 721	1		
2	Lossnay core	Y36 004 723	1		
3	Core handle	Y36 004 722	1		
4	Cover	Y36 004 709	1		
5	Front casing	Y36 004 707	1		
6	PTT screw 4×14	H00 000 333	8		
7	PTT screw 4×10	M32 013 027	1		
8	Filter	Y36 004 717	1		
9	Lamp cover	Y36 004 711	1		
10	Neon lamp	Y36 004 290	1		
11	TB case cover	Y36 004 710	1		
12	PT screw 4×8	H00 000 349	3		
13	TB case	Y36 004 708	1		
14	Cord band	K83 170 228	1		White
15	Crimp cap	K82 181 240	6		CE1(CE-100V)
16	Cord clamper	M35 855 223	1		
17	Cord clamper	M35 830 223	1		
18	PT screw 4×8 BS	H00 011 008	3		
19	Spg. washer (4)	H00 056 075	3		
20	PTT screw 4×8	H00 000 487	6		
21	Cord clip	X31 981 223	1		
22	Cord clip	D40 094 227	2		
23	Fuse	Y36 004 280	1		1A·250V
24	PPT screw 3×10	H00 000 676	1		
25	Fuse holder	Y55 001 281	1		
26	Cord bush	M45 649 226	2		
27	TB fix plate	Y36 004 712	1		
28	PPT screw 4×10	H00 000 471	1		
29	Switch	Y36 004 255	1		With a pull cord
30	Insulator sheet	M34 279 201	1		
31	Capacitor case	M35 768 653	1		
32	Capacitor	M34 203 283	1		4.0µF·220VAC
33	Capacitor cover	M35 275 652	1		
34	Capacitor	Y81 016 284	1		1.5µF·440VAC
35	Power cord	Y36 004 220	1		3200mm



## VL-100U5-E


No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	Wall pipe	M36 091 731	2		
42	Pipe fix plate	M36 293 707	2		
43	Fix plate	M36 100 709	1		
44	Spl scr 3.5×32	M34 863 045	9		
45	PTT screw 4×8	M45 502 095	2		Black
46	Weather cover	M36 099 707	2		
47	Flange	M36 099 708	2		
48	Flange nut	M34 231 303	2		
49	Packing	M34 519 718	2		
50	PTT screw 4×12	D41 037 008	4		SUS
51	Filter stopper	Y36 004 714	1		
52	Pipe	Y36 004 706	2		
53	Filter frame	Y36 004 713	1		
54	Special nut (8)	X31 267 067	2		
55	Tab washer	M36 130 077	2		
56	Centrifugal fan	M36 265 480	1		φ170
57	Spl washer	M36 265 080	1		φ40 (outer dia.)
58	Motor	Y36 004 453	1		
59	Spl washer (8)	M34 365 080	1		φ16 (outer dia.)
60	PTT screw 4×10	H00 000 332	6		
61	Cord clamper	R50 062 223	1		
62	Lead cover	M36 169 712	1		
63	Motor fix plate	Y36 004 715	1		
64	Centrifugal fan	Y36 004 480	1		φ170
65	Fan casing	Y36 004 724	1		
66	Mounting piece	M34 709 345	2		
67	Shutter	Y36 004 719	1		
68	Shutter	Y36 004 720	1		
69	Casing	Y36 004 716	1		
70	Casing assembly	Y36 004 725	1		With shutters

## VL-100EU5-E



## VL-100EU5-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
1	Front panel	Y36 004 721	1		
2	Lossnay core	Y36 004 723	1		
3	Core handle	Y36 004 722	1		
4	Cover	Y36 004 709	1		
5	Front casing	Y36 004 707	1		
6	PTT screw 4×14	H00 000 333	8		
7	PTT screw 4×10	M32 013 027	1		
8	Filter	Y36 004 717	1		
9	Lamp cover	Y36 004 711	1		
10	Neon lamp	Y36 004 290	1		
11	Wiring diagram	Y36 005 357	1		
12	TB case cover	Y36 004 710	1		
13	PT screw 4×8	H00 000 349	3		
14	TB case	Y36 005 706	1		
15	Crimp cap	K82 181 240	5		CE1(CE-100V)
16	Cord clamper	M35 855 223	1		
17	Cord band	K83 170 228	1		White
18	PT screw 4×8 BS	H00 011 008	3		
19	Spg. washer (4)	H00 056 075	3		
20	PTT screw 4×8	H00 000 487	6		
21	Cord clip	D40 134 227	1		
22	PPT screw 3×20	H00 005 005	1		
23	Terminal block	Y36 005 242	1		3P
24	Cord clip	D40 094 227	2		
25	Fuse	Y36 004 280	1		1A·250V
26	PPT screw 3×10	H00 000 676	1		
27	Fuse holder	Y55 001 281	1		
28	Cord bush	M45 649 226	2		
29	TB fix plate	Y36 005 707	1		
30	Capacitor case	M35 768 653	1		
31	Capacitor	M34 203 283	1	Â	4.0μF•220VAC
32	Capacitor cover	M35 275 652	1		
33	Capacitor	Y81 016 284	1		1.5µF•440VAC



## VL-100EU5-E

No.	Name of part	Parts No.	Q'ty pcs/unit	Critical for safety	Remarks
41	Wall pipe	M36 091 731	2		
42	Pipe fix plate	M36 293 707	2		
43	Fix plate	M36 100 709	1		
44	Spl scr 3.5×32	M34 863 045	9		
45	PTT screw 4×8	M45 502 095	2		Black
46	Weather cover	M36 099 707	2		
47	Flange	M36 099 708	2		
48	Flange nut	M34 231 303	2		
49	Packing	M34 519 718	2		
50	PTT screw 4×12	D41 037 008	4		SUS
51	Filter stopper	Y36 004 714	1		
52	Pipe	Y36 004 706	2		
53	Filter frame	Y36 004 713	1		
54	Special nut (8)	X31 267 067	2		
55	Tab washer	M36 130 077	2		
56	Centrifugal fan	M36 265 480	1		φ170
57	Spl washer	M36 265 080	1		φ40 (outer dia.)
58	Motor	Y36 004 453	1		
59	Spl washer (8)	M34 365 080	1		φ16 (outer dia.)
60	PTT screw 4×10	H00 000 332	6		
61	Cord clamper	R50 062 223	1		
62	Lead cover	M36 169 712	1		
63	Motor fix plate	Y36 004 715	1		
64	Centrifugal fan	Y36 004 480	1	$\mathbf{\Lambda}$	φ170
65	Fan casing	Y36 004 724	1		
66	Mounting piece	M34 709 345	2		
67	Shutter	Y36 004 719	1		
68	Shutter	Y36 004 720	1		
69	Casing	Y36 004 716	1		
70	Casing assembly	Y36 004 725	1		With shutters