

AIR CONDITIONING SYSTEMS

CITY MULTI DATA BOOK

MODEL

PQHY-P200-900Y(S)LM-A

PQRY-P200-900Y(S)LM-A

CITY MULTI

Databook

HEAT SOURCE UNITS

GENERAL LINE-UP

WY SERIES	1
WR2 SERIES.....	83

SYSTEM DESIGN

SYSTEM DESIGN WY SERIES	165
SYSTEM DESIGN WR2 SERIES	203

Heat Pump WY Series



PQHY-P200YLM-A
PQHY-P300YLM-A

PQHY-P250YLM-A

8, 10, 12HP



PQHY-P350YLM-A
PQHY-P450YLM-A
PQHY-P550YLM-A

PQHY-P400YLM-A
PQHY-P500YLM-A
PQHY-P600YLM-A

14, 16, 18, 20, 22, 24HP



PQHY-P400YSLM-A
PQHY-P500YSLM-A
PQHY-P600YSLM-A

PQHY-P450YSLM-A
PQHY-P550YSLM-A

16, 18, 20, 22, 24HP



PQHY-P700YSLM-A
PQHY-P800YSLM-A
PQHY-P900YSLM-A

PQHY-P750YSLM-A
PQHY-P850YSLM-A

28, 30, 32, 34, 36HP

Heat Recovery WR2 Series



PQRY-P200YLM-A
PQRY-P300YLM-A

PQRY-P250YLM-A

8, 10, 12HP



PQRY-P350YLM-A
PQRY-P450YLM-A
PQRY-P550YLM-A

PQRY-P400YLM-A
PQRY-P500YLM-A
PQRY-P600YLM-A

14, 16, 18, 20, 22, 24HP



PQRY-P400YSLM-A
PQRY-P500YSLM-A
PQRY-P600YSLM-A

PQRY-P450YSLM-A
PQRY-P550YSLM-A

16, 18, 20, 22, 24HP



PQRY-P700YSLM-A
PQRY-P800YSLM-A
PQRY-P900YSLM-A

PQRY-P750YSLM-A
PQRY-P850YSLM-A

28, 30, 32, 34, 36HP

HEAT SOURCE UNITS

1. SPECIFICATIONS	2
2. EXTERNAL DIMENSIONS	21
3. CENTER OF GRAVITY	26
4. ELECTRICAL WIRING DIAGRAMS	27
5. SOUND LEVELS	28
6. OPERATION TEMPERATURE RANGE	33
7. CAPACITY TABLES	34
7-1. Correction by temperature	34
7-2. Correction by total indoor	53
7-3. Correction by refrigerant piping length	60
8. SYSTEM DESIGN GUIDE	64
8-1. Designing of water circuit system	64
8-2. Water piping work	76
9. OPTIONAL PARTS	80
9-1. JOINT	80
9-2. HEADER	81
9-3. OUTDOOR TWINNING KIT	82

1. SPECIFICATIONS

HEAT SOURCE

WY

Model			PQHY-P200YLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	22.4	
		kcal/h	20,000	
		BTU/h	76,400	
	Power input	kW	3.71	
		A	6.2-5.9-5.7	
		EER	6.03	
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	25.0	
		kcal/h	21,500	
		BTU/h	85,300	
	Power input	kW	3.97	
		A	6.7-6.3-6.1	
		COP	6.29	
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity	
	Model/Quantity		P15~P250/1~17	
Sound pressure level (measured in anechoic room)		dB <A>	46	
Sound power level (measured in anechoic room)		dB <A>	60	
Refrigerant piping diameter	Liquid pipe	mm (in.)	9.52 (3/8) Brazed	
	Gas pipe	mm (in.)	19.05 (3/4) Brazed	
Circulating water	Water flow rate	m ³ /h	5.76	
		L/min	96	
		cfm	3.4	
	Pressure drop	kPa	24	
	Operating volume range	m ³ /h	3.0 ~ 7.2	
Compressor	Type		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter	
	Motor output	kW	4.8	
	Case heater	kW	-	
	Lubricant		MEL32	
External finish			Galvanized steel sheets	
External dimension H x W x D		mm	1,100 x 880 x 550	
		in.	43-5/16 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection	
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)	
	Control		LEV and HIC circuit	
Net weight		kg (lbs)	174 (384)	
Heat exchanger			plate type	
	Water volume in plate	l	5.0	
	Water pressure Max.	MPa	2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure	
Drawing	External		WKS94C746	
	Wiring		WKE94G131	
Standard attachment	Document		Installation Manual	
	Accessory		Refrigerant conn. pipe	
Optional parts			Joint: CMY-Y102SS/LS-G2 Header: CMY-Y104, 108, 1010-G	
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>	

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WV

Model			PQHY-P250YLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	28.0	
		kcal/h	25,000	
		BTU/h	95,500	
	*1	Power input	kW	4.90
		Current input	A	8.2-7.8-7.5
		EER	kW/kW	5.71
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	31.5	
		kcal/h	27,100	
		BTU/h	107,500	
	*2	Power input	kW	5.08
		Current input	A	8.5-8.1-7.8
		COP	kW/kW	6.20
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity	
	Model/Quantity		P15-P250/1~21	
Sound pressure level (measured in anechoic room)		dB <A>	48	
Sound power level (measured in anechoic room)		dB <A>	62	
Refrigerant piping diameter	Liquid pipe	mm (in.)	9.52 (3/8) Brazed (12.7 (1/2) Brazed, farthest length >= 90 m)	
	Gas pipe	mm (in.)	22.2 (7/8) Brazed	
Circulating water	Water flow rate	m ³ /h	5.76	
		L/min	96	
		cfm	3.4	
	Pressure drop	kPa	24	
	Operating volume range	m ³ /h	3.0 ~ 7.2	
Compressor	Type		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter	
	Motor output	kW	6.2	
	Case heater	kW	-	
	Lubricant		MEL32	
External finish			Galvanized steel sheets	
External dimension H x W x D	mm		1,100 x 880 x 550	
	in.		43-5/16 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection	
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)	
	Control		LEV and HIC circuit	
Net weight	kg (lbs)		174 (384)	
Heat exchanger			plate type	
	Water volume in plate	l	5.0	
	Water pressure Max.	MPa	2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure	
Drawing	External		WKS94C746	
	Wiring		WKE94G131	
Standard attachment	Document		Installation Manual	
	Accessory		Refrigerant conn. pipe	
Optional parts			Joint: CMY-Y102SS/LS-G2 Header: CMY-Y104, 108, 1010-G	
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WY

Model			PQHY-P300YLM-A
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz
Cooling capacity (Nominal)	*1	kW	33.5
		kcal/h	30,000
		BTU/h	114,300
	Power input	kW	6.04
		A	10.1-9.6-9.3
		kW/kW	5.54
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Heating capacity (Nominal)	*2	kW	37.5
		kcal/h	32,300
		BTU/h	128,000
	Power input	kW	6.25
		A	10.5-10.0-9.6
		kW/kW	6.00
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity
	Model/Quantity		P15~P250/1~26
Sound pressure level (measured in anechoic room)		dB <A>	54
Sound power level (measured in anechoic room)		dB <A>	68
Refrigerant piping diameter	Liquid pipe	mm (in.)	9.52 (3/8) Brazed (12.7 (1/2) Brazed, farthest length >= 40 m)
	Gas pipe	mm (in.)	22.2 (7/8) Brazed
Circulating water	Water flow rate	m ³ /h	5.76
		L/min	96
		cfm	3.4
	Pressure drop	kPa	24
	Operating volume range	m ³ /h	3.0 ~ 7.2
Compressor	Type		Inverter scroll hermetic compressor
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION
	Starting method		Inverter
	Motor output	kW	7.7
	Case heater	kW	-
	Lubricant		MEL32
External finish			Galvanized steel sheets
External dimension H x W x D		mm	1,100 x 880 x 550
		in.	43-5/16 x 34-11/16 x 21-11/16
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection
	Compressor		Over-heat protection
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)
	Control		LEV and HIC circuit
Net weight		kg (lbs)	174 (384)
Heat exchanger			plate type
Water volume in plate		l	5.0
		MPa	2.0
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure
Drawing	External		WKS94C746
	Wiring		WKE94G131
Standard attachment	Document		Installation Manual
	Accessory		Refrigerant conn. pipe
Optional parts			Joint: CMY-Y102SS/LS-G2 Header: CMY-Y104, 108, 1010-G
Remarks			Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice. The ambient temperature of the heat source unit needs to be kept below 40°C D.B. The ambient relative humidity of the heat source unit needs to be kept below 80%. The heat source unit should not be installed at outdoor. Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit. Be sure to provide interlocking for the unit operation and water circuit. Install the supplied insulation material to the unused drain-socket. When installing insulation material around both water and refrigerant piping, follow the installation manual.

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WV

Model			PQHY-P350YLM-A
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz
Cooling capacity (Nominal)	*1	kW	40.0
		kcal/h	35,000
		BTU/h	136,500
	Power input	kW	7.14
		A	12.0-11.4-11.0
		EER	5.60
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Heating capacity (Nominal)	*2	kW	45.0
		kcal/h	40,000
		BTU/h	153,500
	Power input	kW	7.53
		A	12.7-12.0-11.6
		COP	5.97
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity
	Model/Quantity		P15-P250/1~30
Sound pressure level (measured in anechoic room)		dB <A>	52
Sound power level (measured in anechoic room)		dB <A>	66
Refrigerant piping diameter	Liquid pipe	mm (in.)	12.7 (1/2) Brazed
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed
Circulating water	Water flow rate	m ³ /h	7.20
		L/min	120
		cfm	4.2
	Pressure drop	kPa	44
	Operating volume range	m ³ /h	4.5 ~ 11.6
Compressor	Type		Inverter scroll hermetic compressor
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION
	Starting method		Inverter
	Motor output	kW	9.5
	Case heater	kW	-
	Lubricant		MEL32
External finish			Galvanized steel sheets
External dimension H x W x D	mm		1,450 x 880 x 550
	in.		57-1/8 x 34-11/16 x 21-11/16
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection
	Compressor		Over-heat protection
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)
	Control		LEV and HIC circuit
Net weight	kg (lbs)		217 (479)
Heat exchanger			plate type
	Water volume in plate	l	5.0
	Water pressure Max.	MPa	2.0
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure
Drawing	External		WKS94C747
	Wiring		WKE94G131
Standard attachment	Document		Installation Manual
	Accessory		Refrigerant conn. pipe
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>		

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WY

Model			PQHY-P400YLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	45.0	
		kcal/h	40,000	
		BTU/h	153,500	
	Power input	kW	8.03	
		A	13.5-12.8-12.4	
		kW/kW	5.60	
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	50.0	
		kcal/h	45,000	
		BTU/h	170,600	
	Power input	kW	8.37	
		A	14.1-13.4-12.9	
		kW/kW	5.97	
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity		
	Model/Quantity	P15~P250/1~34		
Sound pressure level (measured in anechoic room)		dB <A>	52	
Sound power level (measured in anechoic room)		dB <A>	66	
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed	
Circulating water	Water flow rate	m ³ /h	7.20	
		L/min	120	
		cfm	4.2	
	Pressure drop	kPa	44	
	Operating volume range	m ³ /h	4.5 ~ 11.6	
Compressor	Type		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter	
	Motor output	kW	10.7	
	Case heater	kW	-	
	Lubricant		MEL32	
External finish			Galvanized steel sheets	
External dimension H x W x D		mm	1,450 x 880 x 550	
		in.	57-1/8 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection	
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)	
	Control		LEV and HIC circuit	
Net weight		kg (lbs)	217 (479)	
Heat exchanger			plate type	
	Water volume in plate	l	5.0	
	Water pressure Max.	MPa	2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure	
Drawing	External		WKS94C747	
	Wiring		WKE94G131	
Standard attachment	Document		Installation Manual	
	Accessory		Refrigerant conn. pipe	
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G	
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>	

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

Model			PQHY-P450YLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	50.0	
		kcal/h	45,000	
		BTU/h	170,600	
	*1	Power input	kW	9.29
		Current input	A	15.6-14.8-14.3
		EER	kW/kW	5.38
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	56.0	
		kcal/h	50,000	
		BTU/h	191,100	
	*2	Power input	kW	9.79
		Current input	A	16.5-15.7-15.1
		COP	kW/kW	5.72
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity	
	Model/Quantity		P15~P250/1~39	
Sound pressure level (measured in anechoic room)		dB <A>	54	
Sound power level (measured in anechoic room)		dB <A>	70	
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed	
Circulating water	Water flow rate	m ³ /h	7.20	
		L/min	120	
		cfm	4.2	
	Pressure drop	kPa	44	
	Operating volume range	m ³ /h	4.5 ~ 11.6	
Compressor	Type		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter	
	Motor output	kW	11.6	
	Case heater	kW	-	
	Lubricant		MEL32	
External finish			Galvanized steel sheets	
External dimension H x W x D		mm	1,450 x 880 x 550	
		in.	57-1/8 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection	
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)	
	Control		LEV and HIC circuit	
Net weight		kg (lbs)	217 (479)	
Heat exchanger			plate type	
	Water volume in plate	l	5.0	
	Water pressure Max.	MPa	2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure	
Drawing	External		WKS94C747	
	Wiring		WKE94G131	
Standard attachment	Document		Installation Manual	
	Accessory		Refrigerant conn. pipe	
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G	
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>	

Notes:	Unit converter
<p>1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)</p> <p>2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)</p>	<p>BTU/h =kW x 3,412</p> <p>cfm =m³/min x 35.31</p> <p>lbs =kg/0.4536</p>
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WY

Model			PQHY-P500YLM-A			
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1	kW	56.0			
		kcal/h	50,000			
		BTU/h	191,100			
	Power input	kW	11.17			
		Current input	A	18.8-17.9-17.2		
		EER	kW/kW	5.01		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Heating capacity (Nominal)	*2	kW	63.0			
		kcal/h	55,000			
		BTU/h	215,000			
	Power input	kW	11.43			
		Current input	A	19.2-18.3-17.6		
		COP	kW/kW	5.51		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity				
	Model/Quantity	P15~P250/1~43				
Sound pressure level (measured in anechoic room)		dB <A>	54			
Sound power level (measured in anechoic room)		dB <A>	70.5			
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed			
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed			
Circulating water	Water flow rate	m ³ /h	7.20			
		L/min	120			
		cfm	4.2			
	Pressure drop	kPa	44			
	Operating volume range	m ³ /h	4.5 ~ 11.6			
Compressor	Type	Inverter scroll hermetic compressor				
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION				
	Starting method	Inverter				
	Motor output	kW	13.0			
	Case heater	kW	-			
	Lubricant	MEL32				
External finish		Galvanized steel sheets				
External dimension H x W x D		mm	1,450 x 880 x 550			
		in.	57-1/8 x 34-11/16 x 21-11/16			
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)				
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection				
	Compressor	Over-heat protection				
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)				
	Control	LEV and HIC circuit				
Net weight		kg (lbs)	217 (479)			
Heat exchanger		plate type				
		Water volume in plate	l	5.0		
		Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)		Copper pipe, tube-in-tube structure				
Drawing	External	WKS94C747				
	Wiring	WKE94G131				
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts		Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G				
Remarks		<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WV

Model			PQHY-P550YLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	63.0	
		kcal/h	55,000	
		*1 BTU/h	215,000	
	Power input	kW	12.54	
		Current input	A	21.1-20.1-19.3
		EER	kW/kW	5.02
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	69.0	
		kcal/h	60,000	
		*2 BTU/h	235,400	
	Power input	kW	12.27	
		Current input	A	20.7-19.6-18.9
		COP	kW/kW	5.62
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity	
	Model/Quantity		P15~P250/2~47	
Sound pressure level (measured in anechoic room)		dB <A>	56.5	
Sound power level (measured in anechoic room)		dB <A>	71.5	
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed	
Circulating water	Water flow rate	m ³ /h	11.52	
		L/min	192	
		cfm	6.8	
	Pressure drop	kPa	45	
	Operating volume range	m ³ /h	6.0 ~ 14.4	
Compressor	Type		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter	
	Motor output	kW	15.0	
	Case heater	kW	0.045 (240 V)	
	Lubricant		MEL32	
External finish			Galvanized steel sheets	
External dimension H x W x D		mm	1,450 x 880 x 550	
		in.	57-1/8 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection	
Refrigerant	Type x original charge		R410A x 11.7 kg (26 lbs)	
	Control		LEV and HIC circuit	
Net weight		kg (lbs)	246 (543)	
Heat exchanger			plate type	
	Water volume in plate	l	10.0	
	Water pressure Max.	MPa	2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure	
Drawing	External		WKS94C748	
	Wiring		WKE94G131	
Standard attachment	Document		Installation Manual	
	Accessory		Refrigerant conn. pipe	
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G	
Remarks			Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice. The ambient temperature of the heat source unit needs to be kept below 40°C D.B. The ambient relative humidity of the heat source unit needs to be kept below 80%. The heat source unit should not be installed at outdoor. Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit. Be sure to provide interlocking for the unit operation and water circuit. Install the supplied insulation material to the unused drain-socket. When installing insulation material around both water and refrigerant piping, follow the installation manual.	

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WY

Model			PQHY-P600YLM-A			
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1	kW	69.0			
		kcal/h	60,000			
		BTU/h	235,400			
	Power input	kW	14.49			
		Current input	A	24.4-23.2-22.3		
		EER	kW/kW	4.76		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Heating capacity (Nominal)	*2	kW	76.5			
		kcal/h	65,800			
		BTU/h	261,000			
	Power input	kW	14.51			
		Current input	A	24.4-23.2-22.4		
		COP	kW/kW	5.27		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity				
	Model/Quantity	P15~P250/2~50				
Sound pressure level (measured in anechoic room)		dB <A>	56.5			
Sound power level (measured in anechoic room)		dB <A>	73			
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed			
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed			
Circulating water	Water flow rate	m ³ /h	11.52			
		L/min	192			
		cfm	6.8			
	Pressure drop	kPa	45			
	Operating volume range	m ³ /h	6.0 ~ 14.4			
Compressor	Type	Inverter scroll hermetic compressor				
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION				
	Starting method	Inverter				
	Motor output	kW	16.1			
	Case heater	kW	0.045 (240 V)			
	Lubricant	MEL32				
External finish		Galvanized steel sheets				
External dimension H x W x D		mm	1,450 x 880 x 550			
		in.	57-1/8 x 34-11/16 x 21-11/16			
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)				
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection				
	Compressor	Over-heat protection				
Refrigerant	Type x original charge	R410A x 11.7 kg (26 lbs)				
	Control	LEV and HIC circuit				
Net weight		kg (lbs)	246 (543)			
Heat exchanger		plate type				
		Water volume in plate	l	10.0		
		Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)		Copper pipe, tube-in-tube structure				
Drawing	External	WKS94C748				
	Wiring	WKE94G131				
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts		Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G				
Remarks		<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WV

Model			PQHY-P400YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	45.0		
		kcal/h	40,000		
		BTU/h	153,500		
	*1	Power input	kW	7.70	
		Current input	A	12.9-12.3-11.9	
EER		kW/kW	5.84		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	50.0		
		kcal/h	45,000		
		BTU/h	170,600		
	*2	Power input	kW	7.94	
		Current input	A	13.4-12.7-12.2	
COP		kW/kW	6.29		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity			
	Model/Quantity	P15~P250/1~34			
Sound pressure level (measured in anechoic room)		dB <A>	49		
Sound power level (measured in anechoic room)		dB <A>	63		
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed		
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed		
Set Model					

Model			PQHY-P200YLM-A		PQHY-P200YLM-A		
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76				
		L/min	96 + 96				
		cfm	3.4 + 3.4				
	Pressure drop	kPa	24		24		
Operating volume range		m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2				
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor		
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method		Inverter		Inverter		
	Motor output	kW	4.8		4.8		
	Case heater	kW	-		-		
	Lubricant		MEL32		MEL32		
External finish			Galvanized steel sheets		Galvanized steel sheets		
External dimension H x W x D		mm	1,100 x 880 x 550		1,100 x 880 x 550		
		in.	43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection		
	Compressor		Over-heat protection		Over-heat protection		
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)		
	Control		LEV and HIC circuit				
Net weight		kg (lbs)	174 (384)		174 (384)		
Heat exchanger			plate type		plate type		
			Water volume in plate	l	5.0		5.0
		Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure		
Pipe between unit and distributor	Liquid pipe	mm (in.)	9.52 (3/8) Brazed		9.52 (3/8) Brazed		
	Gas pipe	mm (in.)	19.05 (3/4) Brazed		19.05 (3/4) Brazed		
Drawing	External		WKS94C751				
	Wiring		WKE94G131		WKE94G131		
Standard attachment	Document		Installation Manual				
	Accessory		Refrigerant conn. pipe				
Optional parts			Heat Source Twinning kit: CMY-Y100VBK3 Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G				
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WY

Model			PQHY-P450YSLM-A	
Power source	3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1	kW	50.0	
		kcal/h	45,000	
	*1	BTU/h	170,600	
		Power input	kW	8.78
	Current input	A	14.8-14.0-13.5	
EER	kW/kW	5.69		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	56.0	
		kcal/h	50,000	
	*2	BTU/h	191,100	
		Power input	kW	8.97
	Current input	A	15.1-14.3-13.8	
COP	kW/kW	6.24		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity		
	Model/Quantity	P15~P250/1~39		
Sound pressure level (measured in anechoic room)	dB <A>	50		
Sound power level (measured in anechoic room)	dB <A>	64		
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed	

Set Model			PQHY-P250YLM-A		PQHY-P200YLM-A	
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76			
		L/min	96 + 96			
		cfm	3.4 + 3.4			
	Pressure drop	kPa	24		24	
Operating volume range	m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2				
Compressor	Type	Inverter scroll hermetic compressor		Inverter scroll hermetic compressor		
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method	Inverter		Inverter		
	Motor output	kW	6.2		4.8	
	Case heater	kW	-		-	
	Lubricant	MEL32		MEL32		
External finish	Galvanized steel sheets		Galvanized steel sheets			
External dimension H x W x D	mm	1,100 x 880 x 550		1,100 x 880 x 550		
		in. 43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection		Over-heat protection, Over-current protection		
	Compressor	Over-heat protection		Over-heat protection		
Refrigerant	Type x original charge	R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)		
	Control	LEV and HIC circuit				
Net weight	kg (lbs)	174 (384)		174 (384)		
Heat exchanger	plate type		plate type			
	Water volume in plate	l	5.0			
	Water pressure Max.	MPa	2.0			
HIC circuit (HIC: Heat Inter-Changer)	Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure			
Pipe between unit and distributor	Liquid pipe	mm (in.)	9.52 (3/8) Brazed			
	Gas pipe	mm (in.)	22.2 (7/8) Brazed			
Drawing	External	WKS94C751				
	Wiring	WKE94G131		WKE94G131		
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts	Heat Source Twinning kit: CMY-Y100VBK3 Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G					
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>					

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31 lbs =kg/0.4536
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WV

Model			PQHY-P500YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	56.0		
		kcal/h	50,000		
		BTU/h	191,100		
	*1	Power input	kW	10.12	
		Current input	A	17.0-16.2-15.6	
EER		kW/kW	5.53		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	63.0		
		kcal/h	55,000		
		BTU/h	215,000		
	*2	Power input	kW	10.16	
		Current input	A	17.1-16.2-15.7	
COP		kW/kW	6.20		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity			
	Model/Quantity	P15~P250/1~43			
Sound pressure level (measured in anechoic room)		dB <A>	51		
Sound power level (measured in anechoic room)		dB <A>	65		
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed		
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed		

Model			PQHY-P250YLM-A		PQHY-P250YLM-A	
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76			
		L/min	96 + 96			
		cfm	3.4 + 3.4			
	Pressure drop	kPa	24		24	
Operating volume range		m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2			
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter		Inverter	
	Motor output	kW	6.2		6.2	
	Case heater	kW	-		-	
	Lubricant		MEL32		MEL32	
External finish			Galvanized steel sheets		Galvanized steel sheets	
External dimension H x W x D		mm	1,100 x 880 x 550		1,100 x 880 x 550	
		in.	43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)	
	Control		LEV and HIC circuit			
Net weight		kg (lbs)	174 (384)		174 (384)	
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure	
Pipe between unit and distributor	Liquid pipe	mm (in.)	9.52 (3/8) Brazed		9.52 (3/8) Brazed	
	Gas pipe	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed	
Drawing	External		WKS94C751			
	Wiring		WKE94G131		WKE94G131	
Standard attachment	Document		Installation Manual			
	Accessory		Refrigerant conn. pipe			
Optional parts			Heat Source Twinning kit: CMY-Y100VBK3 Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G			
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WY

Model			PQHY-P550YSLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	63.0	
		kcal/h	55,000	
		BTU/h	215,000	
	Power input	kW	11.55	
		Current input	A	19.4-18.5-17.8
EER	kW/kW		5.45	
	Indoor	W.B.	15.0~24.0°C (59~75°F)	
Temp. range of cooling	Circulating water		°C	
			10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	69.0	
		kcal/h	60,000	
		BTU/h	235,400	
	Power input	kW	11.31	
		Current input	A	19.0-18.1-17.4
COP	kW/kW		6.10	
	Indoor	D.B.	15.0~27.0°C (59~81°F)	
Temp. range of heating	Circulating water		°C	
			10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity	
	Model/Quantity		P15~P250/2~47	
Sound pressure level (measured in anechoic room)	dB <A>		55	
Sound power level (measured in anechoic room)	dB <A>		69	
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed	

Set Model

Model			PQHY-P300YLM-A		PQHY-P250YLM-A	
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76			
		L/min	96 + 96			
		cfm	3.4 + 3.4			
	Pressure drop	kPa	24		24	
Operating volume range		m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2			
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter		Inverter	
	Motor output	kW	7.7		6.2	
	Case heater	kW	-		-	
	Lubricant		MEL32		MEL32	
External finish			Galvanized steel sheets		Galvanized steel sheets	
External dimension H x W x D	mm		1,100 x 880 x 550		1,100 x 880 x 550	
	in.		43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)	
	Control		LEV and HIC circuit			
Net weight	kg (lbs)		174 (384)		174 (384)	
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure	
Pipe between unit and distributor	Liquid pipe	mm (in.)	12.7 (1/2) Brazed		12.7 (1/2) Brazed	
	Gas pipe	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed	
Drawing	External		WKS94C751			
	Wiring		WKE94G131		WKE94G131	
Standard attachment	Document		Installation Manual			
	Accessory		Refrigerant conn. pipe			
Optional parts			Heat Source Twinning kit: CMY-Y100VBK3 Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G			
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:

- Nominal cooling conditions (subject to JIS B8615-2)
Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F)
Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)
- Nominal heating conditions (subject to JIS B8615-2)
Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.)
Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)

Unit converter

BTU/h =kW x 3.412
cfm =m³/min x 35.31
lbs =kg/0.4536

*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WV

Model			PQHY-P600YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	69.0		
		kcal/h	60,000		
		BTU/h	235,400		
	*1	Power input	kW	12.84	
		Current input	A	21.6-20.5-19.8	
EER		kW/kW	5.37		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	76.5		
		kcal/h	65,800		
		BTU/h	261,000		
	*2	Power input	kW	12.75	
		Current input	A	21.5-20.4-19.7	
COP		kW/kW	6.00		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity			
	Model/Quantity	P15~P250/2~50			
Sound pressure level (measured in anechoic room)		dB <A>	57		
Sound power level (measured in anechoic room)		dB <A>	71		
Refrigerant piping diameter	Liquid pipe	mm (in.)	15.88 (5/8) Brazed		
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed		
Set Model					

Model			PQHY-P300YLM-A		PQHY-P300YLM-A	
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76			
		L/min	96 + 96			
		cfm	3.4 + 3.4			
	Pressure drop	kPa	24		24	
Operating volume range		m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2			
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter		Inverter	
	Motor output	kW	7.7		7.7	
	Case heater	kW	-		-	
	Lubricant		MEL32		MEL32	
External finish			Galvanized steel sheets		Galvanized steel sheets	
External dimension H x W x D		mm	1,100 x 880 x 550		1,100 x 880 x 550	
		in.	43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)	
	Control		LEV and HIC circuit			
Net weight		kg (lbs)	174 (384)		174 (384)	
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure	
Pipe between unit and distributor	Liquid pipe	mm (in.)	12.7 (1/2) Brazed		12.7 (1/2) Brazed	
	Gas pipe	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed	
Drawing	External		WKS94C751			
	Wiring		WKE94G131		WKE94G131	
Standard attachment	Document		Installation Manual			
	Accessory		Refrigerant conn. pipe			
Optional parts			Heat Source Twinning kit: CMY-Y100VBK3 Joint: CMY-Y102SS/LS-G2, CMY-Y202S-G2 Header: CMY-Y104, 108, 1010-G			
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WY

Model			PQHY-P700YSLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	80.0	
		kcal/h	68,800	
		BTU/h	273,000	
	Power input	kW	14.73	
		A	24.8-23.6-22.7	
EER		5.43		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	88.0	
		kcal/h	75,700	
		BTU/h	300,300	
	Power input	kW	14.73	
		A	24.8-23.6-22.7	
COP		5.97		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity		
	Model/Quantity	P15~P250/2~50		
Sound pressure level (measured in anechoic room)		dB <A>	55	
Sound power level (measured in anechoic room)		dB <A>	69	
Refrigerant piping diameter	Liquid pipe	mm (in.)	19.05 (3/4) Brazed	
	Gas pipe	mm (in.)	34.93 (1-3/8) Brazed	

Set Model			PQHY-P350YLM-A		PQHY-P350YLM-A	
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20			
		L/min	120 + 120			
		cfm	4.2 + 4.2			
	Pressure drop	kPa	44			44
Operating volume range	m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6				
Compressor	Type	Inverter scroll hermetic compressor		Inverter scroll hermetic compressor		
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method	Inverter		Inverter		
	Motor output	kW	9.5	9.5		
	Case heater	kW	-	-		
Lubricant	MEL32		MEL32			
External finish	Galvanized steel sheets		Galvanized steel sheets			
External dimension H x W x D	mm	1,450 x 880 x 550		1,450 x 880 x 550		
		57-1/8 x 34-11/16 x 21-11/16		57-1/8 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection		Over-heat protection, Over-current protection		
	Compressor	Over-heat protection		Over-heat protection		
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)		R410A x 6.0 kg (14 lbs)		
	Control	LEV and HIC circuit				
Net weight	kg (lbs)	217 (479)		217 (479)		
Heat exchanger	plate type		plate type			
	Water volume in plate	l	5.0			
	Water pressure Max.	MPa	2.0			
HIC circuit (HIC: Heat Inter-Change)	Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure			
Pipe between unit and distributor	Liquid pipe	mm (in.)	12.7 (1/2) Brazed			
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed			
Drawing	External	WKS94C752				
	Wiring	WKE94G131		WKE94G131		
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts	Heat Source Twinning kit: CMY-Y200VBK2 Joint: CMY-Y102SS/LS-G2, CMY-Y202, 302S-G2 Header: CMY-Y104, 108, 1010-G					
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>					

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

Model			PQHY-P750YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	85.0		
		kcal/h	73,100		
		BTU/h	290,000		
	*1	Power input	kW	15.64	
		Current input	A	26.4-25.0-24.1	
EER		kW/kW	5.43		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	95.0		
		kcal/h	81,700		
		BTU/h	324,100		
	*2	Power input	kW	15.90	
		Current input	A	26.8-25.4-24.5	
COP		kW/kW	5.97		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity	50~130% of heat source unit capacity			
	Model/Quantity	P15~P250/2~50			
Sound pressure level (measured in anechoic room)	dB <A>	55			
Sound power level (measured in anechoic room)	dB <A>	69			
Refrigerant piping diameter	Liquid pipe	mm (in.)	19.05 (3/4) Brazed		
	Gas pipe	mm (in.)	34.93 (1-3/8) Brazed		
Set Model					

Model			PQHY-P400YLM-A		PQHY-P350YLM-A	
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20			
		L/min	120 + 120			
		cfm	4.2 + 4.2			
	Pressure drop	kPa	44		44	
Operating volume range		m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6			
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter		Inverter	
	Motor output	kW	10.7		9.5	
	Case heater	kW	-		-	
	Lubricant		MEL32		MEL32	
External finish			Galvanized steel sheets		Galvanized steel sheets	
External dimension H x W x D		mm	1,450 x 880 x 550		1,450 x 880 x 550	
		in.	57-1/8 x 34-11/16 x 21-11/16		57-1/8 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)		R410A x 6.0 kg (14 lbs)	
	Control		LEV and HIC circuit			
Net weight		kg (lbs)	217 (479)		217 (479)	
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)			Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure	
Pipe between unit and distributor	Liquid pipe	mm (in.)	15.88 (5/8) Brazed		15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed		28.58 (1-1/8) Brazed	
Drawing	External		WKS94C752			
	Wiring		WKE94G131		WKE94G131	
Standard attachment	Document		Installation Manual			
	Accessory		Refrigerant conn. pipe			
Optional parts			Heat Source Twinning kit: CMY-Y200VBK2 Joint: CMY-Y102SS/LS-G2, CMY-Y202, 302S-G2 Header: CMY-Y104, 108, 1010-G			
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WY

Model			PQHY-P800YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	90.0		
		kcal/h	77,400		
		BTU/h	307,100		
	Power input	kW	16.57		
		Current input	A	27.9-26.5-25.6	
EER		kW/kW	5.43		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	100.0		
		kcal/h	86,000		
		BTU/h	341,200		
	Power input	kW	16.75		
		Current input	A	28.2-26.8-25.8	
COP		kW/kW	5.97		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity		
	Model/Quantity		P15~P250/2~50		
Sound pressure level (measured in anechoic room)		dB <A>	55		
Sound power level (measured in anechoic room)		dB <A>	69		
Refrigerant piping diameter	Liquid pipe	mm (in.)	19.05 (3/4) Brazed		
	Gas pipe	mm (in.)	34.93 (1-3/8) Brazed		

Set Model						
Model			PQHY-P400YLM-A		PQHY-P400YLM-A	
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20			
		L/min	120 + 120			
		cfm	4.2 + 4.2			
	Pressure drop	kPa	44		44	
Operating volume range		m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6			
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter		Inverter	
	Motor output	kW	10.7		10.7	
	Case heater	kW	-		-	
Lubricant		MEL32		MEL32		
External finish			Galvanized steel sheets		Galvanized steel sheets	
External dimension H x W x D	mm		1,450 x 880 x 550		1,450 x 880 x 550	
	in.		57-1/8 x 34-11/16 x 21-11/16		57-1/8 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)		R410A x 6.0 kg (14 lbs)	
	Control		LEV and HIC circuit			
Net weight		kg (lbs)	217 (479)		217 (479)	
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Change)			Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure	
Pipe between unit and distributor	Liquid pipe	mm (in.)	15.88 (5/8) Brazed		15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed		28.58 (1-1/8) Brazed	
Drawing	External		WKS94C752			
	Wiring		WKE94G131		WKE94G131	
Standard attachment	Document		Installation Manual			
	Accessory		Refrigerant conn. pipe			
Optional parts			Heat Source Twinning kit: CMY-Y200VBK2 Joint: CMY-Y102SS/LS-G2, CMY-Y202, 302S-G2 Header: CMY-Y104, 108, 1010-G			
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:		Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		cfm =m ³ /min x 35.31
		lbs =kg/0.4536
		*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WV

Model			PQHY-P850YSLM-A
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz
Cooling capacity (Nominal)	*1	kW	96.0
		kcal/h	82,600
		BTU/h	327,600
	Power input	kW	18.03
		A	30.4-28.9-27.8
EER	kW/kW	5.32	
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Heating capacity (Nominal)	*2	kW	108.0
		kcal/h	92,900
		BTU/h	368,500
	Power input	kW	18.49
		A	31.2-29.6-28.5
COP	kW/kW	5.84	
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity
	Model/Quantity		P15~P250/2~50
Sound pressure level (measured in anechoic room)	dB <A>		56
Sound power level (measured in anechoic room)	dB <A>		71.5
Refrigerant piping diameter	Liquid pipe	mm (in.)	19.05 (3/4) Brazed
	Gas pipe	mm (in.)	41.28 (1-5/8) Brazed

Model			PQHY-P450YLM-A	PQHY-P400YLM-A
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20	
		L/min	120 + 120	
		cfm	4.2 + 4.2	
	Pressure drop	kPa	44	44
Operating volume range	m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6		
Compressor	Type	Inverter scroll hermetic compressor		
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method	Inverter		
	Motor output	kW	11.6	10.7
	Case heater	kW	-	-
	Lubricant	MEL32		
External finish	Galvanized steel sheets			
External dimension H x W x D	mm	1,450 x 880 x 550	1,450 x 880 x 550	
	in.	57-1/8 x 34-11/16 x 21-11/16	57-1/8 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection	Over-heat protection, Over-current protection	
	Compressor	Over-heat protection	Over-heat protection	
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)	R410A x 6.0 kg (14 lbs)	
	Control	LEV and HIC circuit		
Net weight	kg (lbs)	217 (479)	217 (479)	
Heat exchanger	plate type			
	Water volume in plate	l	5.0	
	Water pressure Max.	MPa	2.0	
HIC circuit (HIC: Heat Inter-Changer)	Copper pipe, tube-in-tube structure			
Pipe between unit and distributor	Liquid pipe	mm (in.)	15.88 (5/8) Brazed	
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed	
Drawing	External	WKS94C752		
	Wiring	WKE94G131	WKE94G131	
Standard attachment	Document	Installation Manual		
	Accessory	Refrigerant conn. pipe		
Optional parts	Heat Source Twinning kit: CMY-Y200VBK2 Joint: CMY-Y102SS/LS-G2, CMY-Y202, 302S-G2 Header: CMY-Y104, 108, 1010-G			
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WY

Model			PQHY-P900YSLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	101.0	
		kcal/h	86,900	
		BTU/h	344,600	
	Power input	kW	19.38	
		Current input	A	32.7-31.0-29.9
EER		kW/kW	5.21	
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	113.0	
		kcal/h	97,200	
		BTU/h	385,600	
	Power input	kW	19.74	
		Current input	A	33.3-31.6-30.5
COP		kW/kW	5.72	
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~130% of heat source unit capacity	
	Model/Quantity		P15~P250/2~50	
Sound pressure level (measured in anechoic room)		dB <A>	57	
Sound power level (measured in anechoic room)		dB <A>	73	
Refrigerant piping diameter	Liquid pipe	mm (in.)	19.05 (3/4) Brazed	
	Gas pipe	mm (in.)	41.28 (1-5/8) Brazed	


Set Model					
Model			PQHY-P450YLM-A	PQHY-P450YLM-A	
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20		
		L/min	120 + 120		
		cfm	4.2 + 4.2		
	Pressure drop	kPa	44	44	
Operating volume range	m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6			
Compressor	Type	Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method	Inverter		Inverter	
	Motor output	kW	11.6	11.6	
	Case heater	kW	-	-	
Lubricant	MEL32		MEL32		
External finish	Galvanized steel sheets		Galvanized steel sheets		
External dimension H x W x D	mm	1,450 x 880 x 550		1,450 x 880 x 550	
		in.	57-1/8 x 34-11/16 x 21-11/16		57-1/8 x 34-11/16 x 21-11/16
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor	Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)		R410A x 6.0 kg (14 lbs)	
	Control	LEV and HIC circuit			
Net weight	kg (lbs)	217 (479)		217 (479)	
Heat exchanger	plate type		plate type		
	Water volume in plate	l	5.0		
	Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Change)	Copper pipe, tube-in-tube structure		Copper pipe, tube-in-tube structure		
Pipe between unit and distributor	Liquid pipe	mm (in.)	15.88 (5/8) Brazed		
	Gas pipe	mm (in.)	28.58 (1-1/8) Brazed		
Drawing	External	WKS94C752			
	Wiring	WKE94G131		WKE94G131	
Standard attachment	Document	Installation Manual			
	Accessory	Refrigerant conn. pipe			
Optional parts	Heat Source Twinning kit: CMY-Y200VBK2 Joint: CMY-Y102SS/LS-G2, CMY-Y202, 302S-G2 Header: CMY-Y104, 108, 1010-G				
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

PQHY-P200, 250, 300YLM-A

Unit: mm

- <Accessories>
- Refrigerant (Liquid) conn. pipe 1pc. (P200/P250/P300 ; Packaged in the accessory kit)
 - Refrigerant (Gas) conn. elbow 1pc. (P200/P250/P300 ; Packaged in the accessory kit)
 - Water stopper(Liquid,Gas) 1pc. each (P200/P250/P300 ; Packaged in the accessory kit)
 - Sealing material for water stopper (Liquid,Gas) 1pc. each (P200/P250/P300 ; Packaged in the accessory kit)
 - Sealing material for field piping (Liquid,Gas) 1pc. each (P200/P250/P300 ; Packaged in the accessory kit)
 - Sealing material for drain socket 1pc. (P200/P250/P300 ; Packaged in the accessory kit)
 - Pipe cover for gas 1pc. (P200/P250/P300 ; Packaged in the accessory kit)



No.	Usage	Specifications
①	For pipes	140 x 77 Knockout hole
②	For wires	ø65 or ø40 Knockout hole
③	For transmission cables	ø52 or ø27 Knockout hole
④	For transmission cables	ø34 Knockout hole
⑤	Water pipe inlet	Rc1-1/2 Screw
⑥	Water pipe outlet	Rc1-1/2 Screw
⑦	Drain pipe	Rc3/4 Screw

- Note1. Close a hole of the water piping, the refrigerant piping, the power supply, and the control wiring and unused knockout holes with the putty etc. so as not to infiltrate rain water etc. (field erection work)
- Note2. At the time of product shipment, the front side piping specification serves as the local drainage connection. When connecting on the rear side, please remove the rear side plug sealing corks, and attach a front side. Ensure there is no leak after the attachment has been fitted.
- Note3. Take notice of service space as Fig.A. (In case of single installation, 60mm or more of back space as front space makes easier access when servicing the unit from rear side.)
- Note4. If water pipes or refrigerant pipes stretch upward, required space for service and maintenance due to replacement of control box is shown in Fig.B.
- Note5. Environmental condition for installation: -20~40°C(DB) as indoor installation.
- Note6. In case the temperature around the heat source unit has possibility to drop under 0°C, be careful for the following point to prevent the pipe burst by the water pipe freeze-up.
- Circulate the water all the time even if the heat source unit is not in operation.
 - Drain the water from inside of the heat source unit when the heat source unit will not operate for a long term.
- Note7. Ensure that the drain piping is downward with a pitch of more than 1/100.
- Note8. At brazing of pipes, wrap the refrigerant service valve with wet cloth and keep the temperature of refrigerant service valve under 120°C.




Fig.A

Model	Diameter		Service valve
	Refrigerant pipe	Service valve	
PQHY-P200YLM-A	Liquid	Gas	Liquid
	ø9.52 Braze ^{*1}	ø19.05 Braze ^{*1,4}	Gas
PQHY-P250YLM-A	ø9.52 Braze ^{*1}	ø12.7 Braze ^{*1}	ø9.52
	ø12.7 Braze ^{*2,4}	ø22.2 Braze ^{*1,4}	
PQHY-P300YLM-A	ø9.52 Braze ^{*1}	ø12.7 Braze ^{*1}	ø25.4
	ø12.7 Braze ^{*3,4}		

Fig.B


- *1 Connect by using the connecting pipes and elbow that are supplied.
- *2 Total length ≥ 90m
- *3 Total length ≥ 40m
- *4 Use the pipe joint(field supply) and connect to the refrigerant service valve piping.

PQHY-P350, 400, 450, 500YLM-A

Unit: mm


WY

- <Accessories>
- Refrigerant (Liquid) conn. pipe.....1pc (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Refrigerant (Gas) conn. elbow.....1pc (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Water stopper(Liquid,Gas).....1pc, each (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for water stopper (Liquid,Gas).....1pc, each (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for field piping (Liquid,Gas).....1pc, each (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for drain socket.....1pc (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Pipe cover for gas.....1pc (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for base leg (two types).....4pcs each (P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for panel.....1pc (P350/P400/P450/P500 ; Packaged in the accessory kit)



NO.	Usage	Specifications
①	For pipes	Front through hole 140 x 77 Knockout hole
②	For wires	Front through hole ø65 or ø40 Knockout hole
③	For transmission cables	Front through hole ø52 or ø27 Knockout hole
④	Water pipe inlet	ø34 Knockout hole
⑤	Water pipe outlet	Rc1-1/2 Screw
⑦	Drain pipe	Rc1-1/2 Screw Rc3/4 Screw

- Note1. Close a hole of the water piping, the refrigerant piping, the power supply, and the control wiring and unused knockout holes with the putty etc. so as not to infiltrate rain water etc.(field erection work)
- Note2. At the time of product shipment, the front side piping specification serves as the local drainage connection. When connecting on the rear side, please remove the rear side plug sealing corks, and attach a front side. Ensure there is no leak after the attachment has been fitted.
- Note3. Take notice of service space as Fig.A. (In case of single installation, 600mm or more of back space as front space makes easier access when servicing the unit from rear side.)
- Note4. If water pipes or refrigerant pipes stretch upward, required space for service and maintenance due to replacement of control box is shown in Fig.B.
- Note5. Environmental condition for installation; -20~40°C(DB) as indoor installation.
- Note6. In case the temperature around the heat source unit has possibility to drop under 0°C, be careful for the following point to prevent the pipe burst by the water pipe freeze-up.
- Circulate the water all the time even if the heat source unit is not in operation.
 - Drain the water from inside of the heat source unit when the heat source unit will not operate for a long term.
- Note7. Ensure that the drain piping is downward with a pitch of more than 1/100.
- Note8. At brazing of pipes, wrap the refrigerant service valve with wet cloth and keep the temperature of refrigerant service valve under 120°C.



Connecting pipe specifications


Model	Refrigerant pipe		Service valve		Diameter
	Liquid	Gas	Liquid	Gas	
PQHY-P350YLM-A	ø12.7 Brazed *1 *2		ø15.88		ø28.58
PQHY-P400YLM-A		ø28.58 Brazed *1			
PQHY-P450YLM-A	ø15.88 Brazed *1				
PQHY-P500YLM-A					

*1. Connect by using the connecting pipes and elbow that are supplied.
 *2. Use the pipe joint(field supply) and connect to the refrigerant service valve piping.


PQHY-P550, 600YLM-A

Unit: mm


- <Accessories>
- Refrigerant (Liquid) conn. pipe 1pc. (P550/P600 ; Packaged in the accessory kit)
 - Refrigerant (Gas) conn. elbow 1pc. (P550/P600 ; Packaged in the accessory kit)
 - Water stopper(Liquid,Gas) 1pc. each (P550/P600 ; Packaged in the accessory kit)
 - Sealing material for water stopper (Liquid,Gas) 1pc. each (P550/P600 ; Packaged in the accessory kit)
 - Sealing material for field piping (Liquid,Gas) 1pc. each (P550/P600 ; Packaged in the accessory kit)
 - Sealing material for drain socket 1pc. (P550/P600 ; Packaged in the accessory kit)
 - Pipe cover for gas 1pc. (P550/P600 ; Packaged in the accessory kit)
 - Sealing material for base leg (two types) 4pcs. each (P550/P600 ; Packaged in the accessory kit)
 - Sealing material for panel 1pc. (P550/P600 ; Packaged in the accessory kit)




Top view




Front view



Bottom view




Right side view



Back view

NO.	Usage	Specifications
①	Front through hole	140 x 77 Knockout hole
②	Front through hole	ø65 or ø40 Knockout hole
③	Front through hole	ø52 or ø27 Knockout hole
④	For transmission cables	ø34 Knockout hole
⑤	Water pipe inlet	Rc1-1/2 Screw
⑥	Water pipe outlet	Rc1-1/2 Screw
⑦	Drain pipe	Rc3/4 Screw

- Note1. Close a hole of the water piping, the refrigerant piping, the power supply, and the control wiring and unused knockout holes with the putty etc. so as not to infiltrate rain water etc.(field erection work)
- Note2. At the time of product shipment, the front side piping specification serves as the local drainage connection. When connecting on the rear side, please remove the rear side plug sealing corks, and attach a front side. Ensure there is no leak after the attachment has been fitted.
- Note3. Take notice of service space as Fig.A. (in case of single installation, 600mm or more of back space as front space makes easier access when servicing the unit from rear side.)
- Note4. If water pipes or refrigerant pipes stretch upward, required space for service and maintenance due to replacement of control box is shown in Fig.B.
- Note5. Environmental condition for installation; -20~40°C(DB) as indoor installation.
- Note6. In case the temperature around the heat source unit has possibility to drop under 0°C, be careful for the following point to prevent the pipe burst by the water pipe freeze-up.
- Circulate the water all the time even if the heat source unit is not in operation.
 - Drain the water from inside of the heat source unit when the heat source unit will not operate for a long term.
- Note7. Ensure that the drain piping is downward with a pitch of more than 1/100.
- Note8. At brazing of pipes, wrap the refrigerant service valve with wet cloth and keep the temperature of refrigerant service valve under 120°C.



Connecting pipe specifications


Model	Refrigerant pipe		Service valve		Diameter
	Liquid	Gas	Liquid	Gas	
PQHY-P550YLM-A	ø15.88 Brazed	ø28.58 Brazed	ø15.88	ø28.58	L ₁
PQHY-P600YLM-A					

*1. Connect by using the connecting pipes and elbow that are supplied.

WY

PQHY-P400,450,500,550,600YSLM-A


Unit: mm



- Note 1. Connect the pipes as shown in the figure above. Refer to the table below for the pipe size.
 2. Twinning pipe should not be tilted more than 15 degrees from the horizontal plane.
 3. See the Installation Manual for the details of Twinning pipe installation.
 4. The pipe section before the Twinning pipe (sections "a" and "b" in the figure) must have at least 500mm of straight section (*including the straight pipe that is supplied with the Twinning pipe).
 5. Only use the Twinning pipe by Mitsubishi (optional parts).

Twinning pipe connection size


Package unit name	PQHY-P400YSLM-A	PQHY-P450YSLM-A	PQHY-P500YSLM-A	PQHY-P550YSLM-A	PQHY-P600YSLM-A
Heat Source unit 1	PQHY-P200YLM-A	PQHY-P250YLM-A	PQHY-P250YLM-A	PQHY-P300YLM-A	PQHY-P300YLM-A
Heat Source unit 2	PQHY-P200YLM-A	PQHY-P200YLM-A	PQHY-P250YLM-A	PQHY-P250YLM-A	PQHY-P300YLM-A
Twinning pipe Kit(optional parts)	CMY-Y100VBK3				
Indoor unit-Twinning pipe	Liquid	ø15.88			
	Gas	ø28.58			
Twinning pipe-Heat Source unit 1	Liquid	ø9.52		ø12.7	
	Gas	ø19.05		ø22.2	
Twinning pipe-Heat Source unit 2	Liquid	ø9.52		ø12.7	
	Gas	ø19.05		ø22.2	



WY

PQHY-P200/250/300YLM-A

Unit: mm [in.]




Model	X	Y	Z
PQHY-P200YLM-A	353[13-15/16]	233[9-3/16]	448[17-11/16]
PQHY-P250YLM-A	353[13-15/16]	233[9-3/16]	448[17-11/16]
PQHY-P300YLM-A	353[13-15/16]	233[9-3/16]	448[17-11/16]

*1 Mounting Pitch

PQHY-P350/400/450/500/550/600YLM-A


Unit: mm [in.]



Model	X	Y	Z
PQHY-P350YLM-A	382[15-1/16]	233[9-3/16]	632[24-15/16]
PQHY-P400YLM-A	382[15-1/16]	233[9-3/16]	632[24-15/16]
PQHY-P450YLM-A	382[15-1/16]	233[9-3/16]	632[24-15/16]
PQHY-P500YLM-A	382[15-1/16]	233[9-3/16]	632[24-15/16]
PQHY-P550YLM-A	365[14-3/8]	224[8-7/8]	650[25-5/8]
PQHY-P600YLM-A	365[14-3/8]	224[8-7/8]	650[25-5/8]

*1 Mounting Pitch

PQHY-P200, 250, 300, 350, 400, 450, 500, 550, 600YLM-A



- *1. Single-dotted lines indicate wiring not supplied with the unit.
- *2. Dot-dash lines indicate the control box boundaries.
- *3. Refer to the Data book for connecting input/output signal connectors.
- *4. Daisy-chain terminals (TB3) on the heat source units in the same refrigerant system together.
- *5. Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion. Press the tab on the terminals to removed them.
- *6. Control box houses high-voltage parts. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.
- *7. Refer to the Data book for wiring terminal block for Pump interlock, Operation ON signal, DC0-10V signal output and Power input(24V).
- *8. Difference of appliance.

Model name	Appliance
P200/250/300	*8 do not exist
P350/400/450/500/550/600	*8 exist

Model name	Appliance
PQHY	*9 do not exist
PQRY	*9 exist

Model name	Appliance
PQHY	*10 exist
PQRY	*10 do not exist


<Symbol explanation>

Symbol	Explanation
Z/S4a	4-way valve (Cooling/Heating switching)
Z/S4b	Heat exchanger capacity control
GSHT	Pressure switch (High pressure protection for the heat source unit)
63LS1	Pressure sensor (High pressure)
63LS2	Pressure sensor (Low pressure)
Z2C	Magnetic relay (inverter main circuit)
C30-C37	Capacitor (inverter main circuit)
CH11	Crankcase heater (for heating the compressor)
C12/Z2.3	Current sensor (AC)
L	Choke reactor (for high frequency noise reduction)
LEV1	Linear expansion valve (in HIC circuit)
LEV6	Heat exchanger capacity control valve
LEV7	Heat exchanger capacity control valve
LEV/INV	Heat exchanger for inverter
FAN	Fan motor (Start)
R1.5	Resistor (For inrush current prevention)
RSH1	For opening/closing the bypass circuit under the OS
SV1a	Solenoid valve (For opening/closing the bypass circuit under the OS)
SV4a,b,d	Heat exchanger capacity control valve
SV7a,b,c	Heat exchanger capacity control valve
SV9	For opening/closing the bypass circuit
TB1	Terminal block
TB3	indoor/Heat source transmission cable
TB7	Central control transmission cable
TB8	Operation ON signal, Power interlock
TB9	Power input and signal output for variable water flow valve
TH2	Thermistor (Subcool bypass outlet temperature)
TH3	Pipe temperature
TH4	Discharge pipe temperature
TH5	ACC inlet pipe temperature
TH6	Subcooled liquid refrigerant temperature
TH7	Water inlet temperature
TH8	Water outlet temperature
TH9	Outlet temp. detect of heat exchanger for inverter
THS	IPM temperature
Z24,Z5	Function setting connector


*11. Difference of appliance.

Model name	Appliance
P200/250/300/350/400/450/500	*11 do not exist
P550/600	*11 exist

Measurement condition
PQHY-P200, 250, 300YLM-A




Sound level of PQHY-P300YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	51.0	63.0	56.5	47.0	45.5	42.5	44.0	35.5	54.0
Low noise mode	50/60Hz	63.0	47.0	43.0	44.0	42.0	37.5	34.0	27.0	47.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P200YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	66.5	45.5	44.5	42.0	39.5	34.5	32.0	25.5	46.0
Low noise mode	50/60Hz	41.5	42.0	38.5	43.0	40.0	33.0	30.5	22.0	44.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

Sound level of PQHY-P250YLM-A




		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	56.5	46.0	50.0	44.0	42.5	37.5	37.0	27.5	48.0
Low noise mode	50/60Hz	66.5	45.5	44.5	42.0	39.5	34.5	32.0	25.5	46.0


When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

♦ Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required.

Measurement condition
PQHY-P350, 400, 450, 500, 550, 600YLM-A




Sound level of PQHY-P450YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	46.0	48.0	55.5	44.5	46.5	45.5	48.0	41.0	54.0
Low noise mode	50/60Hz	66.5	45.5	46.5	44.0	46.0	42.0	45.0	40.5	51.5

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P350YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	73.5	51.5	50.0	46.0	46.0	41.5	38.5	31.5	52.0
Low noise mode	50/60Hz	53.5	53.0	47.0	43.0	43.0	41.5	44.0	40.0	50.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P500YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	49.5	55.0	50.0	50.0	46.5	43.0	48.0	45.0	54.0
Low noise mode	50/60Hz	57.5	50.5	48.5	47.0	43.0	43.0	47.5	38.0	52.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P400YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	73.5	51.5	50.0	46.0	46.0	41.5	38.5	31.5	52.0
Low noise mode	50/60Hz	53.5	53.0	47.0	43.0	43.0	41.5	44.0	40.0	50.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P550YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	45.5	68.0	50.5	53.0	48.5	42.0	45.5	40.0	56.5
Low noise mode	50/60Hz	65.5	62.5	58.0	47.5	45.5	43.5	39.5	38.5	54.0


When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

◆ Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required.




♦ Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required.

Measurement condition
PQHY-P400, 450, 500, 550, 600YSLM-A




Sound level of PQHY-P500YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	59.5	49.0	53.0	47.0	45.5	40.5	40.0	30.5	51.0
Low noise mode	50/60Hz	69.5	48.5	47.5	45.0	42.5	37.5	35.0	28.5	49.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P400YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	69.5	48.5	47.5	45.0	42.5	37.5	35.0	28.5	49.0
Low noise mode	50/60Hz	44.5	45.0	41.5	46.0	43.0	36.0	33.5	25.0	47.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P550YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	57.5	63.0	57.5	49.0	47.5	43.5	45.0	36.0	55.0
Low noise mode	50/60Hz	68.0	49.5	47.0	46.0	44.0	39.5	36.0	29.5	49.5

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P450YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	67.0	49.0	51.0	46.0	44.5	39.5	38.0	29.5	50.0
Low noise mode	50/60Hz	66.5	47.0	45.5	45.5	43.0	37.0	34.5	27.0	48.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

Sound level of PQHY-P600YSLM-A




		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	54.0	66.0	59.5	50.0	48.5	45.5	47.0	38.5	57.0
Low noise mode	50/60Hz	66.0	50.0	46.0	47.0	45.0	40.5	37.0	30.0	50.0


When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

• Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required.

Measurement condition
PQHY-P700, 750, 800, 850, 900YSLM-A




Sound level of PQHY-P800YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	76.5	54.5	53.0	49.0	49.0	44.5	41.5	34.5	55.0
Low noise mode	50/60Hz	56.5	56.0	50.0	46.0	46.0	44.5	47.0	43.0	53.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P700YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	76.5	54.5	53.0	49.0	49.0	44.5	41.5	34.5	55.0
Low noise mode	50/60Hz	56.5	56.0	50.0	46.0	46.0	44.5	47.0	43.0	53.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P850YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	73.5	53.0	56.5	48.5	49.5	47.0	48.5	41.5	56.0
Low noise mode	50/60Hz	66.5	53.5	50.0	46.5	48.0	45.0	47.5	43.5	54.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQHY-P750YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	76.5	54.5	53.0	49.0	49.0	44.5	41.5	34.5	55.0
Low noise mode	50/60Hz	56.5	56.0	50.0	46.0	46.0	44.5	47.0	43.0	53.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

Sound level of PQHY-P900YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	49.0	51.0	58.5	47.5	49.5	48.5	51.0	44.0	57.0
Low noise mode	50/60Hz	69.5	48.5	49.5	47.0	49.0	45.0	48.0	43.5	54.5


When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

• Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required.


6. OPERATION TEMPERATURE RANGE

WM

• Cooling



• Heating







WY





7-1. Correction by temperature

CITY MULTI could have varied capacity at different designing temperature. Using the nominal cooling/heating capacity value and the ratio below, the capacity can be observed at various temperature.

		PQHY-P200YLM-A	PQRY-P200YLM-A
Nominal Cooling Capacity	kW	22.4	22.4
	BTU/h	76,400	76,400
Input	kW	3.71	3.71







		PQHY-P200YLM-A	PQRY-P200YLM-A
Nominal Heating Capacity	kW	25.0	25.0
	BTU/h	85,300	85,300
Input	kW	3.97	3.97







7. CAPACITY TABLES

WV

		PQHY-P250YLM-A	PQRY-P250YLM-A
Nominal Cooling Capacity	kW	28.0	28.0
	BTU/h	95,500	95,500
Input	kW	4.90	4.90







		PQHY-P250YLM-A	PQRY-P250YLM-A
Nominal Heating Capacity	kW	31.5	31.5
	BTU/h	107,500	107,500
Input	kW	5.08	5.08







7. CAPACITY TABLES

WY

		PQHY-P300YLM-A	PQRY-P300YLM-A
Nominal Cooling Capacity	kW	33.5	33.5
	BTU/h	114,300	114,300
Input	kW	6.04	6.04







		PQHY-P300YLM-A	PQRY-P300YLM-A
Nominal Heating Capacity	kW	37.5	37.5
	BTU/h	128,000	128,000
Input	kW	6.25	6.25







7. CAPACITY TABLES

WV

		PQHY-P350YLM-A	PQRY-P350YLM-A
Nominal Cooling Capacity	kW	40.0	40.0
	BTU/h	136,500	136,500
Input	kW	7.14	7.14







		PQHY-P350YLM-A	PQRY-P350YLM-A
Nominal Heating Capacity	kW	45.0	45.0
	BTU/h	153,500	153,500
Input	kW	7.53	7.53







7. CAPACITY TABLES

WY

		PQHY-P400YLM-A	PQRY-P400YLM-A
Nominal Cooling Capacity	kW	45.0	45.0
	BTU/h	153,500	153,500
Input	kW	8.03	8.03







		PQHY-P400YLM-A	PQRY-P400YLM-A
Nominal Heating Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	8.37	8.37







7. CAPACITY TABLES

WV

		PQHY-P450YLM-A	PQRY-P450YLM-A
Nominal Cooling Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	9.29	9.29



		PQHY-P450YLM-A	PQRY-P450YLM-A
Nominal Heating Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	9.79	9.79







7. CAPACITY TABLES





HEAT SOURCE

WY

		PQHY-P500YLM-A	PQRY-P500YLM-A
Nominal Cooling Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	11.17	11.17







		PQHY-P500YLM-A	PQRY-P500YLM-A
Nominal Heating Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	11.43	11.43







7. CAPACITY TABLES

WV

		PQHY-P550YLM-A	PQRY-P550YLM-A
Nominal Cooling Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	12.54	12.54







		PQHY-P550YLM-A	PQRY-P550YLM-A
Nominal Heating Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	12.27	12.27







7. CAPACITY TABLES

WY

		PQHY-P600YLM-A	PQRY-P600YLM-A
Nominal Cooling Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	14.49	14.49







		PQHY-P600YLM-A	PQRY-P600YLM-A
Nominal Heating Capacity	kW	76.5	76.5
	BTU/h	261,000	261,000
Input	kW	14.51	14.51



7. CAPACITY TABLES





WV

		PQHY-P400YSLM-A	PQRY-P400YSLM-A
Nominal Cooling Capacity	kW	45.0	45.0
	BTU/h	153,500	153,500
Input	kW	7.70	7.70



*The drawing indicates characteristic per unit.

		PQHY-P400YSLM-A	PQRY-P400YSLM-A
Nominal Heating Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	7.94	7.94





*The drawing indicates characteristic per unit.





7. CAPACITY TABLES

WY



		PQHY-P450YSLM-A	PQRY-P450YSLM-A
Nominal Cooling Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	8.78	8.78



		PQHY-P450YSLM-A	PQRY-P450YSLM-A
Nominal Heating Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	8.97	8.97



*The drawing indicates characteristic per unit.







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





WV

		PQHY-P500YSLM-A	PQRY-P500YSLM-A
Nominal Cooling Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	10.12	10.12



*The drawing indicates characteristic per unit.

		PQHY-P500YSLM-A	PQRY-P500YSLM-A
Nominal Heating Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	10.16	10.16





*The drawing indicates characteristic per unit.





7. CAPACITY TABLES

WY



		PQHY-P550YSLM-A	PQRY-P550YSLM-A
Nominal Cooling Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	11.55	11.55



		PQHY-P550YSLM-A	PQRY-P550YSLM-A
Nominal Heating Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	11.31	11.31



*The drawing indicates characteristic per unit.





*The drawing indicates characteristic per unit.





7. CAPACITY TABLES

WV



		PQHY-P600YSLM-A	PQRY-P600YSLM-A
Nominal Cooling Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	12.84	12.84



		PQHY-P600YSLM-A	PQRY-P600YSLM-A
Nominal Heating Capacity	kW	76.5	76.5
	BTU/h	261,000	261,000
Input	kW	12.75	12.75



*The drawing indicates characteristic per unit.







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





WY

		PQHY-P700YSLM-A	PQRY-P700YSLM-A
Nominal Cooling Capacity	kW	80.0	80.0
	BTU/h	273,000	273,000
Input	kW	14.73	14.73



*The drawing indicates characteristic per unit.

		PQHY-P700YSLM-A	PQRY-P700YSLM-A
Nominal Heating Capacity	kW	88.0	88.0
	BTU/h	300,300	300,300
Input	kW	14.73	14.73







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





WV

		PQHY-P750YSLM-A	PQRY-P750YSLM-A
Nominal Cooling Capacity	kW	85.0	85.0
	BTU/h	290,000	290,000
Input	kW	15.64	15.64



*The drawing indicates characteristic per unit.

		PQHY-P750YSLM-A	PQRY-P750YSLM-A
Nominal Heating Capacity	kW	95.0	95.0
	BTU/h	324,100	324,100
Input	kW	15.90	15.90







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





WY

		PQHY-P800YSLM-A	PQRY-P800YSLM-A
Nominal Cooling Capacity	kW	90.0	90.0
	BTU/h	307,100	307,100
Input	kW	16.57	16.57



*The drawing indicates characteristic per unit.

		PQHY-P800YSLM-A	PQRY-P800YSLM-A
Nominal Heating Capacity	kW	100.0	100.0
	BTU/h	341,200	341,200
Input	kW	16.75	16.75







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





WV

		PQHY-P850YSLM-A	PQRY-P850YSLM-A
Nominal Cooling Capacity	kW	96.0	96.0
	BTU/h	327,600	327,600
Input	kW	18.03	18.03



*The drawing indicates characteristic per unit.

		PQHY-P850YSLM-A	PQRY-P850YSLM-A
Nominal Heating Capacity	kW	108.0	108.0
	BTU/h	368,500	368,500
Input	kW	18.49	18.49







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES

HEAT SOURCE





WY

		PQHY-P900YSLM-A	PQRY-P900YSLM-A
Nominal Cooling Capacity	kW	101.0	101.0
	BTU/h	344,600	344,600
Input	kW	19.38	19.38



*The drawing indicates characteristic per unit.

		PQHY-P900YSLM-A	PQRY-P900YSLM-A
Nominal Heating Capacity	kW	113.0	113.0
	BTU/h	385,600	385,600
Input	kW	19.74	19.74




*The drawing indicates characteristic per unit.

7-2. Correction by total indoor

CITY MULTI system have different capacities and inputs when many combinations of indoor units with different total capacities are connected. Using following tables, the maximum capacity can be found to ensure the system is installed with enough capacity for a particular application.


PQHY-P200YLM-A		
Nominal Cooling Capacity	kW	22.4
	BTU/h	76,400
Input	kW	3.71

PQHY-P200YLM-A		
Nominal Heating Capacity	kW	25.0
	BTU/h	85,300
Input	kW	3.97



PQHY-P250YLM-A		
Nominal Cooling Capacity	kW	28.0
	BTU/h	95,500
Input	kW	4.90


PQHY-P250YLM-A		
Nominal Heating Capacity	kW	31.5
	BTU/h	107,500
Input	kW	5.08



WY


PQHY-P300YLM-A		
Nominal Cooling Capacity	kW	33.5
	BTU/h	114,300
Input	kW	6.04

PQHY-P300YLM-A		
Nominal Heating Capacity	kW	37.5
	BTU/h	128,000
Input	kW	6.25



PQHY-P350YLM-A		
Nominal Cooling Capacity	kW	40.0
	BTU/h	136,500
Input	kW	7.14

PQHY-P350YLM-A		
Nominal Heating Capacity	kW	45.0
	BTU/h	153,500
Input	kW	7.53



7. CAPACITY TABLES

WV


PQHY-P400YLM-A		
Nominal Cooling Capacity	kW	45.0
	BTU/h	153,500
Input	kW	8.03

PQHY-P400YLM-A		
Nominal Heating Capacity	kW	50.0
	BTU/h	170,600
Input	kW	8.37

PQHY-P400YSLM-A		
Nominal Cooling Capacity	kW	45.0
	BTU/h	153,500
Input	kW	7.70

PQHY-P400YSLM-A		
Nominal Heating Capacity	kW	50.0
	BTU/h	170,600
Input	kW	7.94

PQHY-P400Y(S)LM-A




PQHY-P450YLM-A		
Nominal Cooling Capacity	kW	50.0
	BTU/h	170,600
Input	kW	9.29

PQHY-P450YLM-A		
Nominal Heating Capacity	kW	56.0
	BTU/h	191,100
Input	kW	9.79

PQHY-P450YSLM-A		
Nominal Cooling Capacity	kW	50.0
	BTU/h	170,600
Input	kW	8.78

PQHY-P450YSLM-A		
Nominal Heating Capacity	kW	56.0
	BTU/h	191,100
Input	kW	8.97

PQHY-P450Y(S)LM-A



7. CAPACITY TABLES

HEAT SOURCE


WY

PQHY-P500YLM-A		
Nominal Cooling Capacity	kW	56.0
	BTU/h	191,100
Input	kW	11.17

PQHY-P500YLM-A		
Nominal Heating Capacity	kW	63.0
	BTU/h	215,000
Input	kW	11.43

PQHY-P500YSLM-A		
Nominal Cooling Capacity	kW	56.0
	BTU/h	191,100
Input	kW	10.12

PQHY-P500YSLM-A		
Nominal Heating Capacity	kW	63.0
	BTU/h	215,000
Input	kW	10.16




PQHY-P550YLM-A		
Nominal Cooling Capacity	kW	63.0
	BTU/h	215,000
Input	kW	12.54

PQHY-P550YLM-A		
Nominal Heating Capacity	kW	69.0
	BTU/h	235,400
Input	kW	12.27

PQHY-P550YSLM-A		
Nominal Cooling Capacity	kW	63.0
	BTU/h	215,000
Input	kW	11.55

PQHY-P550YSLM-A		
Nominal Heating Capacity	kW	69.0
	BTU/h	235,400
Input	kW	11.31



7. CAPACITY TABLES

WV


PQHY-P600YLM-A		
Nominal Cooling Capacity	kW	69.0
	BTU/h	235,400
Input	kW	14.49

PQHY-P600YLM-A		
Nominal Heating Capacity	kW	76.5
	BTU/h	261,000
Input	kW	14.51

PQHY-P600YSLM-A		
Nominal Cooling Capacity	kW	69.0
	BTU/h	235,400
Input	kW	12.84

PQHY-P600YSLM-A		
Nominal Heating Capacity	kW	76.5
	BTU/h	261,000
Input	kW	12.75


PQHY-P600Y(S)LM-A



PQHY-P700YSLM-A		
Nominal Cooling Capacity	kW	80.0
	BTU/h	273,000
Input	kW	14.73


PQHY-P700YSLM-A		
Nominal Heating Capacity	kW	88.0
	BTU/h	300,300
Input	kW	14.73

PQHY-P700YSLM-A




PQHY-P750YSLM-A		
Nominal Cooling Capacity	kW	85.0
	BTU/h	290,000
Input	kW	15.64

PQHY-P750YSLM-A		
Nominal Heating Capacity	kW	95.0
	BTU/h	324,100
Input	kW	15.90



PQHY-P800YSLM-A		
Nominal Cooling Capacity	kW	90.0
	BTU/h	307,100
Input	kW	16.57

PQHY-P800YSLM-A		
Nominal Heating Capacity	kW	100.0
	BTU/h	341,200
Input	kW	16.75




7. CAPACITY TABLES

HEAT SOURCE

WV


PQHY-P850YSLM-A		
Nominal Cooling Capacity	kW	96.0
	BTU/h	327,600
Input	kW	18.03

PQHY-P850YSLM-A		
Nominal Heating Capacity	kW	108.0
	BTU/h	368,500
Input	kW	18.49



PQHY-P900YSLM-A		
Nominal Cooling Capacity	kW	101.0
	BTU/h	344,600
Input	kW	19.38


PQHY-P900YSLM-A		
Nominal Heating Capacity	kW	113.0
	BTU/h	385,600
Input	kW	19.74



7-3. Correction by refrigerant piping length

CITY MULTI system can extend the piping flexibly within its limitation for the actual situation. However, a decrease of cooling/heating capacity could happen correspondently. Using following correction factor according to the equivalent length of the piping shown at 7-3-1 and 7-3-2, the capacity can be observed. 7-3-3 shows how to obtain the equivalent length of piping.







7-3-1. Cooling capacity correction




7. CAPACITY TABLES

HEAT SOURCE

WV



7-3-2. Heating capacity correction



7-3-3. How to obtain the equivalent piping length**1 PQHY-P200YLM**

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.35 × number of bends in the piping) m

2 PQHY-P250, 300YLM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.42 × number of bends in the piping) m

3 PQHY-P350, 400, 450, 500, 550, 600Y(S)LM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.50 × number of bends in the piping) m

4 PQHY-P700, 750, 800YSLM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.70 × number of bends in the piping) m

5 PQHY-P850, 900YSLM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.80 × number of bends in the piping) m

8-1. Designing of water circuit system

1) Example of basic water circuit

The water circuit of the water heat source CITY MULTI connects the heat source unit with the cooling tower/auxiliary heat source/heat storage tank/circulation pump with a single system water piping as shown in the figure below. The selector valve automatically controls to circulate water toward the cooling tower in the cooling season, while toward the heat storage tank in the heating season. If the circulation water temperature is kept in a range of 10~45°C [50~113°F] regardless of the building load, the water heat source CITY MULTI can be operated for either cooling or heating. Therefore in the summer when only cooling load exists, the temperature rise of circulation water will be suppressed by operating the cooling tower. While in the winter when heating load increases, the temperature of circulation water may be dropped below 10°C [50°F]. Under such situation, the circulation water will be heated with the auxiliary heat source if it drops below a certain temperature.


When the thermal balance between cooling and heating operation is in a correct proportion, the operation of the auxiliary heat source and cooling tower is not required.

In order to control the above thermal balance properly and use thermal energy effectively, utilizing of heat storage tanks, and night-time discounted electric power as a auxiliary heat source will be economical.

Meantime as this system uses plural sets of heat source unit equipped with water heat exchangers, water quality control is important. Therefore it is recommended to use closed type cooling towers as much as possible to prevent the circulation water from being contaminated.

When open type cooling towers are used, it is essential to provide proper maintenance control such as that to install water treatment system to prevent troubles caused by contaminated circulation water.

Example of basic water circuit for water heat source CITY MULTI



The indoor unit and refrigerant piping system are excluded in this figure.

2) Cooling tower


a) Types of cooling tower

The cooling towers presently used include the open type cooling tower, open type cooling tower + heat exchanger, closed type cooling tower, and air-cooled type cooling tower. However, as the quality control of circulation water is essential when units are installed in decentralized state inside a building, the closed type cooling tower is generally employed in such case.

Although the circulation water will not be contaminated by atmospheric air, it is recommended to periodically blow water inside the system and replenish fresh water instead.

In a district where the coil may be frozen in the winter, it is necessary to apply antifreeze solution to the circulation water, or take freeze protection measures such as to automatically discharge water inside the cooling coil at the stopping of the pump.

When the open type cooling tower is used, be sure to install a water quality control device in addition to the freeze protection measures, as the water may be deteriorated by atmospheric contaminants entered into the cooling tower and dissolved into the circulation water.



b) Calculation method of cooling tower capacity

All units of the water heat source CITY MULTI may possibly be in cooling operation temporarily (at pulling down) in the summer, however, it is not necessary to determine the capacity according to the total cooling capacity of all CITY MULTI units as this system has a wide operating water temperature range (10~45°C) [50~113°F].

It is determined in accordance with the value obtained by adding the maximum cooling load of an actual building, the input heat equivalent value of all CITY MULTI units, and the cooling load of the circulating pumps. Please check for the values of the cooling water volume and circulation water volume.

$$\text{Cooling tower capacity} = \frac{Q_c + 860 \times (\sum Q_w + P_w)}{3,900} \text{ (Refrigeration ton)}$$

- Q_c : Maximum cooling load under actual state (kcal/h)
- Q_w : Total input of water heat source CITY MULTI at simultaneous operation under maximum state (kW)
- P_w : Shaft power of circulation pumps (kW)

$$\text{Cooling tower capacity} = \frac{Q_c + 3,412 \times (\sum Q_w + P_w)}{15,500} \text{ (Refrigeration ton)}$$

- Q_c : Maximum cooling load under actual state (BTU/h)
- Q_w : Total input of water heat source CITY MULTI at simultaneous operation under maximum state (kW)
- P_w : Shaft power of circulation pumps (kW)

* 1 Refrigerant ton of cooling tower capacity ≈ US refrigerant ton × (1 + 0.3)
= 3,900 kcal/h = 15,500 BTU/h

3) Auxiliary heat source and heat storage tank

When the heating load is larger than the cooling load, the circulation water temperature lowers in accordance with the heat balance of the system. It should be heated by the auxiliary heat source in order to keep the inlet water temperature within the operating range (10°C [50°F] or more) of the water heat source CITY MULTI.

Further in order to operate the water heat source CITY MULTI effectively, it is recommended to utilize the heat storage tank to cover the warming up load in the morning and the insufficient heat amount. Effective heat utilization can be expected to cover insufficient heat at the warming up in the next morning or peak load time by storing heat by installing a heat storage tank or operating a low load auxiliary heat source at the stopping of the water heat source CITY MULTI. As it can also be possible to reduce the running cost through the heat storage by using the discounted night-time electric power, using both auxiliary heat source and heat storage tank together is recommended. The effective temperature difference of an ordinary heat storage tank shows about 5°C [41°F] even with the storing temperature at 45°C [113°F]. However with the water heat source CITY MULTI, it can be utilized as heating heat source up to 15°C [59°F] with an effective temperature of a high 30°C [54°F] approximately, thus the capacity of the heat storage tank can be minimized.

a) Auxiliary heat source

The following can be used as the auxiliary heat source.

- Boiler (Heavy oil, kerosine, gas, electricity)
- Electric heat (Insertion of electric heater into heat storage tank)
- Outdoor air (Air-heat source heat pump chiller)
- Warm discharge water (Exhaust water heat from machines inside building and hot water supply)
- Utilization of night-time lighting
- Solar heat

Please note that the auxiliary heat source should be selected after studying your operating environment and economical feasibility.

Determining the auxiliary heat source capacity

For the CITY MULTI water heat source system, a heat storage tank is recommended to use. When employment of the heat storage tank is difficult, the warming up operation should be arranged to cover the starting up heating load. Since the holding water inside the piping circuit owns heat capacity and the warming up operation can be assumed for about one hour except that in a cold region, the heat storage tank capacity is required to be that at the maximum daily heating load including the warming up load at the next morning of the holiday. However the auxiliary heat source capacity should be determined by the daily heating load including warming up load on the week day. For the load at the next morning of the holiday, heat storage is required by operating the auxiliary heat source even outside of the ordinary working hour.

When heat storage tank is not used

$$QH = HCT \left(1 - \frac{1}{COP_h} \right) - 1000 \times V_w \times \Delta T - 860 \times P_w$$

- QH : Auxiliary heat source capacity (kcal/h)
- HCT : Total heating capacity of each water heat source CITY MULTI (kcal/h)
- COP_H : COP of water heat source CITY MULTI at heating
- V_w : Holding water volume inside piping (m³)
- ΔT : Allowable water temperature drop = T_{WH} - T_{WL} (°C)
- T_{WH} : Heat source water temperature at high temperature side (°C)
- T_{WL} : Heat source water temperature at low temperature side (°C)
- P_w : Heat source water pump shaft power (kW)

$$QH = HCT \left(1 - \frac{1}{COP_h} \right) - 8.343 \times V_w \times \Delta T - 3412 \times P_w$$

- QH : Auxiliary heat source capacity (BTU/h)
- HCT : Total heating capacity of each water heat source CITY MULTI (BTU/h)
- COP_H : COP of water heat source CITY MULTI at heating
- V_w : Holding water volume inside piping (G)
- ΔT : Allowable water temperature drop = T_{WH} - T_{WL} (°F)
- T_{WH} : Heat source water temperature at high temperature side (°F)
- T_{WL} : Heat source water temperature at low temperature side (°F)
- P_w : Heat source water pump shaft power (kW)

When heat storage tank is not used

$$QH = \frac{HQ_{1T} \cdot \left(1 - \frac{1}{COP_h} \right) - 860 \times P_w \times T_2}{T_1} \times K \quad (\text{kcal})$$

- QH_{1T} : Total of heating load on weekday including warming up (kcal/day)
- T₁ : Operating hour of auxiliary heat source (h)
- T₂ : Operating hour of heat source water pump (h)
- K : Allowance factor (Heat storage tank, piping loss, etc.) 1.05~1.10

HQ_{1T} is calculated from the result of steady state load calculation similarly by using the equation below.

$$HQ_{1T} = 1.15 \times (\Sigma Q'a + \Sigma Q'b + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe_1 + \Sigma Qe_2 + \Sigma Qe_3) (T_2 - 1)$$

- Q'a : Thermal load from external wall/roof in each zone (kcal/h)
- Q'b : Thermal load from glass window in each zone (kcal/h)
- Q'c : Thermal load from partition/ceiling/floor in each zone (kcal/h)
- Q'd : Thermal load by infiltration in each zone (kcal/h)
- Q'f : Fresh outdoor air load in each zone (kcal/h)
- Q'e₁ : Thermal load from human body in each zone (kcal/h)
- Q'e₂ : Thermal load from lighting fixture in each zone (kcal/h)
- Q'e₃ : Thermal load from equipment in each zone (kcal/h)
- ψ : Radiation load rate 0.6~0.8
- T₂ : Air conditioning hour

$$QH = \frac{HQ_{1T} \cdot \left(1 - \frac{1}{COP_h} \right) - 3,412 \times P_w \times T_2}{T_1} \times K \quad (\text{BTU})$$

- QH_{1T} : Total of heating load on weekday including warming up (BTU/day)
- T₁ : Operating hour of auxiliary heat source (h)
- T₂ : Operating hour of heat source water pump (h)
- K : Allowance factor (Heat storage tank, piping loss, etc.) 1.05~1.10

HQ_{1T} is calculated from the result of steady state load calculation similarly by using the equation below.

$$HQ_{1T} = 1.15 \times (\Sigma Q'a + \Sigma Q'b + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe_1 + \Sigma Qe_2 + \Sigma Qe_3) (T_2 - 1)$$

- Q'a : Thermal load from external wall/roof in each zone (BTU/h)
- Q'b : Thermal load from glass window in each zone (BTU/h)
- Q'c : Thermal load from partition/ceiling/floor in each zone (BTU/h)
- Q'd : Thermal load by infiltration in each zone (BTU/h)
- Q'f : Fresh outdoor air load in each zone (BTU/h)
- Q'e₁ : Thermal load from human body in each zone (BTU/h)
- Q'e₂ : Thermal load from lighting fixture in each zone (BTU/h)
- Q'e₃ : Thermal load from equipment in each zone (BTU/h)
- ψ : Radiation load rate 0.6~0.8
- T₂ : Air conditioning hour

WY

b) Heat storage tank

Heat storage tank can be classified by types into the open type heat storage tank exposed to atmosphere, and the closed type heat storage tank with structure separated from atmosphere. Although the size of the tank and its installation place should be taken into account, the closed type tank is being usually employed by considering corrosion problems.

The capacity of heat storage tanks is determined in accordance with the daily maximum heating load that includes warming up load to be applied for the day after the holiday.

When auxiliary heat source is operated during operation and even after stopping of water heat source CITY MULTI unit

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 860 \times P_w \times T_2 - Q_H \times T_2}{\Delta T \times 1,000 \times \eta V} \quad (\text{ton})$$

HQ_{2T} : Maximum heating load including load required for the day after the holiday (kcal/day)
 ΔT : Temperature difference utilized by heat storage tank (°C)
 ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 3,412 \times P_w \times T_2 - Q_H \times T_2}{\Delta T \times \eta V} \quad (\text{lbs})$$

HQ_{2T} : Maximum heating load including load required for the day after the holiday (BTU/day)
 ΔT : Temperature difference utilized by heat storage tank (°F)
 ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$

When auxiliary heat source is operated after stopping of water heat source CITY MULTI unit

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 860 \times P_w \times T_2}{\Delta T \times 1,000 \times \eta V} \quad (\text{ton})$$

HQ_{2T} : Maximum heating load including load required for the day after the holiday (kcal/day)
 ΔT : Temperature difference utilized by heat storage tank (°C)
 ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 3,412 \times P_w \times T_2}{\Delta T \times \eta V} \quad (\text{lbs})$$

HQ_{2T} : Maximum heating load including load required for the day after the holiday (BTU/day)
 ΔT : Temperature difference utilized by heat storage tank (°F)
 ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$


4) Piping system

The following items should be kept in your mind in planning / designing water circuits.

- a) All units should be constituted in a single circuit in principle.
- b) When plural numbers of the water heat source CITY MULTI unit are installed, the rated circulating water flow rate should be kept by making the piping resistance to each unit almost same value. As an example, the reverse return system as shown below may be employed.
- c) Depending on the structure of a building, the water circuit may be prefabricated by making the layout uniform.
- d) When a closed type piping circuit is constructed, install an expansion tank usable commonly for a make-up water tank to absorb the expansion/contraction of water caused by temperature fluctuation.
- e) If the operating temperature range of circulation water stays within the temperature near the normal temperature (summer :29.4°C [85°F], winter :21.1°C [70°F]), thermal insulation or anti-sweating work is not required for the piping inside buildings.

In case of the conditions below, however, thermal insulation is required.

- When well water is used for heat source water.
- When piped to outdoor or a place where freezing may be caused.
- When vapor condensation may be generated on piping due to an increase in dry bulb temperature caused by the entry of fresh outdoor air.




5) Practical System Examples and Circulation Water Control

Since the water heat source CITY MULTI is of water heat source system, versatile systems can be constituted by combining it with various heat sources.

The practical system examples are given below.


Either cooling or heating operation can be performed if the circulation water temperature of the water heat source CITY MULTI stays within a range of 10~45°C [50~113°F]. However, the circulation water temperature near 32°C [90°F] for cooling and 20°C [68°F] for heating is recommended by taking the life, power consumption and capacity of the air conditioning units into consideration. The detail of the control is also shown below.

Example-1 Combination of closed type cooling tower and hot water heat storage tank (using underground hollow slab)



Example-2 Combination of closed type cooling tower and hot water heat storage tank

- T1 : Proportional type, insertion system thermostat
- T2 : Proportional type, insertion system thermostat
- T3 : Proportional type, insertion system thermostat
- V1 : Proportional type, motor-driven 3-way valve
- V2 : Proportional type, motor-driven 3-way valve
- XS : Auxiliary switch (Duplex switch type)
- SC : Step controller
- R : Relay
- MG : Magnetic



In the summer, as the circulation water temperature rises exceeding the set temperature of T1, the bypass port of V1 will open to lower the circulation water temperature. In the winter, if the circulation water temperature stays below 25°C [77°F], V2 will open/close by the command of T2 to keep the circulation water temperature constant.


The temperature of the hot water inside the heat storage tank will be controlled through the step control of the electric heater by step controller operation following the command of T3.

During the stopping of the heat source water pump, the bypass port of V2 will be closed fully by interlocking thus preventing the high temperature water from entering into the system at the starting of the pump.

The start/stop control of the fan and pump of the closed type cooling tower is applied with the step control of the fan and pump following the command of the auxiliary switch XS of V1, that operates only the fan at the light load while the fan and pump at the maximum load thus controlling water temperature and saving motor power.

Example-3 Combination of closed type cooling tower and boiler


- T1 : Proportional type, insertion system thermostat
- T2 : Proportional type, insertion system thermostat
- T3 : Proportional type, insertion system thermostat
- V1 : Proportional type, motor-driven 3-way valve
- S : Selector switch
- R : Relay
- XS : Auxiliary switch (Duplex switch type)



In the summer, as the circulation water temperature rises exceeding the set temperature of T1, the bypass port of V1 will close to lower the circulation water temperature. In the winter, if the circulation water temperature drops below 25°C [77°F], V2 will conduct water temperature control to keep the circulation water temperature constant. During the stopping of the heat source water pump, the bypass port of V2 will be closed fully by interlocking. The start/stop control of the fan and pump of the closed type cooling tower is applied with the step control following the command of the auxiliary switch XS of V1, thus controlling water temperature and saving motor power.


Example-4 Combination of closed type cooling tower and heat exchanger (of other heat source)

- T1 : Proportional type, insertion system thermostat
- T2 : Proportional type, insertion system thermostat
- V1 : Proportional type, motor-driven 3-way valve
- V2 : Proportional type, motor-driven 3-way valve
- S : Selector switch
- R : Relay
- XS : Auxiliary switch (Duplex switch type)




In the summer, as the circulation water temperature rises exceeding the set temperature of T1, the bypass port of V1 will close to lower the circulation water temperature. In the winter, if the circulation water temperature drops below 26°C [79°F], V2 will conduct water temperature control to keep the circulation water temperature constant. During the stopping of the heat source water pump, the bypass port of V2 will be closed fully by interlocking. The start/stop control of the fan and pump of the closed type cooling tower is applied with the step control following the command of the auxiliary switch XS of V1, thus controlling water temperature and saving motor power.

6) Pump interlock circuit



Wiring diagram

This circuit uses the "Terminal block for pump interlock (TB8)" inside the electrical parts box of the heat source equipment. This circuit is for interlocking the heat source equipment operation and the heat source water pump.




Operation ON signal

Terminal No.	TB8-1, 2																														
Output	Relay contacts output Rated voltage : L1 - N : 220 ~ 240V Rated load : 1A																														
Operation	<ul style="list-style-type: none"> When setting No.917 for Dip switch 4 (Dip switch 6-10 is ON) is OFF. The relay closes during compressor operation. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th colspan="10">SW4 0: OFF, 1: ON</th> </tr> <tr> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td>0</td><td>1</td><td>1</td><td>1</td> </tr> </table> <ul style="list-style-type: none"> When setting No.917 for Dip switch 4 (Dip switch 6-10 is ON) is ON. The relay closes during reception of cooling or the heating operation signal from the controller. (Note : It is output even if the thermostat is OFF (when the compressor is stopped).) 	SW4 0: OFF, 1: ON										1	2	3	4	5	6	7	8	9	10	1	0	1	0	1	0	0	1	1	1
SW4 0: OFF, 1: ON																															
1	2	3	4	5	6	7	8	9	10																						
1	0	1	0	1	0	0	1	1	1																						

Pump Interlock

Terminal No.	TB8-3, 4
Input	Level signal
Operation	If the circuit between TB8-3 and TB8-4 is open, compressor operation is prohibited.

*Remove the short circuit wire between 3 and 4 when wiring to TB8.
To prevent a false detection of error resulting from contact failure, use a flow switch with a minimum guaranteed current of 5 mA or below for FS.



WY

8-2. Water piping work

Although the water piping for the CITY MULTI WY system does not differ from that for ordinary air conditioning systems, pay special attention to the items below in conducting the piping work.


1) Items to be observed on installation work

- In order to equalize piping resistance for each unit, adapt the reverse return system.
- Mount a joint and a valve onto the water outlet/inlet of the unit to allow for maintenance, inspection and replacement work. Be sure to mount a strainer at the water inlet piping of the unit. (The strainer is required at the circulation water inlet to protect the heat source unit.)
- * The installation example of the heat source unit is shown right.
- Be sure to provide an air relief opening on the water piping properly, and purge air after feeding water to the piping system.
- Condensate will generate at the low temperature part inside the heat source equipment. Connect drain piping to the drain piping connection located at the bottom of the heat source equipment to discharge it outside the equipment.
- At the center of the header of the heat exchanger water inlet inside the unit, a plug for water discharge is being provided. Use it for maintenance work or the like.
- Mount a backflow prevention valve and a flexible joint for vibration control onto the pump.
- Provide a sleeve to the penetrating parts of the wall to prevent the piping.
- Fasten the piping with metal fitting, arrange the piping not to expose to cutting or bending force, and pay sufficient care for possible vibration.
- Be careful not to erroneously judge the position of the inlet and outlet of water.
(Lower position : Inlet, Upper position : Outlet)
- When connecting heat source unit water piping and water piping on site, apply liquid sealing material for water piping over the sealing tape before connection. (for Maximum water pressure above 1.0MPa)
- Wrap the sealing tape as follows.
- a) Wrap the joint with sealing tape in the direction of the threads (clockwise), and do not let the tape run over the edge.
- b) Overlap the sealing tape by two-thirds to three-fourths of its width on each turn. Press the tape with your fingers so that it is pressed firmly against each thread.
- c) Leave the 1.5th through 2nd farthest threads away from the pipe end unwrapped.
- Hold the pipe on the unit side in place with a spanner when installing the pipes or strainer. Tighten screws to a torque of 150N · m.

2) Thermal insulation work

Thermal insulation or anti sweating work is not required for the piping inside buildings in the case of the CITY MULTI WY system if the operating temperature range of circulation water stays within the temperature near the normal (summer : 29.4°C[85°F], winter : 21.1°C[70°F]). In case of the conditions below, however, thermal insulation is required.

- Use of well water for heat source water
- Outdoor piping portions
- Indoor piping portions where freezing may be caused in winter
- A place where vapor condensation may be generated on



- piping due to an increase in dry bulb temperature inside the ceiling caused by the entry of fresh outdoor air
- Drain piping portions

3) Water treatment and water quality control

For the circulation water cooling tower of the CITY MULTI WY system, employment of the closed type is recommended to keep water quality. However, in the case that an open type cooling tower is employed or the circulating water quality is inferior, scale will adhere onto the water heat exchanger leading to the decreased heat exchange capacity or the corrosion of the heat exchanger. Be sufficiently careful for water quality control and water treatment at the installation of the circulation water system.

- Removal of impurities inside piping
Be careful not to allow impurities such as welding fragment, remaining sealing material and rust from mixing into the piping during installation work.
- Water treatment
The water quality standards have been established by the industry (Japan Refrigeration, Air Conditioning Industry Association, in case of Japan) for water treatment to be applied.

Items	Lower mid-range temperature water system		Tendency	
	Recirculating water [20<T<60°C] [68<T<140°F]	Make-up water	Corrosive	Scale-forming
pH (25°C[77°F])	7.0 ~ 8.0	7.0 ~ 8.0	○	○
Electric conductivity (mS/m) (25°C[77°F])	30 or less	30 or less	○	○
(µS/cm) (25°C[77°F])	[300 or less]	[300 or less]		
Chloride ion (mg Cl/l/l)	50 or less	50 or less	○	
Sulfate ion (mg SO ₄ ²⁻ /l/l)	50 or less	50 or less	○	
Acid consumption (pH4.8) (mg CaCO ₃ /l/l)	50 or less	50 or less		○
Total hardness (mg CaCO ₃ /l/l)	70 or less	70 or less		○
Calcium hardness (mg CaCO ₃ /l/l)	50 or less	50 or less		○
Ionic silica (mg SiO ₂ /l/l)	30 or less	30 or less		○
Iron (mg Fe/l/l)	1.0 or less	0.3 or less	○	○
Copper (mg Cu/l/l)	1.0 or less	0.1 or less	○	
Sulfide ion (mg S ²⁻ /l/l)	not to be detected	not to be detected	○	
Ammonium ion (mg NH ₄ ⁺ /l/l)	0.3 or less	0.1 or less	○	
Residual chlorine (mg Cl/l/l)	0.25 or less	0.3 or less	○	
Free carbon dioxide (mg CO ₂ /l/l)	0.4 or less	4.0 or less	○	
Ryzner stability index	-	-	○	○

Reference : Guideline of Water Quality for Refrigeration and Air Conditioning Equipment. (JRA GL02E-1994)

In order to keep the water quality within such standards, you are kindly requested to conduct bleeding-off by overflow and periodical water quality tests, and use inhibitors to suppress condensation or corrosion. Since piping may be corroded by some kinds of inhibitor, consult an appropriate water treatment expert for proper water treatment.


4) Pump interlock

Operating the heat source unit without circulation water inside the water piping can cause a trouble. Be sure to provide interlocking for the unit operation and water circuit. Since the terminal block is being provided inside the unit, use it as required.

5) Handling plate heat exchangers for heat-source units

<Designing the piping system>

- Install a strainer (50 mesh or finer recommended) near the heat-source unit on the inlet side of the hot/cold water pipe and cooling-water pipe (hereafter referred to as water pipes) to prevent an infiltration of foreign materials of solid nature, such as dirt and sand, into the plate heat exchanger.
- Depending on the water quality, scale may form inside plate heat exchangers. Plate heat exchangers must be chemically cleaned regularly to remove scale formation. Install sluice valves on the water pipes, and provide ports for connecting a pipe between the sluice valves and the heat-source unit for chemical cleaning.
- On both the inlet and outlet sides of water pipes, provide a plug to remove trapped air and water (also to be used for cleaning heat-source units and for purging water before a period of nonuse in winter or at the end of an air conditioning season). Also, provide automatic air-vent valves where air is likely to be trapped (such as a pipe that runs vertically).
- In addition to installing the above-mentioned strainers, install a cleanable strainer near the pump pipe inlet.
- Keep the pipes properly insulated and take an appropriate measure against humidity to minimize heat loss and prevent freeze damage in severe cold climate.
- If the system is stopped during winter or at night in subfreezing temperatures, take appropriate measures to protect pipes from freezing (i.e., pipe purging and use of water-circulation pump or heater) and prevent resultant damage to the plate heat exchanger.



<Test run>

- Before performing a test run, check that the piping system is properly installed, especially the strainers, air-vents, automatic water-supply valves, expansion tanks, and systems.
- After the pipe system is filled with water, first, operate the pump alone to check the system for trapped air and adjust the water flow rate to prevent the plate heat exchanger from freezing. Take into consideration the water pressure loss before and after each heat-source unit, and make sure the water flow rate falls within the design water flow rate range. Stop the test run and correct any problems found, if any.
- At the completion of a test run, check the strainer at the inlet pipe of the heat-source unit and clean it as necessary.

<Daily maintenance>

- Controlling the water quality
Plate heat exchangers cannot be disassembled for cleaning and have no replaceable parts. Watch the water quality to prevent corrosion and scale formation. The quality of the water to be used for plate heat exchangers must meet the water quality guidelines JRA GL-02-1994 specified by Japan Refrigeration and Air conditioning Industry Association (JRAIA). (Refer to section 3) Water treatment and water quality control.)
- Controlling the circulation water flow rate
Insufficient water rate will cause freeze damage to plate heat exchangers. Check for insufficient water flow caused by clogged strainer, trapped air in the system, or malfunction of the circulation water pump. Flow rate can also be checked by measuring the temperature or pressure difference between the inlet and outlet of plate heat exchangers. If the temperature or pressure difference goes outside of the specified range, stop the operation, remove the cause of the problem, and resume operation.
- What to do when the freeze protection trips
If the freeze protection trips during operation, be sure to remove its cause before resuming operation. Tripped freeze protection indicates that the system is partially frozen, and resuming operation without removing the cause of the problem will result in freeze damage to plate heat exchangers and/or pipes as well as resultant refrigerant leaks and infiltration of water into the refrigerant circuit.

<Maintaining plate heat exchangers>

Plate heat exchangers must be maintained in a planned and periodical manner to prevent scale formation, which may cause performance loss or decrease water flow rate that result in freeze damage to the plate heat exchanger.





- ♦ Check the following items before the operating season.
 1. Check that the water quality meets the specified water quality.
 2. Clean the strainers.
 3. Check that the water flow rate is adequate.
 4. Check for proper operation (e.g., pressure, flow rate, inlet/outlet temperatures).

- ♦ Plate heat exchangers cannot be disassembled for cleaning. Clean them in the following way.
 1. Make sure that there is a pipe connection port on the water inlet pipe.
Use formic acid, citric acid, oxalic acid, acetic acid, or phosphoric acid diluted to 5% to clean plate heat exchangers. Do not use highly corrosive acids, such as hydrochloric acid, sulfuric acid, or nitric acid.
 2. Make sure that valves are installed before the inlet connection port and after the outlet connection port.
 3. Connect a pipe for circulating cleaning solution to the inlet/outlet pipes of the plate heat exchanger, fill the plate heat exchanger with cleaning solution at a temperature between 50 and 60°C, and circulate the cleaning solution with a pump for 2 to 5 hours. The cleaning time will depend on the temperature of the cleaning solution and the degree of scale formation. Use the color of the cleaning solution as a guide to determine how long the system needs to be cleaned.
 4. When done, discharge the cleaning solution out of the plate heat exchanger, fill it with sodium hydrate (NaOH) or sodium bicarbonate (NaHCO₃) diluted with water to 1 to 2%, and let the solution be circulated for 15 to 20 minutes until the cleaning solution is neutralized.
 5. After neutralizing the cleaning solution, thoroughly rinse the plate heat exchanger with clean water.
 6. When using a commercially available cleaning solution, make sure to use a solution not corrosive to stainless steel or copper.
 7. Consult the cleaning solution manufacture for details.

- ♦ At the completion of cleaning, check the system for proper operation.

9-1. JOINT

CITY MULTI units can be easily connected by using Joint sets and Header sets provided by Mitsubishi Electric. Four kinds of Joint sets are available for use. Refer to section 3 in "System Design" or the Installation Manual that comes with the Joint set for how to install the Joint set.



9-2. HEADER

CITY MULTI units can be easily connected by using Joint sets and Header sets provided by Mitsubishi Electric. Three kinds of Header sets are available for use. Refer to section 3 in "System Design" or the Installation Manual that comes with the Header set for how to install the Header set.

CMY-Y104-G mm

For Gas pipe:

<Deformed pipe(Accessory)>
 ID ϕ 15.88
 OD ϕ 15.88 (3 Pcs.)

For Liquid pipe:

<Deformed pipe(Accessory)>
 ID ϕ 9.52
 OD ϕ 9.52 (3 Pcs.)

ID: Inner Diameter OD: Outer Diameter
 NOTE: Besides above mentioned accessories, caps for pipe of ϕ 6.35, ϕ 9.52, ϕ 12.7, ϕ 15.88 (each diameter 1 piece) are included in the Header set.

CMY-Y108-G mm

For Gas pipe:

<Deformed pipe(Accessory)>
 ID ϕ 12.7
 OD ϕ 18.05
 ID ϕ 15.88
 OD ϕ 19.05
 ID ϕ 22.2
 OD ϕ 19.05
 ID ϕ 12.7
 OD ϕ 15.88 (5 Pcs.)
 ID ϕ 19.05
 OD ϕ 15.88 (2 Pcs.)

For Liquid pipe:

<Deformed pipe(Accessory)>
 ID ϕ 6.35
 OD ϕ 9.52 (6 Pcs.)

ID: Inner Diameter OD: Outer Diameter
 NOTE: Besides above mentioned accessories, caps for pipe of ϕ 6.35, ϕ 9.52, ϕ 12.7, ϕ 15.88 (each diameter 2 pieces) and 1 cap for pipe of ϕ 19.05 are included in the Header set.

CMY-Y1010-G mm

For Gas pipe:

<Deformed pipe(Accessory)>
 ID ϕ 12.7
 OD ϕ 19.05 (2 Pcs.)
 ID ϕ 15.88
 OD ϕ 19.05 (2 Pcs.)
 ID ϕ 12.7
 OD ϕ 15.88 (5 Pcs.)
 ID ϕ 19.05
 OD ϕ 15.88
 ID ϕ 15.88
 OD ϕ 12.7 (3 Pcs.)
 ID ϕ 22.2
 OD ϕ 19.05



For Liquid pipe:

<Deformed pipe(Accessory)>
 ID ϕ 15.88
 OD ϕ 12.7
 ID ϕ 12.7
 OD ϕ 12.7
 ID ϕ 9.52
 OD ϕ 12.7
 ID ϕ 6.35
 OD ϕ 9.52 (5 Pcs.)
 ID ϕ 6.35
 OD ϕ 6.35 (5 Pcs.)


ID: Inner Diameter OD: Outer Diameter
 NOTE: Besides above mentioned accessories, caps for pipe of ϕ 6.35, ϕ 9.52, ϕ 12.7, ϕ 15.88 (each diameter 2 pieces) and 1 cap for pipe of ϕ 19.05 are included in the Header set.

9-3. OUTDOOR TWINNING KIT

The following optional Outdoor Twinning Kit is needed to use to combine multiple refrigerant pipes. Refer to the chapter entitled System Design Section for the details of selecting a proper twinning kit.



Note 1. Reference the attitude angle of the branch pipe below the fig.



The angle of the branch pipe is within $\pm 15^\circ$ against the horizontal plane.

2. Use the attached pipe to braze the port-opening of the distributor.
3. Pipe diameter is indicated by inside diameter.

HEAT SOURCE UNITS

1. SPECIFICATIONS	84
2. EXTERNAL DIMENSIONS	103
3. CENTER OF GRAVITY	108
4. ELECTRICAL WIRING DIAGRAMS	109
5. SOUND LEVELS	110
6. OPERATION TEMPERATURE RANGE	115
7. CAPACITY TABLES	116
7-1. Correction by temperature	116
7-2. Correction by total indoor	135
7-3. Correction by refrigerant piping length	142
7-4. Correction by port counts of the BC controller	145
8. SYSTEM DESIGN GUIDE	146
8-1. Designing of water circuit system	146
8-2. Water piping work	158
9. OPTIONAL PARTS	162
9-1. JOINT	162
9-2. OUTDOOR TWINNING KIT	163
9-3. JOINT KIT "CMY-R160-J1" FOR BC CONTROLLER	164

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P200YLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	22.4		
		kcal/h	20,000		
		BTU/h	76,400		
	Power input	kW	3.71		
		Current input	A	6.2-5.9-5.7	
EER		kW/kW	6.03		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	25.0		
		kcal/h	21,500		
		BTU/h	85,300		
	Power input	kW	3.97		
		Current input	A	6.7-6.3-6.1	
COP		kW/kW	6.29		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity		
	Model/Quantity		P15~P250/1~20		
Sound pressure level (measured in anechoic room)		dB <A>	46		
Sound power level (measured in anechoic room)		dB <A>	60		
Refrigerant piping diameter	High pressure	mm (in.)	15.88 (5/8) Brazed		
	Low pressure	mm (in.)	19.05 (3/4) Brazed		
Circulating water	Water flow rate	m ³ /h	5.76		
		L/min	96		
		cfm	3.4		
	Pressure drop	kPa	24		
	Operating volume range	m ³ /h	3.0 ~ 7.2		
Compressor	Type		Inverter scroll hermetic compressor		
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method		Inverter		
	Motor output	kW	4.8		
	Case heater	kW	-		
	Lubricant		MEL32		
External finish			Galvanized steel sheets		
External dimension H x W x D		mm	1,100 x 880 x 550		
		in.	43-5/16 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		
	Compressor		Over-heat protection		
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)		
	Control		Indoor LEV and BC controller		
Net weight		kg (lbs)	172 (380)		
Heat exchanger			plate type		
	Water volume in plate	l	5.0		
	Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)			-		
Drawing	External		WKS94C743		
	Wiring		WKE94G131		
Standard attachment	Document		Installation Manual		
	Accessory		Refrigerant conn. pipe		
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 BC controller: CMB-P104, 105, 106, 108, 1010, 1013, 1016V-G1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1		
Remarks			Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice. The ambient temperature of the heat source unit needs to be kept below 40°C D.B. The ambient relative humidity of the heat source unit needs to be kept below 80%. The heat source unit should not be installed at outdoor. Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit. Be sure to provide interlocking for the unit operation and water circuit. Install the supplied insulation material to the unused drain-socket. When installing insulation material around both water and refrigerant piping, follow the installation manual.		

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

W/R2

Model			PQRY-P250YLM-A			
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1	kW	28.0			
		kcal/h	25,000			
		BTU/h	95,500			
	Power input	kW	4.90			
		Current input	A	8.2-7.8-7.5		
EER		kW/kW	5.71			
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Heating capacity (Nominal)	*2	kW	31.5			
		kcal/h	27,100			
		BTU/h	107,500			
	Power input	kW	5.08			
		Current input	A	8.5-8.1-7.8		
COP		kW/kW	6.20			
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity				
	Model/Quantity	P15~P250/1~25				
Sound pressure level (measured in anechoic room)		dB <A>	48			
Sound power level (measured in anechoic room)		dB <A>	62			
Refrigerant piping diameter	High pressure	mm (in.)	19.05 (3/4) Brazed			
	Low pressure	mm (in.)	22.2 (7/8) Brazed			
Circulating water	Water flow rate	m ³ /h	5.76			
		L/min	96			
		cfm	3.4			
	Pressure drop	kPa	24			
	Operating volume range	m ³ /h	3.0 ~ 7.2			
Compressor	Type	Inverter scroll hermetic compressor				
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION				
	Starting method	Inverter				
	Motor output	kW	6.2			
	Case heater	kW	-			
	Lubricant	MEL32				
External finish		Galvanized steel sheets				
External dimension H x W x D		mm	1,100 x 880 x 550			
		in.	43-5/16 x 34-11/16 x 21-11/16			
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)				
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection				
	Compressor	Over-heat protection				
Refrigerant	Type x original charge	R410A x 5.0 kg (12 lbs)				
	Control	Indoor LEV and BC controller				
Net weight		kg (lbs)	172 (380)			
Heat exchanger		plate type				
		Water volume in plate	l	5.0		
		Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)		-				
Drawing	External	WKS94C743				
	Wiring	WKE94G131				
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts		Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 BC controller: CMB-P104, 105, 106, 108, 1010, 1013, 1016V-G1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1				
Remarks		Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice. The ambient temperature of the heat source unit needs to be kept below 40°C D.B. The ambient relative humidity of the heat source unit needs to be kept below 80%. The heat source unit should not be installed at outdoor. Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit. Be sure to provide interlocking for the unit operation and water circuit. Install the supplied insulation material to the unused drain-socket. When installing insulation material around both water and refrigerant piping, follow the installation manual.				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.) 2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31 lbs =kg/0.4536 *Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P300YLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	33.5		
		kcal/h	30,000		
		BTU/h	114,300		
	Power input	kW	6.04		
		Current input	A	10.1-9.6-9.3	
EER		kW/kW	5.54		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	37.5		
		kcal/h	32,300		
		BTU/h	128,000		
	Power input	kW	6.25		
		Current input	A	10.5-10.0-9.6	
COP		kW/kW	6.00		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity		
	Model/Quantity		P15~P250/1~30		
Sound pressure level (measured in anechoic room)		dB <A>	54		
Sound power level (measured in anechoic room)		dB <A>	68		
Refrigerant piping diameter	High pressure	mm (in.)	19.05 (3/4) Brazed		
	Low pressure	mm (in.)	22.2 (7/8) Brazed		
Circulating water	Water flow rate	m ³ /h	5.76		
		L/min	96		
		cfm	3.4		
	Pressure drop	kPa	24		
	Operating volume range	m ³ /h	3.0 ~ 7.2		
Compressor	Type		Inverter scroll hermetic compressor		
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method		Inverter		
	Motor output	kW	7.7		
	Case heater	kW	-		
	Lubricant		MEL32		
External finish			Galvanized steel sheets		
External dimension H x W x D		mm	1,100 x 880 x 550		
		in.	43-5/16 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		
	Compressor		Over-heat protection		
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)		
	Control		Indoor LEV and BC controller		
Net weight		kg (lbs)	172 (380)		
Heat exchanger			plate type		
	Water volume in plate	l	5.0		
	Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)			-		
Drawing	External		WKS94C743		
	Wiring		WKE94G131		
Standard attachment	Document		Installation Manual		
	Accessory		Refrigerant conn. pipe		
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 BC controller: CMB-P104, 105, 106, 108, 1010, 1013, 1016V-G1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1		
Remarks			Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice. The ambient temperature of the heat source unit needs to be kept below 40°C D.B. The ambient relative humidity of the heat source unit needs to be kept below 80%. The heat source unit should not be installed at outdoor. Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit. Be sure to provide interlocking for the unit operation and water circuit. Install the supplied insulation material to the unused drain-socket. When installing insulation material around both water and refrigerant piping, follow the installation manual.		

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

Model			PQRY-P350YLM-A			
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1	kW	40.0			
		kcal/h	35,000			
		BTU/h	136,500			
	*1	Power input	kW	7.14		
		Current input	A	12.0-11.4-11.0		
EER		kW/kW	5.60			
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Heating capacity (Nominal)	*2	kW	45.0			
		kcal/h	40,000			
		BTU/h	153,500			
	*2	Power input	kW	7.53		
		Current input	A	12.7-12.0-11.6		
COP		kW/kW	5.97			
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity				
	Model/Quantity	P15~P250/1~35				
Sound pressure level (measured in anechoic room)		dB <A>	52			
Sound power level (measured in anechoic room)		dB <A>	66			
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed			
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed			
Circulating water	Water flow rate	m ³ /h	7.20			
		L/min	120			
		cfm	4.2			
	Pressure drop	kPa	44			
	Operating volume range	m ³ /h	4.5 ~ 11.6			
Compressor	Type	Inverter scroll hermetic compressor				
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION				
	Starting method	Inverter				
	Motor output	kW	9.5			
	Case heater	kW	-			
	Lubricant	MEL32				
External finish		Galvanized steel sheets				
External dimension H x W x D		mm	1,450 x 880 x 550			
		in.	57-1/8 x 34-11/16 x 21-11/16			
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)				
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection				
	Compressor	Over-heat protection				
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)				
	Control	Indoor LEV and BC controller				
Net weight		kg (lbs)	216 (477)			
Heat exchanger		plate type				
		Water volume in plate	l	5.0		
		Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)		-				
Drawing	External	WKS94C744				
	Wiring	WKE94G131				
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts		Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 BC controller: CMB-P104, 105, 106, 108, 1010, 1013, 1016V-G1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1				
Remarks		Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual. Due to continuing improvement, above specifications may be subject to change without notice. The ambient temperature of the heat source unit needs to be kept below 40°C D.B. The ambient relative humidity of the heat source unit needs to be kept below 80%. The heat source unit should not be installed at outdoor. Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit. Be sure to provide interlocking for the unit operation and water circuit. Install the supplied insulation material to the unused drain-socket. When installing insulation material around both water and refrigerant piping, follow the installation manual.				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P400YLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	45.0		
		kcal/h	40,000		
		BTU/h	153,500		
	Power input	kW	8.03		
		Current input	A	13.5-12.8-12.4	
EER		kW/kW	5.60		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	50.0		
		kcal/h	45,000		
		BTU/h	170,600		
	Power input	kW	8.37		
		Current input	A	14.1-13.4-12.9	
COP		kW/kW	5.97		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity		
	Model/Quantity		P15~P250/1~40		
Sound pressure level (measured in anechoic room)		dB <A>	52		
Sound power level (measured in anechoic room)		dB <A>	66		
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed		
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed		
Circulating water	Water flow rate	m ³ /h	7.20		
		L/min	120		
		cfm	4.2		
	Pressure drop	kPa	44		
	Operating volume range	m ³ /h	4.5 ~ 11.6		
Compressor	Type		Inverter scroll hermetic compressor		
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method		Inverter		
	Motor output	kW	10.7		
	Case heater	kW	-		
	Lubricant		MEL32		
External finish			Galvanized steel sheets		
External dimension H x W x D		mm	1,450 x 880 x 550		
		in.	57-1/8 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		
	Compressor		Over-heat protection		
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)		
	Control		Indoor LEV and BC controller		
Net weight		kg (lbs)	216 (477)		
Heat exchanger			plate type		
	Water volume in plate	l	5.0		
	Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)			-		
Drawing	External		WKS94C744		
	Wiring		WKE94G131		
Standard attachment	Document		Installation Manual		
	Accessory		Refrigerant conn. pipe		
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1		
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>		

Notes:	Unit converter
1. Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h = kW x 3,412
2. Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm = m ³ /min x 35.31
	lbs = kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WR2

Model			PQRY-P450YLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	50.0		
		kcal/h	45,000		
		BTU/h	170,600		
	Power input	kW	9.29		
		Current input	A	15.6-14.8-14.3	
EER		kW/kW	5.38		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	56.0		
		kcal/h	50,000		
		BTU/h	191,100		
	Power input	kW	9.79		
		Current input	A	16.5-15.7-15.1	
COP		kW/kW	5.72		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity			
	Model/Quantity	P15~P250/1~45			
Sound pressure level (measured in anechoic room)		dB <A>	54		
Sound power level (measured in anechoic room)		dB <A>	70		
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed		
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed		
Circulating water	Water flow rate	m ³ /h	7.20		
		L/min	120		
		cfm	4.2		
	Pressure drop	kPa	44		
	Operating volume range	m ³ /h	4.5 ~ 11.6		
Compressor	Type	Inverter scroll hermetic compressor			
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION			
	Starting method	Inverter			
	Motor output	kW	11.6		
	Case heater	kW	-		
	Lubricant	MEL32			
External finish			Galvanized steel sheets		
External dimension H x W x D		mm	1,450 x 880 x 550		
		in.	57-1/8 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection			
	Compressor	Over-heat protection			
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)			
	Control	Indoor LEV and BC controller			
Net weight		kg (lbs)	216 (477)		
Heat exchanger			plate type		
Water volume in plate		l	5.0		
Water pressure Max.		MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)			-		
Drawing	External	WKS94C744			
	Wiring	WKE94G131			
Standard attachment	Document	Installation Manual			
	Accessory	Refrigerant conn. pipe			
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1		
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>		

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P500YLM-A
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz
Cooling capacity (Nominal)	*1	kW	56.0
		kcal/h	50,000
		BTU/h	191,100
	Power input	kW	11.17
		A	18.8-17.9-17.2
EER		5.01	
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Heating capacity (Nominal)	*2	kW	63.0
		kcal/h	55,000
		BTU/h	215,000
	Power input	kW	11.43
		A	19.2-18.3-17.6
COP		5.51	
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity	
	Model/Quantity	P15~P250/1~50	
Sound pressure level (measured in anechoic room)		dB <A>	54
Sound power level (measured in anechoic room)		dB <A>	70.5
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed
Circulating water	Water flow rate	m ³ /h	7.20
		L/min	120
		cfm	4.2
	Pressure drop	kPa	44
	Operating volume range	m ³ /h	4.5 ~ 11.6
Compressor	Type	Inverter scroll hermetic compressor	
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method	Inverter	
	Motor output	kW	13.0
	Case heater	kW	-
	Lubricant	MEL32	
External finish			Galvanized steel sheets
External dimension H x W x D		mm	1,450 x 880 x 550
		in.	57-1/8 x 34-11/16 x 21-11/16
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection
	Compressor		Over-heat protection
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)
	Control		Indoor LEV and BC controller
Net weight	kg (lbs)	216 (477)	
Heat exchanger			plate type
	Water volume in plate	l	5.0
	Water pressure Max.	MPa	2.0
HIC circuit (HIC: Heat Inter-Changer)			-
Drawing	External		WKS94C744
	Wiring		WKE94G131
Standard attachment	Document		Installation Manual
	Accessory		Refrigerant conn. pipe
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>		

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412 cfm =m ³ /min x 35.31 lbs =kg/0.4536
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

Model			PQRY-P550YLM-A			
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1	kW	63.0			
		kcal/h	55,000			
		BTU/h	215,000			
	Power input	kW	12.54			
		Current input	A	21.1-20.1-19.3		
EER		kW/kW	5.02			
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Heating capacity (Nominal)	*2	kW	69.0			
		kcal/h	60,000			
		BTU/h	235,400			
	Power input	kW	12.27			
		Current input	A	20.7-19.6-18.9		
COP		kW/kW	5.62			
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)			
	Circulating water	°C	10.0~45.0°C (50~113°F)			
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity				
	Model/Quantity	P15~P250/2~50				
Sound pressure level (measured in anechoic room)		dB <A>	56.5			
Sound power level (measured in anechoic room)		dB <A>	71.5			
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed (28.58 (1-1/8) Brazed for the part that exceeds 65 m)			
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed			
Circulating water	Water flow rate	m ³ /h	11.52			
		L/min	192			
		cfm	6.8			
	Pressure drop	kPa	45			
	Operating volume range	m ³ /h	6.0 ~ 14.4			
Compressor	Type	Inverter scroll hermetic compressor				
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION				
	Starting method	Inverter				
	Motor output	kW	15.0			
	Case heater	kW	0.045 (240 V)			
	Lubricant	MEL32				
External finish		Galvanized steel sheets				
External dimension H x W x D		mm	1,450 x 880 x 550			
		in.	57-1/8 x 34-11/16 x 21-11/16			
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)				
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection				
	Compressor	Over-heat protection				
Refrigerant	Type x original charge	R410A x 11.7 kg (26 lbs)				
	Control	Indoor LEV and BC controller				
Net weight		kg (lbs)	246 (543)			
Heat exchanger		plate type				
		Water volume in plate	l	10.0		
		Water pressure Max.	MPa	2.0		
HIC circuit (HIC: Heat Inter-Changer)		-				
Drawing	External	WKS94C745				
	Wiring	WKE94G131				
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts		Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1				
Remarks		<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p> <p>When the high pressure piping length is 65 m or less, use 22.2 (7/8) pipe. When the high pressure piping length exceeds 65 m, use 22.2 (7/8) pipe until 65 m, use 28.58 (1-1/8) pipe for the part that exceeds 65 m.</p>				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P600YLM-A
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz
Cooling capacity (Nominal)	*1	kW	69.0
		kcal/h	60,000
		BTU/h	235,400
	Power input	kW	14.49
		Current input	A
EER		kW/kW	4.76
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Heating capacity (Nominal)	*2	kW	76.5
		kcal/h	65,800
		BTU/h	261,000
	Power input	kW	14.51
		Current input	A
COP		kW/kW	5.27
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)
	Circulating water	°C	10.0~45.0°C (50~113°F)
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity
	Model/Quantity		P15~P250/2~50
Sound pressure level (measured in anechoic room)		dB <A>	56.5
Sound power level (measured in anechoic room)		dB <A>	73
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed (28.58 (1-1/8) Brazed for the part that exceeds 65 m)
	Low pressure	mm (in.)	34.93 (1-3/8) Brazed
Circulating water	Water flow rate	m ³ /h	11.52
		L/min	192
		cfm	6.8
	Pressure drop	kPa	45
	Operating volume range	m ³ /h	6.0 ~ 14.4
Compressor	Type		Inverter scroll hermetic compressor
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION
	Starting method		Inverter
	Motor output	kW	16.1
	Case heater	kW	0.045 (240 V)
	Lubricant		MEL32
External finish			Galvanized steel sheets
External dimension H x W x D		mm	1,450 x 880 x 550
		in.	57-1/8 x 34-11/16 x 21-11/16
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection
	Compressor		Over-heat protection
Refrigerant	Type x original charge		R410A x 11.7 kg (26 lbs)
	Control		Indoor LEV and BC controller
Net weight		kg (lbs)	246 (543)
Heat exchanger			plate type
	Water volume in plate	l	10.0
	Water pressure Max.	MPa	2.0
HIC circuit (HIC: Heat Inter-Changer)			-
Drawing	External		WKS94C745
	Wiring		WKE94G131
Standard attachment	Document		Installation Manual
	Accessory		Refrigerant conn. pipe
Optional parts			Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p> <p>When the high pressure piping length is 65 m or less, use 22.2 (7/8) pipe. When the high pressure piping length exceeds 65 m, use 22.2 (7/8) pipe until 65 m, use 28.58 (1-1/8) pipe for the part that exceeds 65 m.</p>		

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

W/R2

Model			PQRY-P400YSLM-A	
Power source	3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1 kW	45.0		
	kcal/h	40,000		
	*1 BTU/h	153,500		
	Power input kW	7.70		
	Current input A	12.9-12.3-11.9		
Temp. range of cooling	EER kW/kW	5.84		
	Indoor W.B.	15.0~24.0°C (59~75°F)		
Heating capacity (Nominal)	Circulating water °C	10.0~45.0°C (50~113°F)		
	*2 kW	50.0		
	kcal/h	45,000		
	*2 BTU/h	170,600		
	Power input kW	7.94		
	Current input A	13.4-12.7-12.2		
	COP kW/kW	6.29		
Temp. range of heating	Indoor D.B.	15.0~27.0°C (59~81°F)		
	Circulating water °C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity		
	Model/Quantity	P15~P250/1~40		
Sound pressure level (measured in anechoic room)	dB <A>	49		
Sound power level (measured in anechoic room)	dB <A>	63		
Refrigerant piping diameter	High pressure mm (in.)	22.2 (7/8) Brazed		
	Low pressure mm (in.)	28.58 (1-1/8) Brazed		

Set Model			PQRY-P200YLM-A		PQRY-P200YLM-A	
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76		96 + 96	
		L/min	3.4 + 3.4		3.4 + 3.4	
		cfm	24		24	
	Pressure drop	kPa	3.0 + 3.0 ~ 7.2 + 7.2		3.0 + 3.0 ~ 7.2 + 7.2	
	Operating volume range	m ³ /h	Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
Compressor	Type	AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Manufacture	Inverter		Inverter		
	Starting method	4.8		4.8		
	Motor output kW	-		-		
	Case heater kW	MEL32		MEL32		
External finish	Galvanized steel sheets		Galvanized steel sheets		Galvanized steel sheets	
	External dimension H x W x D	mm	1,100 x 880 x 550		1,100 x 880 x 550	
in.		43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection		Over-heat protection, Over-current protection		
	Compressor	Over-heat protection		Over-heat protection		
Refrigerant	Type x original charge	R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)		
	Control	Indoor LEV and BC controller				
Net weight	kg (lbs)	172 (380)		172 (380)		
Heat exchanger	plate type		plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)	-					
Pipe between unit and distributor	High pressure	mm (in.)	15.88 (5/8) Brazed		15.88 (5/8) Brazed	
	Low pressure	mm (in.)	19.05 (3/4) Brazed		19.05 (3/4) Brazed	
Drawing	External	WKS94C749				
	Wiring	WKE94G131		WKE94G131		
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts	Heat Source Twinning kit: CMY-Q100CBK2 Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1					
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>					

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P450YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	50.0		
		kcal/h	45,000		
		BTU/h	170,600		
	Power input	kW	8.78		
		Current input	A	14.8-14.0-13.5	
EER		kW/kW	5.69		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	56.0		
		kcal/h	50,000		
		BTU/h	191,100		
	Power input	kW	8.97		
		Current input	A	15.1-14.3-13.8	
COP		kW/kW	6.24		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity		
	Model/Quantity		P15~P250/1~45		
Sound pressure level (measured in anechoic room)		dB <A>	50		
Sound power level (measured in anechoic room)		dB <A>	64		
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed		
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed		

Set Model			PQRY-P250YLM-A			PQRY-P200YLM-A		
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76					
		L/min	96 + 96					
		cfm	3.4 + 3.4					
	Pressure drop	kPa	24			24		
Operating volume range		m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2					
Compressor	Type		Inverter scroll hermetic compressor			Inverter scroll hermetic compressor		
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION			AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method		Inverter			Inverter		
	Motor output	kW	6.2			4.8		
	Case heater	kW	-			-		
Lubricant		MEL32			MEL32			
External finish		Galvanized steel sheets			Galvanized steel sheets			
External dimension H x W x D		mm	1,100 x 880 x 550			1,100 x 880 x 550		
		in.	43-5/16 x 34-11/16 x 21-11/16			43-5/16 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection			Over-heat protection, Over-current protection		
	Compressor		Over-heat protection			Over-heat protection		
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)			R410A x 5.0 kg (12 lbs)		
	Control		Indoor LEV and BC controller					
Net weight		kg (lbs)	172 (380)			172 (380)		
Heat exchanger			plate type			plate type		
	Water volume in plate	l	5.0			5.0		
	Water pressure Max.	MPa	2.0			2.0		
HIC circuit (HIC: Heat Inter-Changer)		-			-			
Pipe between unit and distributor	High pressure	mm (in.)	19.05 (3/4) Brazed			19.05 (3/4) Brazed		
	Low pressure	mm (in.)	22.2 (7/8) Brazed			22.2 (7/8) Brazed		
Drawing	External		WKS94C749					
	Wiring		WKE94G131			WKE94G131		
Standard attachment	Document		Installation Manual					
	Accessory		Refrigerant conn. pipe					
Optional parts		Heat Source Twinning kit: CMY-Q100CBK2 Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1						
Remarks		<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>						

Notes:	1.Nominal cooling conditions (subject to JIS B8615-2)		Unit converter	
	Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F)		BTU/h	=kW x 3.412
	Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		cfm	=m ³ /min x 35.31
	2.Nominal heating conditions (subject to JIS B8615-2)		lbs	=kg/0.4536
Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.)				
Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)				
*Above specification data is subject to rounding variation.				

1. SPECIFICATIONS

W/R2

Model			PQRY-P500YSLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	56.0	
		kcal/h	50,000	
		BTU/h	191,100	
	Power input	kW	10.12	
		A	17.0-16.2-15.6	
EER		5.53		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	63.0	
		kcal/h	55,000	
		BTU/h	215,000	
	Power input	kW	10.16	
		A	17.1-16.2-15.7	
COP		6.20		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity	
	Model/Quantity		P15~P250/1~50	
Sound pressure level (measured in anechoic room)		dB <A>	51	
Sound power level (measured in anechoic room)		dB <A>	65	
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed	
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed	

Set Model			PQRY-P250YLM-A		PQRY-P250YLM-A	
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76		96 + 96	
		L/min	3.4 + 3.4		3.4 + 3.4	
		cfm	24		24	
	Pressure drop	kPa	3.0 + 3.0 ~ 7.2 + 7.2		24	
Operating volume range		m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2		3.0 + 3.0 ~ 7.2 + 7.2	
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter		Inverter	
	Motor output	kW	6.2		6.2	
	Case heater	kW	-		-	
	Lubricant		MEL32		MEL32	
External finish			Galvanized steel sheets		Galvanized steel sheets	
External dimension H x W x D		mm	1,100 x 880 x 550		1,100 x 880 x 550	
		in.	43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge		R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)	
	Control		Indoor LEV and BC controller			
Net weight		kg (lbs)	172 (380)		172 (380)	
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)			-		-	
Pipe between unit and distributor	High pressure	mm (in.)	19.05 (3/4) Brazed		19.05 (3/4) Brazed	
	Low pressure	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed	
Drawing	External		WKS94C749			
	Wiring		WKE94G131		WKE94G131	
Standard attachment	Document		Installation Manual			
	Accessory		Refrigerant conn. pipe			
Optional parts			Heat Source Twinning kit: CMY-Q100CBK2 Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1			
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>			

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WR2

Model			PQRY-P550YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	63.0		
		kcal/h	55,000		
		BTU/h	215,000		
	Power input	kW	11.55		
		A	19.4-18.5-17.8		
EER	kW/kW	5.45			
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	69.0		
		kcal/h	60,000		
		BTU/h	235,400		
	Power input	kW	11.31		
		A	19.0-18.1-17.4		
COP	kW/kW	6.10			
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity		
	Model/Quantity		P15~P250/2~50		
Sound pressure level (measured in anechoic room)		dB <A>	55		
Sound power level (measured in anechoic room)		dB <A>	69		
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed (28.58 (1-1/8) Brazed for the part that exceeds 65 m)		
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed		

Set Model			PQRY-P300YLM-A			PQRY-P250YLM-A		
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76					
		L/min	96 + 96					
		cfm	3.4 + 3.4					
	Pressure drop	kPa	24		24			
Operating volume range	m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2						
Compressor	Type	Inverter scroll hermetic compressor			Inverter scroll hermetic compressor			
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION			AC&R Works, MITSUBISHI ELECTRIC CORPORATION			
	Starting method	Inverter			Inverter			
	Motor output	kW	7.7		6.2			
	Case heater	kW	-		-			
	Lubricant		MEL32			MEL32		
External finish			Galvanized steel sheets			Galvanized steel sheets		
External dimension H x W x D	mm		1,100 x 880 x 550		1,100 x 880 x 550			
	in.		43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16			
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection			Over-heat protection, Over-current protection			
	Compressor	Over-heat protection			Over-heat protection			
Refrigerant	Type x original charge	R410A x 5.0 kg (12 lbs)			R410A x 5.0 kg (12 lbs)			
	Control	Indoor LEV and BC controller						
Net weight	kg (lbs)	172 (380)		172 (380)				
Heat exchanger			plate type			plate type		
	Water volume in plate	l	5.0		5.0			
	Water pressure Max.	MPa	2.0		2.0			
HIC circuit (HIC: Heat Inter-Changer)			-			-		
Pipe between unit and distributor	High pressure	mm (in.)	19.05 (3/4) Brazed		19.05 (3/4) Brazed			
	Low pressure	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed			
Drawing	External	WKS94C749						
	Wiring	WKE94G131		WKE94G131				
Standard attachment	Document	Installation Manual						
	Accessory	Refrigerant conn. pipe						
Optional parts			Heat Source Twinning kit: CMY-Q100CBK2 Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1					
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p> <p>When the high pressure piping length is 65 m or less, use 22.2 (7/8) pipe. When the high pressure piping length exceeds 65 m, use 22.2 (7/8) pipe until 65 m, use 28.58 (1-1/8) pipe for the part that exceeds 65 m.</p>					

Notes:		Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		cfm =m ³ /min x 35.31
		lbs =kg/0.4536
		*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

W/R2

Model			PQRY-P600YSLM-A	
Power source	3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1 kW	69.0		
	kcal/h	60,000		
	*1 BTU/h	235,400		
	Power input kW	12.84		
	Current input A	21.6-20.5-19.8		
EER	kW/kW			5.37
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2 kW	76.5		
	kcal/h	65,800		
	*2 BTU/h	261,000		
	Power input kW	12.75		
	Current input A	21.5-20.4-19.7		
COP	kW/kW			6.00
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity		
	Model/Quantity	P15~P250/2~50		
Sound pressure level (measured in anechoic room)	dB <A>	57		
Sound power level (measured in anechoic room)	dB <A>	71		
Refrigerant piping diameter	High pressure	mm (in.)	22.2 (7/8) Brazed (28.58 (1-1/8) Brazed for the part that exceeds 65 m)	
	Low pressure	mm (in.)	34.93 (1-3/8) Brazed	

Set Model			PQRY-P300YLM-A		PQRY-P300YLM-A	
Circulating water	Water flow rate	m ³ /h	5.76 + 5.76		96 + 96	
		L/min	3.4 + 3.4		3.4 + 3.4	
		cfm	24		24	
	Pressure drop	kPa	3.0 + 3.0 ~ 7.2 + 7.2		3.0 + 3.0 ~ 7.2 + 7.2	
Operating volume range	m ³ /h	3.0 + 3.0 ~ 7.2 + 7.2		3.0 + 3.0 ~ 7.2 + 7.2		
Compressor	Type	Inverter scroll hermetic compressor		Inverter scroll hermetic compressor		
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method	Inverter		Inverter		
	Motor output	kW	7.7		7.7	
	Case heater	kW	-		-	
	Lubricant	MEL32		MEL32		
External finish	Galvanized steel sheets		Galvanized steel sheets			
External dimension H x W x D	mm	1,100 x 880 x 550		1,100 x 880 x 550		
	in.	43-5/16 x 34-11/16 x 21-11/16		43-5/16 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection		Over-heat protection, Over-current protection		
	Compressor	Over-heat protection		Over-heat protection		
Refrigerant	Type x original charge	R410A x 5.0 kg (12 lbs)		R410A x 5.0 kg (12 lbs)		
	Control	Indoor LEV and BC controller				
Net weight	kg (lbs)	172 (380)		172 (380)		
Heat exchanger	Water volume in plate	plate type		plate type		
	Water pressure Max.	MPa	5.0		5.0	
HIC circuit (HIC: Heat Inter-Changer)		2.0		2.0		
Pipe between unit and distributor	High pressure	mm (in.)	19.05 (3/4) Brazed		19.05 (3/4) Brazed	
	Low pressure	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed	
Drawing	External	WKS94C749				
	Wiring	WKE94G131		WKE94G131		
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts	Heat Source Twinning kit: CMY-Q100CBK2 Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P108, 1010, 1013, 1016V-GA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1					
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p> <p>When the high pressure piping length is 65 m or less, use 22.2 (7/8) pipe. When the high pressure piping length exceeds 65 m, use 22.2 (7/8) pipe until 65 m, use 28.58 (1-1/8) pipe for the part that exceeds 65 m.</p>					

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P700YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	80.0		
		kcal/h	68,800		
		BTU/h	273,000		
	Power input	kW	14.73		
		A	24.8-23.6-22.7		
EER	kW/kW	5.43			
	Indoor	W.B.	15.0~24.0°C (59~75°F)		
Temp. range of cooling	Circulating water	°C	10.0~45.0°C (50~113°F)		
	Heating capacity (Nominal)	*2	kW	88.0	
kcal/h			75,700		
BTU/h			300,300		
Power input		kW	14.73		
		A	24.8-23.6-22.7		
COP	kW/kW	5.97			
	Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
Circulating water		°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity		
	Model/Quantity		P15~P250/2~50		
Sound pressure level (measured in anechoic room)		dB <A>	55		
Sound power level (measured in anechoic room)		dB <A>	69		
Refrigerant piping diameter	High pressure	mm (in.)	28.58 (1-1/8) Brazed		
	Low pressure	mm (in.)	34.93 (1-3/8) Brazed		

Set Model			PQRY-P350YLM-A			PQRY-P350YLM-A		
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20					
		L/min	120 + 120					
		cfm	4.2 + 4.2					
	Pressure drop	kPa	44			44		
Operating volume range		m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6					
Compressor	Type		Inverter scroll hermetic compressor			Inverter scroll hermetic compressor		
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION			AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method		Inverter			Inverter		
	Motor output	kW	9.5			9.5		
	Case heater	kW	-			-		
	Lubricant		MEL32			MEL32		
External finish			Galvanized steel sheets			Galvanized steel sheets		
External dimension H x W x D		mm	1,450 x 880 x 550			1,450 x 880 x 550		
		in.	57-1/8 x 34-11/16 x 21-11/16			57-1/8 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection			Over-heat protection, Over-current protection		
	Compressor		Over-heat protection			Over-heat protection		
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)			R410A x 6.0 kg (14 lbs)		
	Control		Indoor LEV and BC controller					
Net weight		kg (lbs)	216 (477)			216 (477)		
Heat exchanger			plate type			plate type		
	Water volume in plate	l	5.0			5.0		
	Water pressure Max.	MPa	2.0			2.0		
HIC circuit (HIC: Heat Inter-Changer)			-			-		
Pipe between unit and distributor	High pressure	mm (in.)	22.2 (7/8) Brazed			22.2 (7/8) Brazed		
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed			28.58 (1-1/8) Brazed		
Drawing	External		WKS94C750			WKS94C750		
	Wiring		WKE94G131			WKE94G131		
Standard attachment	Document		Installation Manual					
	Accessory		Refrigerant conn. pipe					
Optional parts			Heat Source Twinning kit: CMY-Q200CBK Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P1016V-HA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1					
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>					

Notes:		Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		cfm =m ³ /min x 35.31
		lbs =kg/0.4536
		*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

W/R2

Model			PQRY-P750YSLM-A	
Power source	3-phase 4-wire 380-400-415 V 50/60 Hz			
Cooling capacity (Nominal)	*1 kW	85.0		
	kcal/h	73,100		
	*1 BTU/h	290,000		
	Power input kW	15.64		
	Current input A	26.4-25.0-24.1		
EER	kW/kW			5.43
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2 kW	95.0		
	kcal/h	81,700		
	*2 BTU/h	324,100		
	Power input kW	15.90		
	Current input A	26.8-25.4-24.5		
COP	kW/kW			5.97
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity		
	Model/Quantity	P15~P250/2~50		
Sound pressure level (measured in anechoic room)	dB <A>	55		
Sound power level (measured in anechoic room)	dB <A>	69		
Refrigerant piping diameter	High pressure	mm (in.)	28.58 (1-1/8) Brazed	
	Low pressure	mm (in.)	34.93 (1-3/8) Brazed	

Set Model			PQRY-P400YLM-A		PQRY-P350YLM-A	
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20			
		L/min	120 + 120			
		cfm	4.2 + 4.2			
	Pressure drop	kPa	44		44	
Operating volume range	m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6				
Compressor	Type	Inverter scroll hermetic compressor		Inverter scroll hermetic compressor		
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		
	Starting method	Inverter		Inverter		
	Motor output	kW	10.7		9.5	
	Case heater	kW	-		-	
	Lubricant	MEL32		MEL32		
External finish	Galvanized steel sheets		Galvanized steel sheets			
External dimension H x W x D	mm	1,450 x 880 x 550		1,450 x 880 x 550		
	in.	57-1/8 x 34-11/16 x 21-11/16		57-1/8 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection		Over-heat protection, Over-current protection		
	Compressor	Over-heat protection		Over-heat protection		
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)		R410A x 6.0 kg (14 lbs)		
	Control	Indoor LEV and BC controller				
Net weight	kg (lbs)	216 (477)		216 (477)		
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)						
Pipe between unit and distributor	High pressure	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed	
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed		28.58 (1-1/8) Brazed	
Drawing	External	WKS94C750				
	Wiring	WKE94G131		WKE94G131		
Standard attachment	Document	Installation Manual				
	Accessory	Refrigerant conn. pipe				
Optional parts	Heat Source Twinning kit: CMY-Q200CBK Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P1016V-HA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1					
Remarks	<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>					

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

HEAT SOURCE

WR2

Model			PQRY-P800YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	90.0		
		kcal/h	77,400		
		BTU/h	307,100		
	Power input	kW	16.57		
		Current input	A	27.9-26.5-25.6	
EER		kW/kW	5.43		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	100.0		
		kcal/h	86,000		
		BTU/h	341,200		
	Power input	kW	16.75		
		Current input	A	28.2-26.8-25.8	
COP		kW/kW	5.97		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity	50~150% of heat source unit capacity			
	Model/Quantity	P15~P250/2~50			
Sound pressure level (measured in anechoic room)		dB <A>	55		
Sound power level (measured in anechoic room)		dB <A>	69		
Refrigerant piping diameter	High pressure	mm (in.)	28.58 (1-1/8) Brazed		
	Low pressure	mm (in.)	34.93 (1-3/8) Brazed		

Set Model			PQRY-P400YLM-A			PQRY-P400YLM-A		
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20					
		L/min	120 + 120					
		cfm	4.2 + 4.2					
	Pressure drop	kPa	44			44		
	Operating volume range	m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6					
Compressor	Type	Inverter scroll hermetic compressor			Inverter scroll hermetic compressor			
	Manufacture	AC&R Works, MITSUBISHI ELECTRIC CORPORATION			AC&R Works, MITSUBISHI ELECTRIC CORPORATION			
	Starting method	Inverter			Inverter			
	Motor output	kW	10.7			10.7		
	Case heater	kW	-			-		
	Lubricant	MEL32			MEL32			
External finish			Galvanized steel sheets			Galvanized steel sheets		
External dimension H x W x D			1,450 x 880 x 550			1,450 x 880 x 550		
			57-1/8 x 34-11/16 x 21-11/16			57-1/8 x 34-11/16 x 21-11/16		
Protection devices	High pressure protection	High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			
	Inverter circuit (COMP.)	Over-heat protection, Over-current protection			Over-heat protection, Over-current protection			
	Compressor	Over-heat protection			Over-heat protection			
Refrigerant	Type x original charge	R410A x 6.0 kg (14 lbs)			R410A x 6.0 kg (14 lbs)			
	Control	Indoor LEV and BC controller						
Net weight		kg (lbs)	216 (477)			216 (477)		
Heat exchanger			plate type			plate type		
	Water volume in plate	l	5.0			5.0		
	Water pressure Max.	MPa	2.0			2.0		
HIC circuit (HIC: Heat Inter-Changer)			-			-		
Pipe between unit and distributor	High pressure	mm (in.)	22.2 (7/8) Brazed			22.2 (7/8) Brazed		
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed			28.58 (1-1/8) Brazed		
Drawing	External	WKS94C750						
	Wiring	WKE94G131			WKE94G131			
Standard attachment	Document	Installation Manual						
	Accessory	Refrigerant conn. pipe						
Optional parts			Heat Source Twinning kit: CMY-Q200CBK Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P1016V-HA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1					
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>					

Notes:		Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		cfm =m ³ /min x 35.31
		lbs =kg/0.4536
		*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

W/R2

Model			PQRY-P850YSLM-A	
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz	
Cooling capacity (Nominal)	*1	kW	96.0	
		kcal/h	82,600	
		BTU/h	327,600	
	Power input	kW	18.03	
		A	30.4-28.9-27.8	
EER		5.32		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Heating capacity (Nominal)	*2	kW	108.0	
		kcal/h	92,900	
		BTU/h	368,500	
	Power input	kW	18.49	
		A	31.2-29.6-28.5	
COP		5.84		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)	
	Circulating water	°C	10.0~45.0°C (50~113°F)	
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity	
	Model/Quantity		P15~P250/2~50	
Sound pressure level (measured in anechoic room)		dB <A>	56	
Sound power level (measured in anechoic room)		dB <A>	71.5	
Refrigerant piping diameter	High pressure	mm (in.)	28.58 (1-1/8) Brazed	
	Low pressure	mm (in.)	41.28 (1-5/8) Brazed	

Set Model			PQRY-P450YLM-A		PQRY-P400YLM-A	
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20			
		L/min	120 + 120			
		cfm	4.2 + 4.2			
	Pressure drop	kPa	44		44	
Operating volume range		m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6			
Compressor	Type		Inverter scroll hermetic compressor		Inverter scroll hermetic compressor	
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION		AC&R Works, MITSUBISHI ELECTRIC CORPORATION	
	Starting method		Inverter		Inverter	
	Motor output	kW	11.6		10.7	
	Case heater	kW	-		-	
Lubricant		MEL32		MEL32		
External finish		Galvanized steel sheets		Galvanized steel sheets		
External dimension H x W x D	mm		1,450 x 880 x 550		1,450 x 880 x 550	
	in.		57-1/8 x 34-11/16 x 21-11/16		57-1/8 x 34-11/16 x 21-11/16	
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)	
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection		Over-heat protection, Over-current protection	
	Compressor		Over-heat protection		Over-heat protection	
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)		R410A x 6.0 kg (14 lbs)	
	Control		Indoor LEV and BC controller			
Net weight		kg (lbs)	216 (477)		216 (477)	
Heat exchanger			plate type		plate type	
	Water volume in plate	l	5.0		5.0	
	Water pressure Max.	MPa	2.0		2.0	
HIC circuit (HIC: Heat Inter-Changer)						
Pipe between unit and distributor	High pressure	mm (in.)	22.2 (7/8) Brazed		22.2 (7/8) Brazed	
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed		28.58 (1-1/8) Brazed	
Drawing	External		WKS94C750			
	Wiring		WKE94G131		WKE94G131	
Standard attachment	Document		Installation Manual			
	Accessory		Refrigerant conn. pipe			
Optional parts		Heat Source Twinning kit: CMY-Q200CBK Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P1016V-HA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1				
Remarks		<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>				

Notes:	Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)	cfm =m ³ /min x 35.31
	lbs =kg/0.4536
	*Above specification data is subject to rounding variation.

1. SPECIFICATIONS

WR2

Model			PQRY-P900YSLM-A		
Power source			3-phase 4-wire 380-400-415 V 50/60 Hz		
Cooling capacity (Nominal)	*1	kW	101.0		
		kcal/h	86,900		
		BTU/h	344,600		
	Power input	kW	19.38		
		Current input	A	32.7-31.0-29.9	
EER		kW/kW	5.21		
Temp. range of cooling	Indoor	W.B.	15.0~24.0°C (59~75°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Heating capacity (Nominal)	*2	kW	113.0		
		kcal/h	97,200		
		BTU/h	385,600		
	Power input	kW	19.74		
		Current input	A	33.3-31.6-30.5	
COP		kW/kW	5.72		
Temp. range of heating	Indoor	D.B.	15.0~27.0°C (59~81°F)		
	Circulating water	°C	10.0~45.0°C (50~113°F)		
Indoor unit connectable	Total capacity		50~150% of heat source unit capacity		
	Model/Quantity		P15~P250/2~50		
Sound pressure level (measured in anechoic room)		dB <A>	57		
Sound power level (measured in anechoic room)		dB <A>	73		
Refrigerant piping diameter	High pressure	mm (in.)	28.58 (1-1/8) Brazed		
	Low pressure	mm (in.)	41.28 (1-5/8) Brazed		

Set Model			PQRY-P450YLM-A			PQRY-P450YLM-A			
Circulating water	Water flow rate	m ³ /h	7.20 + 7.20						
		L/min	120 + 120						
		cfm	4.2 + 4.2						
	Pressure drop	kPa	44			44			
Operating volume range		m ³ /h	4.5 + 4.5 ~ 11.6 + 11.6						
Compressor	Type		Inverter scroll hermetic compressor			Inverter scroll hermetic compressor			
	Manufacture		AC&R Works, MITSUBISHI ELECTRIC CORPORATION			AC&R Works, MITSUBISHI ELECTRIC CORPORATION			
	Starting method		Inverter			Inverter			
	Motor output	kW	11.6			11.6			
	Case heater	kW	-			-			
	Lubricant		MEL32			MEL32			
External finish			Galvanized steel sheets			Galvanized steel sheets			
External dimension H x W x D		mm	1,450 x 880 x 550			1,450 x 880 x 550			
		in.	57-1/8 x 34-11/16 x 21-11/16			57-1/8 x 34-11/16 x 21-11/16			
Protection devices	High pressure protection		High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			High pressure sensor, High pressure switch at 4.15 MPa (601 psi)			
	Inverter circuit (COMP.)		Over-heat protection, Over-current protection			Over-heat protection, Over-current protection			
	Compressor		Over-heat protection			Over-heat protection			
Refrigerant	Type x original charge		R410A x 6.0 kg (14 lbs)			R410A x 6.0 kg (14 lbs)			
	Control		Indoor LEV and BC controller						
Net weight		kg (lbs)	216 (477)			216 (477)			
Heat exchanger			plate type			plate type			
			Water volume in plate	l	5.0			5.0	
		Water pressure Max.	MPa	2.0			2.0		
HIC circuit (HIC: Heat Inter-Changer)			-						
Pipe between unit and distributor	High pressure	mm (in.)	22.2 (7/8) Brazed			22.2 (7/8) Brazed			
	Low pressure	mm (in.)	28.58 (1-1/8) Brazed			28.58 (1-1/8) Brazed			
Drawing	External		WKS94C750			WKS94C750			
	Wiring		WKE94G131			WKE94G131			
Standard attachment	Document		Installation Manual						
	Accessory		Refrigerant conn. pipe						
Optional parts			Heat Source Twinning kit: CMY-Q200CBK Joint: CMY-Y102SS/LS-G2, CMY-R160-J1 Main BC controller: CMB-P1016V-HA1 Sub BC controller: CMB-P104, 108V-GB1, CMB-P1016V-HB1						
Remarks			<p>Details on foundation work, duct work, insulation work, electrical wiring, power source switch, and other items shall be referred to the Installation Manual.</p> <p>Due to continuing improvement, above specifications may be subject to change without notice.</p> <p>The ambient temperature of the heat source unit needs to be kept below 40°C D.B.</p> <p>The ambient relative humidity of the heat source unit needs to be kept below 80%.</p> <p>The heat source unit should not be installed at outdoor.</p> <p>Be sure to mount a strainer (more than 50 meshes) at the water inlet piping of the unit.</p> <p>Be sure to provide interlocking for the unit operation and water circuit.</p> <p>The heat source twinning kit (low pressure) should be connected to the low pressure side of the heat source unit.</p> <p>Install the supplied insulation material to the unused drain-socket.</p> <p>When installing insulation material around both water and refrigerant piping, follow the installation manual.</p>						


Notes:		Unit converter
1.Nominal cooling conditions (subject to JIS B8615-2) Indoor: 27°C D.B./19°C W.B. (81°F D.B./66°F W.B.), Water temperature: 30°C (86°F) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		BTU/h =kW x 3,412
2.Nominal heating conditions (subject to JIS B8615-2) Indoor: 20°C D.B. (68°F D.B.), Water temperature: 20°C (68°F D.B.) Pipe length: 7.5 m (24-9/16 ft.), Level difference: 0 m (0 ft.)		cfm =m ³ /min x 35.31
		lbs =kg/0.4536
		*Above specification data is subject to rounding variation.

PQRY-P200, 250, 300YLM-A


Unit: mm

- <Accessories>
- Refrigerant (high pressure) conn. pipe.....1pc.
(P200/P250/P300 ; Packaged in the accessory kit)
 - Refrigerant (low pressure) conn. elbow.....1pc.
(P200/P250/P300 ; Packaged in the accessory kit)
 - Water stopper.....1pc.
(P200/P250/P300 ; Packaged in the accessory kit)
 - Sealing material for water stopper.....1pc.
(P200/P250/P300 ; Packaged in the accessory kit)
 - Sealing material for field piping (high pressure, low pressure).....1pc. each
(P200/P250/P300 ; Packaged in the accessory kit)
 - Sealing material for drain socket.....1pc.
(P200/P250/P300 ; Packaged in the accessory kit)
 - Pipe cover for low pressure.....1pc.
(P200/P250/P300 ; Packaged in the accessory kit)

- Note1. Close a hole of the water piping, the refrigerant piping, the power supply, and the control wiring and unused knockout holes with the putty etc. so as not to infiltrate rain water etc.(field erection work)
- Note2. At the time of product shipment, the front side piping specification serves as the local drainage connection. When connecting on the rear side, please remove the rear side plug sealing corks, and attach a front side. Ensure there is no leak after the attachment has been fitted.
- Note3. Take notice of service space as Fig. A. (In case of single installation, 600mm or more of back space as front space makes easier access when servicing the unit from rear side.)
- Note4. If water pipes or refrigerant pipes stretch upward, required space for service and maintenance due to replacement of control box is shown in Fig.B.
- Note5. Environmental condition for installation: -20~40°C(DB) as indoor installation.
- Note6. In case the temperature around the heat source unit has possibility to drop under 0°C, be careful for the following point to prevent the pipe burst by the water pipe freeze-up.
- Circulate the water all the time even if the heat source unit is not in operation.
 - Drain the water from inside of the heat source unit when the heat source unit will not operate for a long term.
- Note7. Ensure that the drain piping is downward with a pitch of more than 1/100.
- Note8. At brazing of pipes, wrap the refrigerant service valve with wet cloth and keep the temperature of refrigerant service valve under 120°C.



NO.	Usage	Specifications
①	Front through hole	140 x 77 Knockout hole
②	Front through hole (Uses when twinning kit (optional parts) is mounted.)	ø45 Knockout hole
③	Front through hole	ø65 or ø40 Knockout hole
④	Front through hole	ø52 or ø27 Knockout hole
⑤	For transmission cables	Front through hole ø34 Knockout hole
⑥	Water pipe inlet	Rc1-1/2 Screw
⑦	Water pipe outlet	Rc1-1/2 Screw
⑧	Drain pipe	Rc3/4 Screw



Connecting pipe specifications

Model	Refrigerant pipe		Service valve	
	High pressure	Low pressure	High pressure	Low pressure
PQRY-P200YLM-A	ø15.88 Brazed *1 *2	ø19.05 Brazed *1 *2	ø19.05	ø25.4
PQRY-P250YLM-A	ø19.05 Brazed *1	ø22.2 Brazed *1 *2		
PQRY-P300YLM-A				


*1. Connect by using the connecting pipes and elbow that are supplied.
*2. Use the pipe joint(field supply) and connect to the refrigerant service valve piping.

PQRY-P350, 400, 450, 500YLM-A


Unit: mm

WR2

- <Accessories>
- Refrigerant (high pressure) conn. pipe 1pc.
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Refrigerant (low pressure) conn. pipe 1pc.
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Water stopper 1pc.
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for water stopper 1pc.
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for field piping (high pressure, low pressure) 1pc. each
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for drain socket 1pc.
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Pipe cover for low pressure 1pc.
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for base leg (two types) 4pcs each
(P350/P400/P450/P500 ; Packaged in the accessory kit)
 - Sealing material for panel 1pc.
(P350/P400/P450/P500 ; Packaged in the accessory kit)




Top view




Right side view

Back view



Front view



Bottom view

Note1. Close a hole of the water piping, the refrigerant piping, the power supply, and the control wiring and unused knockout holes with the putty etc. so as not to infiltrate rain water etc.(field erection work)

Note2. At the time of product shipment, the front side piping specification serves as the local drainage connection. When connecting on the rear side, please remove the rear side plug sealing corks, and attach a front side.

Note3. Ensure there is no leak after the attachment has been fitted. Note3. Take notice of service space as Fig.A. (In case of single installation, 600mm or more of back space as front side.)

Note4. If water pipes or refrigerant pipes stretch upward, makes easier access when servicing the unit from rear side.) required space for service and maintenance due to replacement of control box is shown in Fig.B.

Note5. Environmental condition for installation: -20~40°C(DB) as indoor installation.


Note6. In case the temperature around the heat source unit has possibility to drop under 0°C, be careful for the following point to prevent the pipe burst by the water pipe freeze-up.

- Circulate the water all the time even if the heat source unit is not in operation.

- Drain the water from inside of the heat source unit when the heat source unit will not operate for a long term.

Note7. Ensure that the drain piping is downward with a pitch of more than 1/100.

Note8. At brazing of pipes, wrap the refrigerant service valve with wet cloth and keep the temperature of refrigerant service valve under 120°C.



Connecting pipe specifications

Model	Refrigerant pipe		Service valve		Diameter
	High pressure	Low pressure	High pressure	Low pressure	
PQRY-P350YLM-A	ø22.2 Brazed	ø28.58	ø25.4	ø28.58	*1
PQRY-P400YLM-A	ø22.2 Brazed	ø28.58	ø25.4	ø28.58	
PQRY-P450YLM-A	ø22.2 Brazed	ø28.58	ø25.4	ø28.58	
PQRY-P500YLM-A	ø22.2 Brazed	ø28.58	ø25.4	ø28.58	

*1. Connect by using the connecting pipes that are supplied.

NO.	Usage	Specifications
①	Front through hole	140 x 77 Knockout hole
②	For pipes	Front through hole (Uses when twinning kit (optional parts) is mounted.)
③	For wires	ø45 Knockout hole
④	For transmission cables	Front through hole
⑤	Water pipe inlet	ø65 or ø40 Knockout hole
⑥	Water pipe outlet	ø52 or ø27 Knockout hole
⑦	Drain pipe	ø34 Knockout hole
⑧		Rc1-1/2 Screw
		Rc3/4 Screw

Unit: mm

PQRY-P550, 600YLM-A

Note1. Close a hole of the water piping, the refrigerant piping, the power supply, and the control wiring and unused knockout holes with the putty etc. so as not to infiltrate rain water etc.(field erection work)

Note2. At the time of product shipment, the front side piping specification serves as the local drainage connection. When connecting on the rear side, please remove the rear side plug sealing corks, and attach a front side. Ensure there is no leak after the attachment has been fitted.

Note3. Take notice of service space as Fig.A. (In case of single installation, 600mm or more of back space as front space makes easier access when servicing the unit from rear side.)

Note4. If water pipes or refrigerant pipes stretch upward, required space for service and maintenance due to replacement of control box is shown in Fig.B.

Note5. Environmental condition for installation: -20~40°C(DB) as indoor installation.

Note6. In case the temperature around the heat source unit has possibility to drop under 0°C, be careful for the following point to prevent the pipe burst by the water pipe freeze-up.

- Circulate the water all the time even if the heat source unit is not in operation.
- Drain the water from inside of the heat source unit when the heat source unit will not operate for a long term.

Note7. Ensure that the drain piping is downward with a pitch of more than 1/100.

Note8. At brazing of pipes, wrap the refrigerant service valve with wet cloth and keep the temperature of refrigerant service valve under 120°C.

Top view

Front view

Bottom view

Right side view

Back view

NO	Usage	Specifications
①	Front through hole	140 x 77 Knockout hole
②	For pipes	Front through hole (Uses when trimming kit (optional parts) is mounted.)
③	For wires	Front through hole
④	For transmission cables	Front through hole
⑤	Water pipe inlet	Front through hole
⑥	Water pipe outlet	Front through hole
⑦	Drain pipe	Front through hole
⑧		Rc1-1/2 Screw Rc1-1/2 Screw Rc3/4 Screw

Accessories

- Refrigerant (high pressure) conn. pipe1pc. (P550/P600 ; Packaged in the accessory kit)
- Refrigerant (low pressure) conn. pipe1pc. (P550/P600 ; Packaged in the accessory kit)
- Water stopper1pc. (P550/P600 ; Packaged in the accessory kit)
- Sealing material for water stopper1pc. (P550/P600 ; Packaged in the accessory kit)
- Sealing material for field piping (high pressure, low pressure)1pc. each (P550/P600 ; Packaged in the accessory kit)
- Sealing material for drain socket1pc. (P550/P600 ; Packaged in the accessory kit)
- Pipe cover for low pressure1pc. (P550/P600 ; Packaged in the accessory kit)
- Sealing material for base leg (two types)4pcs each (P550/P600 ; Packaged in the accessory kit)
- Sealing material for panel1pc. (P550/P600 ; Packaged in the accessory kit)


Connecting pipe specifications

Model	Refrigerant pipe		Service valve	
	High pressure	Low pressure	High pressure	Low pressure
PQRY-P550YLM-A	ø22.2 Brazeed *1 *2	ø28.58 Brazeed *1	ø25.4	ø28.58
PQRY-P600YLM-A	ø22.2 Brazeed *1 *2	ø34.93 Brazeed *1 *3	ø25.4	ø28.58

*1. Connect by using the connecting pipes and that are supplied.
 *2. When the piping length is 65 m or longer, use the ø28.58 pipe for the part that exceeds 65 m.
 *3. Use the pipe joint(field supply) and connect to the refrigerant service valve piping.

PQRY-P400, 450, 500, 550, 600YSLM-A

Unit: mm




- Note 1. Connect the pipes as shown in the figure above. Refer to the table below for the pipe size.
- 2. Twinning pipe (High pressure) should not be tilted more than 15 degrees from the horizontal plane.
- 3. See the Installation Manual for the details of Twinning pipe installation.
- 4. Only use the Twinning pipe by Mitsubishi (optional parts).

Twinning pipe connection size

Package unit name	PQRY-P400YSLM-A	PQRY-P450YSLM-A	PQRY-P500YSLM-A	PQRY-P550YSLM-A	PQRY-P600YSLM-A
Heat Source unit 1	PQRY-P200YLM-A	PQRY-P250YLM-A	PQRY-P250YLM-A	PQRY-P300YLM-A	PQRY-P300YLM-A
Heat Source unit 2	PQRY-P200YLM-A	PQRY-P200YLM-A	PQRY-P250YLM-A	PQRY-P250YLM-A	PQRY-P300YLM-A
Twinning pipe X (optional parts)	CMY-Q100CBK2				
BC controller~ Twinning pipe	ø22.2				
High pressure	ø28.58				
Low pressure	ø22.2 *1				
	ø34.93				

Unit model	High pressure core	Low pressure d
P200	ø15.88 *2	ø19.05 *2
P250	ø19.05	ø22.2
P300		


*1. When the piping length is 65 m or longer, use the ø28.58 pipe for the part that exceeds 65 m.
 *2. When the package unit name "PQRY-P450YSLM-A", use the ø19.05 pipe for high pressure and the ø22.2 pipe for low pressure.



WR2

PQRY-P200/250/300YLM-A

Unit: mm [in.]




Model	X	Y	Z
PQRY-P200YLM-A	347[13-11/16]	234[9-1/4]	438[17-1/4]
PQRY-P250YLM-A	347[13-11/16]	234[9-1/4]	438[17-1/4]
PQRY-P300YLM-A	347[13-11/16]	234[9-1/4]	438[17-1/4]

*1 Mounting Pitch

PQRY-P350/400/450/500/550/600YLM-A


Unit: mm [in.]



Model	X	Y	Z
PQRY-P350YLM-A	379[14-15/16]	235[9-5/16]	631[24-7/8]
PQRY-P400YLM-A	379[14-15/16]	235[9-5/16]	631[24-7/8]
PQRY-P450YLM-A	379[14-15/16]	235[9-5/16]	631[24-7/8]
PQRY-P500YLM-A	379[14-15/16]	235[9-5/16]	631[24-7/8]
PQRY-P550YLM-A	366[14-7/16]	230[9-1/16]	672[26-1/2]
PQRY-P600YLM-A	366[14-7/16]	230[9-1/16]	672[26-1/2]

*1 Mounting Pitch

PQRY-P200, 250, 300, 350, 400, 450, 500, 550, 600YLM-A



- *1. Single-dotted lines indicate wiring not supplied with the unit.
- *2. Dot-dash lines indicate the control box boundaries.
- *3. Refer to the Data book for connecting input/output signal connectors.
- *4. Daisy-chain terminals (TB3) on the heat source units in the same refrigerant system together.
- *5. Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion. Press the tab on the terminals to removed them.
- *6. Control box houses high-voltage parts. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.
- *7. Refer to the Data book for wiring terminal block for Pump interlock, Operation ON signal, DC0-10V signal output and Power input(24V).
- *8. Difference of appliance.

Model name	Appliance
P200/250/300	*8 do not exist
P350/400/450/500/550/600	*8 exist

- *9. Difference of appliance.

Model name	Appliance
PQRY	*9 do not exist
PQRY	*9 exist

- *10. Difference of appliance.

Model name	Appliance
PQRY	*10 exist
PQRY	*10 do not exist


<Symbol explanation>

Symbol	Explanation
Z/S4a	4-way valve (Cooling/Heating switching)
Z/S4b	Heat exchanger capacity control
GSHT	Pressure switch (High pressure protection for the heat source unit)
63HS1	Pressure sensor (High pressure)
63LS1	Pressure sensor (Low pressure)
Z/C	Magnetic relay (inverter main circuit)
C30-C37	Capacitor (inverter main circuit)
CH11	Crankcase heater (for heating the compressor)
C12/Z2.3	Current sensor (AC)
L	Choke reactor (for high frequency noise reduction)
LEV1	Linear expansion valve (in HIC circuit)
LEV6	Heat exchanger capacity control valve
LEV7	Heat exchanger capacity control valve
LEVINV	Heat exchanger capacity control valve (for inverter)
R1.5	Fan motor (fan speed prevention)
RSH1	Resistor (For inrush current prevention)
SV1a	Solenoid valve (For opening/closing the bypass circuit under the OS)
SV4a,b,d	Heat exchanger capacity control valve
SV7a,b,c	Heat exchanger capacity control valve
SV9	Heat exchanger capacity control valve (for opening/closing the bypass circuit under the OS)
TB1	Terminal block
TB3	Terminal block (indoor/Heat source transmission cable)
TB7	Central control transmission cable
TB8	Operation ON signal, Power interlock
TB9	Power input and signal output for variable water flow valve
TH2	Thermistor (Subcool bypass outlet temperature)
TH3	Pipe temperature
TH4	Discharge pipe temperature
TH5	ACC inlet pipe temperature
TH6	Subcooled liquid refrigerant temperature
TH7	Water inlet temperature
TH8	Water outlet temperature
THINV	Outlet temp. detect of heat exchanger for inverter
THHS	IPM temperature
Z24.25	Function setting connector


*11. Difference of appliance.

Model name	Appliance
P200/250/300/350/400/450/500	*11 do not exist
P550/600	*11 exist

Measurement condition
PQRY-P200, 250, 300YLM-A




Sound level of PQRY-P300YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	51.0	63.0	56.5	47.0	45.5	42.5	44.0	35.5	54.0
Low noise mode	50/60Hz	63.0	47.0	43.0	44.0	42.0	37.5	34.0	27.0	47.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P200YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	66.5	45.5	44.5	42.0	39.5	34.5	32.0	25.5	46.0
Low noise mode	50/60Hz	41.5	42.0	38.5	43.0	40.0	33.0	30.5	22.0	44.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

Sound level of PQRY-P250YLM-A




		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	56.5	46.0	50.0	44.0	42.5	37.5	37.0	27.5	48.0
Low noise mode	50/60Hz	66.5	45.5	44.5	42.0	39.5	34.5	32.0	25.5	46.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


- Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required. For BC controller, it is recommended to be installed in places such as ceilings of corridor, rest rooms and plant rooms.

W/R2

Measurement condition
PQRY-P350, 400, 450, 500, 550, 600YLM-A




Sound level of PQRY-P450YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	46.0	48.0	55.5	44.5	46.5	45.5	48.0	41.0	54.0
Low noise mode	50/60Hz	66.5	45.5	46.5	44.0	46.0	42.0	45.0	40.5	51.5

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P350YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	73.5	51.5	50.0	46.0	46.0	41.5	38.5	31.5	52.0
Low noise mode	50/60Hz	53.5	53.0	47.0	43.0	43.0	41.5	44.0	40.0	50.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P500YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	49.5	55.0	50.0	50.0	46.5	43.0	48.0	45.0	54.0
Low noise mode	50/60Hz	57.5	50.5	48.5	47.0	43.0	43.0	47.5	38.0	52.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P400YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	73.5	51.5	50.0	46.0	46.0	41.5	38.5	31.5	52.0
Low noise mode	50/60Hz	53.5	53.0	47.0	43.0	43.0	41.5	44.0	40.0	50.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P550YLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	45.5	68.0	50.5	53.0	48.5	42.0	45.5	40.0	56.5
Low noise mode	50/60Hz	65.5	62.5	58.0	47.5	45.5	43.5	39.5	38.5	54.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


- ◆ Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required. For BC controller, it is recommended to be installed in places such as ceilings of corridor, rest rooms and plant rooms.




- Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required. For BC controller, it is recommended to be installed in places such as ceilings of corridor, rest rooms and plant rooms.

W/R2

Measurement condition
PQRY-P400, 450, 500, 550, 600YSLM-A




Sound level of PQRY-P500YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	59.5	49.0	53.0	47.0	45.5	40.5	40.0	30.5	51.0
Low noise mode	50/60Hz	69.5	48.5	47.5	45.0	42.5	37.5	35.0	28.5	49.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P400YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	69.5	48.5	47.5	45.0	42.5	37.5	35.0	28.5	49.0
Low noise mode	50/60Hz	44.5	45.0	41.5	46.0	43.0	36.0	33.5	25.0	47.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P550YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	57.5	63.0	57.5	49.0	47.5	43.5	45.0	36.0	55.0
Low noise mode	50/60Hz	68.0	49.5	47.0	46.0	44.0	39.5	36.0	29.5	49.5

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P450YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	67.0	49.0	51.0	46.0	44.5	39.5	38.0	29.5	50.0
Low noise mode	50/60Hz	66.5	47.0	45.5	45.5	43.0	37.0	34.5	27.0	48.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

Sound level of PQRY-P600YSLM-A




		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	54.0	66.0	59.5	50.0	48.5	45.5	47.0	38.5	57.0
Low noise mode	50/60Hz	66.0	50.0	46.0	47.0	45.0	40.5	37.0	30.0	50.0


When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

- Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required. For BC controller, it is recommended to be installed in places such as ceilings of corridor, rest rooms and plant rooms.

Measurement condition
PQRY-P700, 750, 800, 850, 900YSLM-A




Sound level of PQRY-P800YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	76.5	54.5	53.0	49.0	49.0	44.5	41.5	34.5	55.0
Low noise mode	50/60Hz	56.5	56.0	50.0	46.0	46.0	44.5	47.0	43.0	53.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P700YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	76.5	54.5	53.0	49.0	49.0	44.5	41.5	34.5	55.0
Low noise mode	50/60Hz	56.5	56.0	50.0	46.0	46.0	44.5	47.0	43.0	53.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P850YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	73.5	53.0	56.5	48.5	49.5	47.0	48.5	41.5	56.0
Low noise mode	50/60Hz	66.5	53.5	50.0	46.5	48.0	45.0	47.5	43.5	54.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.


Sound level of PQRY-P750YSLM-A



		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	76.5	54.5	53.0	49.0	49.0	44.5	41.5	34.5	55.0
Low noise mode	50/60Hz	56.5	56.0	50.0	46.0	46.0	44.5	47.0	43.0	53.0

When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

Sound level of PQRY-P900YSLM-A




		63	125	250	500	1k	2k	4k	8k	dB(A)
Standard	50/60Hz	49.0	51.0	58.5	47.5	49.5	48.5	51.0	44.0	57.0
Low noise mode	50/60Hz	69.5	48.5	49.5	47.0	49.0	45.0	48.0	43.5	54.5


When Low noise mode is set, the A/C system's capacity is limited. The system could return to normal operation from Low noise mode automatically in the case that the operation condition is severe.

- Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes when operating normally. Please consider to avoid location where quietness is required. For BC controller, it is recommended to be installed in places such as ceilings of corridor, rest rooms and plant rooms.

• Cooling



• Heating







• Combination of cooling/heating operation (Cooling main or Heating main)

Water temperature	Indoor temperature	
	Cooling	Heating
10 to 45°C (50 to 113°F)	15 to 24°CWB (59 to 75°FWB)	15 to 27°CDB (59 to 81°FDB)





7-1. Correction by temperature

CITY MULTI could have varied capacity at different designing temperature. Using the nominal cooling/heating capacity value and the ratio below, the capacity can be observed at various temperature.

		PQHY-P200YLM-A	PQRY-P200YLM-A
Nominal Cooling Capacity	kW	22.4	22.4
	BTU/h	76,400	76,400
Input	kW	3.71	3.71







		PQHY-P200YLM-A	PQRY-P200YLM-A
Nominal Heating Capacity	kW	25.0	25.0
	BTU/h	85,300	85,300
Input	kW	3.97	3.97







7. CAPACITY TABLES

W/R2

		PQHY-P250YLM-A	PQRY-P250YLM-A
Nominal Cooling Capacity	kW	28.0	28.0
	BTU/h	95,500	95,500
Input	kW	4.90	4.90







		PQHY-P250YLM-A	PQRY-P250YLM-A
Nominal Heating Capacity	kW	31.5	31.5
	BTU/h	107,500	107,500
Input	kW	5.08	5.08







7. CAPACITY TABLES

WR2

		PQHY-P300YLM-A	PQRY-P300YLM-A
Nominal Cooling Capacity	kW	33.5	33.5
	BTU/h	114,300	114,300
Input	kW	6.04	6.04







		PQHY-P300YLM-A	PQRY-P300YLM-A
Nominal Heating Capacity	kW	37.5	37.5
	BTU/h	128,000	128,000
Input	kW	6.25	6.25







7. CAPACITY TABLES

W/R2

		PQHY-P350YLM-A	PQRY-P350YLM-A
Nominal Cooling Capacity	kW	40.0	40.0
	BTU/h	136,500	136,500
Input	kW	7.14	7.14







		PQHY-P350YLM-A	PQRY-P350YLM-A
Nominal Heating Capacity	kW	45.0	45.0
	BTU/h	153,500	153,500
Input	kW	7.53	7.53







7. CAPACITY TABLES

WR2

		PQHY-P400YLM-A	PQRY-P400YLM-A
Nominal Cooling Capacity	kW	45.0	45.0
	BTU/h	153,500	153,500
Input	kW	8.03	8.03







		PQHY-P400YLM-A	PQRY-P400YLM-A
Nominal Heating Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	8.37	8.37







7. CAPACITY TABLES

W/R2

		PQHY-P450YLM-A	PQRY-P450YLM-A
Nominal Cooling Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	9.29	9.29







		PQHY-P450YLM-A	PQRY-P450YLM-A
Nominal Heating Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	9.79	9.79







7. CAPACITY TABLES

WR2

		PQHY-P500YLM-A	PQRY-P500YLM-A
Nominal Cooling Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	11.17	11.17







		PQHY-P500YLM-A	PQRY-P500YLM-A
Nominal Heating Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	11.43	11.43







7. CAPACITY TABLES

W/R2

		PQHY-P550YLM-A	PQRY-P550YLM-A
Nominal Cooling Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	12.54	12.54



		PQHY-P550YLM-A	PQRY-P550YLM-A
Nominal Heating Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	12.27	12.27







7. CAPACITY TABLES





HEAT SOURCE

WR2

		PQHY-P600YLM-A	PQRY-P600YLM-A
Nominal Cooling Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	14.49	14.49





		PQHY-P600YLM-A	PQRY-P600YLM-A
Nominal Heating Capacity	kW	76.5	76.5
	BTU/h	261,000	261,000
Input	kW	14.51	14.51







7. CAPACITY TABLES

W/R2



		PQHY-P400YSLM-A	PQRY-P400YSLM-A
Nominal Cooling Capacity	kW	45.0	45.0
	BTU/h	153,500	153,500
Input	kW	7.70	7.70



		PQHY-P400YSLM-A	PQRY-P400YSLM-A
Nominal Heating Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	7.94	7.94



*The drawing indicates characteristic per unit.





*The drawing indicates characteristic per unit.





7. CAPACITY TABLES

WR2



		PQHY-P450YSLM-A	PQRY-P450YSLM-A
Nominal Cooling Capacity	kW	50.0	50.0
	BTU/h	170,600	170,600
Input	kW	8.78	8.78



		PQHY-P450YSLM-A	PQRY-P450YSLM-A
Nominal Heating Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	8.97	8.97



*The drawing indicates characteristic per unit.







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





W/R2

		PQHY-P500YSLM-A	PQRY-P500YSLM-A
Nominal Cooling Capacity	kW	56.0	56.0
	BTU/h	191,100	191,100
Input	kW	10.12	10.12



*The drawing indicates characteristic per unit.

		PQHY-P500YSLM-A	PQRY-P500YSLM-A
Nominal Heating Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	10.16	10.16







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES

HEAT SOURCE





WR2

		PQHY-P550YSLM-A	PQRY-P550YSLM-A
Nominal Cooling Capacity	kW	63.0	63.0
	BTU/h	215,000	215,000
Input	kW	11.55	11.55



*The drawing indicates characteristic per unit.

		PQHY-P550YSLM-A	PQRY-P550YSLM-A
Nominal Heating Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	11.31	11.31





*The drawing indicates characteristic per unit.





7. CAPACITY TABLES

W/R2



		PQHY-P600YSLM-A	PQRY-P600YSLM-A
Nominal Cooling Capacity	kW	69.0	69.0
	BTU/h	235,400	235,400
Input	kW	12.84	12.84



		PQHY-P600YSLM-A	PQRY-P600YSLM-A
Nominal Heating Capacity	kW	76.5	76.5
	BTU/h	261,000	261,000
Input	kW	12.75	12.75







*The drawing indicates characteristic per unit.



*The drawing indicates characteristic per unit.





WR2

		PQHY-P700YSLM-A	PQRY-P700YSLM-A
Nominal Cooling Capacity	kW	80.0	80.0
	BTU/h	273,000	273,000
Input	kW	14.73	14.73



*The drawing indicates characteristic per unit.

		PQHY-P700YSLM-A	PQRY-P700YSLM-A
Nominal Heating Capacity	kW	88.0	88.0
	BTU/h	300,300	300,300
Input	kW	14.73	14.73







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





W/R2

		PQHY-P750YSLM-A	PQRY-P750YSLM-A
Nominal Cooling Capacity	kW	85.0	85.0
	BTU/h	290,000	290,000
Input	kW	15.64	15.64



*The drawing indicates characteristic per unit.

		PQHY-P750YSLM-A	PQRY-P750YSLM-A
Nominal Heating Capacity	kW	95.0	95.0
	BTU/h	324,100	324,100
Input	kW	15.90	15.90







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





WR2

		PQHY-P800YSLM-A	PQRY-P800YSLM-A
Nominal Cooling Capacity	kW	90.0	90.0
	BTU/h	307,100	307,100
Input	kW	16.57	16.57



*The drawing indicates characteristic per unit.

		PQHY-P800YSLM-A	PQRY-P800YSLM-A
Nominal Heating Capacity	kW	100.0	100.0
	BTU/h	341,200	341,200
Input	kW	16.75	16.75







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





W/R2

		PQHY-P850YSLM-A	PQRY-P850YSLM-A
Nominal Cooling Capacity	kW	96.0	96.0
	BTU/h	327,600	327,600
Input	kW	18.03	18.03



*The drawing indicates characteristic per unit.

		PQHY-P850YSLM-A	PQRY-P850YSLM-A
Nominal Heating Capacity	kW	108.0	108.0
	BTU/h	368,500	368,500
Input	kW	18.49	18.49







*The drawing indicates characteristic per unit.

7. CAPACITY TABLES





WR2

		PQHY-P900YSLM-A	PQRY-P900YSLM-A
Nominal Cooling Capacity	kW	101.0	101.0
	BTU/h	344,600	344,600
Input	kW	19.38	19.38



*The drawing indicates characteristic per unit.

		PQHY-P900YSLM-A	PQRY-P900YSLM-A
Nominal Heating Capacity	kW	113.0	113.0
	BTU/h	385,600	385,600
Input	kW	19.74	19.74



*The drawing indicates characteristic per unit.


W/R2

7-2. Correction by total indoor

CITY MULTI system have different capacities and inputs when many combinations of indoor units with different total capacities are connected. Using following tables, the maximum capacity can be found to ensure the system is installed with enough capacity for a particular application.


PQRY-P200YLM-A		
Nominal Cooling Capacity	kW	22.4
	BTU/h	76,400
Input	kW	3.71

PQRY-P200YLM-A		
Nominal Heating Capacity	kW	25.0
	BTU/h	85,300
Input	kW	3.97



PQRY-P250YLM-A		
Nominal Cooling Capacity	kW	28.0
	BTU/h	95,500
Input	kW	4.90

PQRY-P250YLM-A		
Nominal Heating Capacity	kW	31.5
	BTU/h	107,500
Input	kW	5.08




7. CAPACITY TABLES

HEAT SOURCE

WR2


PQRY-P300YLM-A		
Nominal Cooling Capacity	kW	33.5
	BTU/h	114,300
Input	kW	6.04

PQRY-P300YLM-A		
Nominal Heating Capacity	kW	37.5
	BTU/h	128,000
Input	kW	6.25



PQRY-P350YLM-A		
Nominal Cooling Capacity	kW	40.0
	BTU/h	136,500
Input	kW	7.14

PQRY-P350YLM-A		
Nominal Heating Capacity	kW	45.0
	BTU/h	153,500
Input	kW	7.53



7. CAPACITY TABLES

W/R2


PQRY-P400YLM-A		
Nominal Cooling Capacity	kW	45.0
	BTU/h	153,500
Input	kW	8.03

PQRY-P400YLM-A		
Nominal Heating Capacity	kW	50.0
	BTU/h	170,600
Input	kW	8.37

PQRY-P400YSLM-A		
Nominal Cooling Capacity	kW	45.0
	BTU/h	153,500
Input	kW	7.70

PQRY-P400YSLM-A		
Nominal Heating Capacity	kW	50.0
	BTU/h	170,600
Input	kW	7.94

PQRY-P400Y(S)LM-A




PQRY-P450YLM-A		
Nominal Cooling Capacity	kW	50.0
	BTU/h	170,600
Input	kW	9.29

PQRY-P450YLM-A		
Nominal Heating Capacity	kW	56.0
	BTU/h	191,100
Input	kW	9.79

PQRY-P450YSLM-A		
Nominal Cooling Capacity	kW	50.0
	BTU/h	170,600
Input	kW	8.78

PQRY-P450YSLM-A		
Nominal Heating Capacity	kW	56.0
	BTU/h	191,100
Input	kW	8.97

PQRY-P450Y(S)LM-A



7. CAPACITY TABLES

HEAT SOURCE

WR2


PQRY-P500YLM-A		
Nominal Cooling Capacity	kW	56.0
	BTU/h	191,100
Input	kW	11.17

PQRY-P500YLM-A		
Nominal Heating Capacity	kW	63.0
	BTU/h	215,000
Input	kW	11.43

PQRY-P500YSLM-A		
Nominal Cooling Capacity	kW	56.0
	BTU/h	191,100
Input	kW	10.12

PQRY-P500YSLM-A		
Nominal Heating Capacity	kW	63.0
	BTU/h	215,000
Input	kW	10.16

PQRY-P500Y(S)LM-A




PQRY-P550YLM-A		
Nominal Cooling Capacity	kW	63.0
	BTU/h	215,000
Input	kW	12.54

PQRY-P550YLM-A		
Nominal Heating Capacity	kW	69.0
	BTU/h	235,400
Input	kW	12.27

PQRY-P550YSLM-A		
Nominal Cooling Capacity	kW	63.0
	BTU/h	215,000
Input	kW	11.55

PQRY-P550YSLM-A		
Nominal Heating Capacity	kW	69.0
	BTU/h	235,400
Input	kW	11.31

PQRY-P550Y(S)LM-A



7. CAPACITY TABLES

HEAT SOURCE

W/R2


PQRY-P600YLM-A		
Nominal Cooling Capacity	kW	69.0
	BTU/h	235,400
Input	kW	14.49

PQRY-P600YLM-A		
Nominal Heating Capacity	kW	76.5
	BTU/h	261,000
Input	kW	14.51

PQRY-P600YSLM-A		
Nominal Cooling Capacity	kW	69.0
	BTU/h	235,400
Input	kW	12.84

PQRY-P600YSLM-A		
Nominal Heating Capacity	kW	76.5
	BTU/h	261,000
Input	kW	12.75


PQRY-P600Y(S)LM-A



PQRY-P700YSLM-A		
Nominal Cooling Capacity	kW	80.0
	BTU/h	273,000
Input	kW	14.73

PQRY-P700YSLM-A		
Nominal Heating Capacity	kW	88.0
	BTU/h	300,300
Input	kW	14.73

PQRY-P700YSLM-A




7. CAPACITY TABLES

HEAT SOURCE

WR2


PQRY-P750YSLM-A		
Nominal Cooling Capacity	kW	85.0
	BTU/h	290,000
Input	kW	15.64

PQRY-P750YSLM-A		
Nominal Heating Capacity	kW	95.0
	BTU/h	324,100
Input	kW	15.90



PQRY-P800YSLM-A		
Nominal Cooling Capacity	kW	90.0
	BTU/h	307,100
Input	kW	16.57

PQRY-P800YSLM-A		
Nominal Heating Capacity	kW	100.0
	BTU/h	341,200
Input	kW	16.75




7. CAPACITY TABLES

HEAT SOURCE

W/R2


PQRY-P850YSLM-A		
Nominal Cooling Capacity	kW	96.0
	BTU/h	327,600
Input	kW	18.03

PQRY-P850YSLM-A		
Nominal Heating Capacity	kW	108.0
	BTU/h	368,500
Input	kW	18.49



PQRY-P900YSLM-A		
Nominal Cooling Capacity	kW	101.0
	BTU/h	344,600
Input	kW	19.38

PQRY-P900YSLM-A		
Nominal Heating Capacity	kW	113.0
	BTU/h	385,600
Input	kW	19.74




7-3. Correction by refrigerant piping length

CITY MULTI system can extend the piping flexibly within its limitation for the actual situation. However, a decrease of cooling/heating capacity could happen correspondently. Using following correction factor according to the equivalent length of the piping shown at 7-3-1 and 7-3-2, the capacity can be observed. 7-3-3 shows how to obtain the equivalent length of piping.

7-3-1. Cooling capacity correction







WR2



7. CAPACITY TABLES







HEAT SOURCE

WR2



7-3-2. Heating capacity correction

WR2



7-3-3. How to obtain the equivalent piping length

1 PQRYP200YLM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.35 × number of bends in the piping) m

2 PQRYP250, 300YLM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.42 × number of bends in the piping) m

3 PQRYP350, 400, 450, 500, 550, 600Y(S)LM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.50 × number of bends in the piping) m

4 PQRYP700, 750, 800YSLM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.70 × number of bends in the piping) m

5 PQRYP850, 900YSLM

Equivalent length = (Actual piping length to the farthest indoor unit) + (0.80 × number of bends in the piping) m

7-4. Correction by port counts of the BC controller

Indoor unit sizes P200 and P250 must be connected to 2 ports on the BC controller.

Indoor unit sizes from P100 to P140 should normally be connected to 2 ports on the BC controller (set BC controller DIP-SW 4-6 to its ON position).

In cases whereby indoor unit sizes from P100 to P140 are connected to only 1 port on the BC controller (set BC controller DIP-SW 4-6 to its OFF position), the cooling capacity of the indoor unit should be multiplied by a correction factor of **0.97**.

8-1. Designing of water circuit system

1) Example of basic water circuit


The water circuit of the water heat source CITY MULTI connects the heat source unit with the cooling tower/auxiliary heat source/heat storage tank/circulation pump with a single system water piping as shown in the figure below. The selector valve automatically controls to circulate water toward the cooling tower in the cooling season, while toward the heat storage tank in the heating season. If the circulation water temperature is kept in a range of 10~45°C [50~113°F] regardless of the building load, the water heat source CITY MULTI can be operated for either cooling or heating. Therefore in the summer when only cooling load exists, the temperature rise of circulation water will be suppressed by operating the cooling tower. While in the winter when heating load increases, the temperature of circulation water may be dropped below 10°C [50°F]. Under such situation, the circulation water will be heated with the auxiliary heat source if it drops below a certain temperature.

When the thermal balance between cooling and heating operation is in a correct proportion, the operation of the auxiliary heat source and cooling tower is not required.

In order to control the above thermal balance properly and use thermal energy effectively, utilizing of heat storage tanks, and night-time discounted electric power as a auxiliary heat source will be economical.

Meantime as this system uses plural sets of heat source unit equipped with water heat exchangers, water quality control is important. Therefore it is recommended to use closed type cooling towers as much as possible to prevent the circulation water from being contaminated.

When open type cooling towers are used, it is essential to provide proper maintenance control such as that to install water treatment system to prevent troubles caused by contaminated circulation water.



2) Cooling tower


a) Types of cooling tower

The cooling towers presently used include the open type cooling tower, open type cooling tower + heat exchanger, closed type cooling tower, and air-cooled type cooling tower. However, as the quality control of circulation water is essential when units are installed in decentralized state inside a building, the closed type cooling tower is generally employed in such case.

Although the circulation water will not be contaminated by atmospheric air, it is recommended to periodically blow water inside the system and replenish fresh water instead.

In a district where the coil may be frozen in the winter, it is necessary to apply antifreeze solution to the circulation water, or take freeze protection measures such as to automatically discharge water inside the cooling coil at the stopping of the pump.

When the open type cooling tower is used, be sure to install a water quality control device in addition to the freeze protection measures, as the water may be deteriorated by atmospheric contaminants entered into the cooling tower and dissolved into the circulation water.



b) Calculation method of cooling tower capacity

All units of the water heat source CITY MULTI may possibly be in cooling operation temporarily (at pulling down) in the summer, however, it is not necessary to determine the capacity according to the total cooling capacity of all CITY MULTI units as this system has a wide operating water temperature range.

It is determined in accordance with the value obtained by adding the maximum cooling load of an actual building, the input heat equivalent value of all CITY MULTI units, and the cooling load of the circulating pumps. Please check for the values of the cooling water volume and circulation water volume.

$$\text{Cooling tower capacity} = \frac{Q_c + 860 \times (\Sigma Q_w + P_w)}{3,900} \text{ (Refrigeration ton)}$$

- Q_c : Maximum cooling load under actual state (kcal/h)
- Q_w : Total input of water heat source CITY MULTI at simultaneous operation under maximum state (kW)
- P_w : Shaft power of circulation pumps (kW)

$$\text{Cooling tower capacity} = \frac{Q_c + 3,412 \times (\Sigma Q_w + P_w)}{15,500} \text{ (Refrigeration ton)}$$

- Q_c : Maximum cooling load under actual state (BTU/h)
- Q_w : Total input of water heat source CITY MULTI at simultaneous operation under maximum state (kW)
- P_w : Shaft power of circulation pumps (kW)

* 1 Refrigerant ton of cooling tower capacity ≈ US refrigerant ton × (1 + 0.3)
= 3,900 kcal/h = 15,500 BTU/h

3) Auxiliary heat source and heat storage tank

When the heating load is larger than the cooling load, the circulation water temperature lowers in accordance with the heat balance of the system. It should be heated by the auxiliary heat source in order to keep the inlet water temperature within the operating range of the water heat source CITY MULTI.

Further in order to operate the water heat source CITY MULTI effectively, it is recommended to utilize the heat storage tank to cover the warming up load in the morning and the insufficient heat amount. Effective heat utilization can be expected to cover insufficient heat at the warming up in the next morning or peak load time by storing heat by installing a heat storage tank or operating a low load auxiliary heat source at the stopping of the water heat source CITY MULTI. As it can also be possible to reduce the running cost through the heat storage by using the discounted night-time electric power, using both auxiliary heat source and heat storage tank together is recommended. The effective temperature difference of an ordinary heat storage tank shows about 5°C [41°F] even with the storing temperature at 45°C [113°F]. However with the water heat source CITY MULTI, it can be utilized as heating heat source up to 15°C [59°F] with an effective temperature of a high 30°C [54°F] approximately, thus the capacity of the heat storage tank can be minimized.

a) Auxiliary heat source

The following can be used as the auxiliary heat source.

- Boiler (Heavy oil, kerosine, gas, electricity)
- Electric heat (Insertion of electric heater into heat storage tank)
- Outdoor air (Air-heat source heat pump chiller)
- Warm discharge water (Exhaust water heat from machines inside building and hot water supply)
- Utilization of night-time lighting
- Solar heat

Please note that the auxiliary heat source should be selected after studying your operating environment and economical feasibility.

Determining the auxiliary heat source capacity

For the CITY MULTI water heat source system, a heat storage tank is recommended to use. When employment of the heat storage tank is difficult, the warming up operation should be arranged to cover the starting up heating load. Since the holding water inside the piping circuit owns heat capacity and the warming up operation can be assumed for about one hour except that in a cold region, the heat storage tank capacity is required to be that at the maximum daily heating load including the warming up load at the next morning of the holiday. However the auxiliary heat source capacity should be determined by the daily heating load including warming up load on the week day. For the load at the next morning of the holiday, heat storage is required by operating the auxiliary heat source even outside of the ordinary working hour.

When heat storage tank is not used

$$QH = HCT \left(1 - \frac{1}{COP_h} \right) - 1000 \times V_w \times \Delta T - 860 \times P_w$$

- | | | |
|------------------|--|-------------------|
| QH | : Auxiliary heat source capacity | (kcal/h) |
| HCT | : Total heating capacity of each water heat source CITY MULTI | (kcal/h) |
| COP _H | : COP of water heat source CITY MULTI at heating | |
| V _w | : Holding water volume inside piping | (m ³) |
| ΔT | : Allowable water temperature drop = T _{WH} - T _{WL} | (°C) |
| T _{WH} | : Heat source water temperature at high temperature side | (°C) |
| T _{WL} | : Heat source water temperature at low temperature side | (°C) |
| P _w | : Heat source water pump shaft power | (kW) |

$$QH = HCT \left(1 - \frac{1}{COP_h} \right) - 8.343 \times V_w \times \Delta T - 3412 \times P_w$$

- | | | |
|------------------|--|---------|
| QH | : Auxiliary heat source capacity | (BTU/h) |
| HCT | : Total heating capacity of each water heat source CITY MULTI | (BTU/h) |
| COP _H | : COP of water heat source CITY MULTI at heating | |
| V _w | : Holding water volume inside piping | (G) |
| ΔT | : Allowable water temperature drop = T _{WH} - T _{WL} | (°F) |
| T _{WH} | : Heat source water temperature at high temperature side | (°F) |
| T _{WL} | : Heat source water temperature at low temperature side | (°F) |
| P _w | : Heat source water pump shaft power | (kW) |

When heat storage tank is not used

$$QH = \frac{HQ_{1T} \cdot \left(1 - \frac{1}{COP_h} \right) - 860 \times P_w \times T_2}{T_1} \times K \quad (\text{kcal})$$

- QH_{1T} : Total of heating load on weekday including warming up (kcal/day)
- T₁ : Operating hour of auxiliary heat source (h)
- T₂ : Operating hour of heat source water pump (h)
- K : Allowance factor (Heat storage tank, piping loss, etc.) 1.05~1.10

HQ_{1T} is calculated from the result of steady state load calculation similarly by using the equation below.

$$HQ_{1T} = 1.15 \times (\Sigma Q'a + \Sigma Q'b + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe_1 + \Sigma Qe_2 + \Sigma Qe_3) (T_2 - 1)$$

- Q'a : Thermal load from external wall/roof in each zone (kcal/h)
- Q'b : Thermal load from glass window in each zone (kcal/h)
- Q'c : Thermal load from partition/ceiling/floor in each zone (kcal/h)
- Q'd : Thermal load by infiltration in each zone (kcal/h)
- Q'f : Fresh outdoor air load in each zone (kcal/h)
- Q'e₁ : Thermal load from human body in each zone (kcal/h)
- Q'e₂ : Thermal load from lighting fixture in each zone (kcal/h)
- Q'e₃ : Thermal load from equipment in each zone (kcal/h)
- ψ : Radiation load rate 0.6~0.8
- T₂ : Air conditioning hour

$$QH = \frac{HQ_{1T} \cdot \left(1 - \frac{1}{COP_h} \right) - 3,412 \times P_w \times T_2}{T_1} \times K \quad (\text{BTU})$$

- QH_{1T} : Total of heating load on weekday including warming up (BTU/day)
- T₁ : Operating hour of auxiliary heat source (h)
- T₂ : Operating hour of heat source water pump (h)
- K : Allowance factor (Heat storage tank, piping loss, etc.) 1.05~1.10

HQ_{1T} is calculated from the result of steady state load calculation similarly by using the equation below.

$$HQ_{1T} = 1.15 \times (\Sigma Q'a + \Sigma Q'b + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe_1 + \Sigma Qe_2 + \Sigma Qe_3) (T_2 - 1)$$

- Q'a : Thermal load from external wall/roof in each zone (BTU/h)
- Q'b : Thermal load from glass window in each zone (BTU/h)
- Q'c : Thermal load from partition/ceiling/floor in each zone (BTU/h)
- Q'd : Thermal load by infiltration in each zone (BTU/h)
- Q'f : Fresh outdoor air load in each zone (BTU/h)
- Q'e₁ : Thermal load from human body in each zone (BTU/h)
- Q'e₂ : Thermal load from lighting fixture in each zone (BTU/h)
- Q'e₃ : Thermal load from equipment in each zone (BTU/h)
- ψ : Radiation load rate 0.6~0.8
- T₂ : Air conditioning hour

b) Heat storage tank

Heat storage tank can be classified by types into the open type heat storage tank exposed to atmosphere, and the closed type heat storage tank with structure separated from atmosphere. Although the size of the tank and its installation place should be taken into account, the closed type tank is being usually employed by considering corrosion problems.

The capacity of heat storage tanks is determined in accordance with the daily maximum heating load that includes warming up load to be applied for the day after the holiday.

When auxiliary heat source is operated during operation and even after stopping of water heat source CITY MULTI unit

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 860 \times P_w \times T_2 - Q_H \times T_2}{\Delta T \times 1,000 \times \eta V} \quad (\text{ton})$$

- HQ_{2T} : Maximum heating load including load required for the day after the holiday (kcal/day)
- ΔT : Temperature difference utilized by heat storage tank (°C)
- ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 3,412 \times P_w \times T_2 - Q_H \times T_2}{\Delta T \times \eta V} \quad (\text{lbs})$$

- HQ_{2T} : Maximum heating load including load required for the day after the holiday (BTU/day)
- ΔT : Temperature difference utilized by heat storage tank (°F)
- ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$

When auxiliary heat source is operated after stopping of water heat source CITY MULTI unit

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 860 \times P_w \times T_2}{\Delta T \times 1,000 \times \eta V} \quad (\text{ton})$$

- HQ_{2T} : Maximum heating load including load required for the day after the holiday (kcal/day)
- ΔT : Temperature difference utilized by heat storage tank (°C)
- ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$

$$V = \frac{HQ_{2T} \left(1 - \frac{1}{COP_h} \right) - 3,412 \times P_w \times T_2}{\Delta T \times \eta V} \quad (\text{lbs})$$

- HQ_{2T} : Maximum heating load including load required for the day after the holiday (BTU/day)
- ΔT : Temperature difference utilized by heat storage tank (°F)
- ηV : Heat storage tank efficiency

$$HQ_{2T} : 1.3 \times (\Sigma Q'a + \Sigma Q'c + \Sigma Q'd + \Sigma Q'f) T_2 - \psi (\Sigma Qe2 + \Sigma Qe3) (T_2 - 1)$$

4) Piping system


The following items should be kept in your mind in planning / designing water circuits.

- a) All units should be constituted in a single circuit in principle.
- b) When plural numbers of the water heat source CITY MULTI unit are installed, the rated circulating water flow rate should be kept by making the piping resistance to each unit almost same value. As an example, the reverse return system as shown below may be employed.
- c) Depending on the structure of a building, the water circuit may be prefabricated by making the layout uniform.
- d) When a closed type piping circuit is constructed, install an expansion tank usable commonly for a make-up water tank to absorb the expansion/contraction of water caused by temperature fluctuation.
- e) If the operating temperature range of circulation water stays within the temperature near the normal temperature (summer :29.4°C [85°F], winter :21.1°C [70°F]), thermal insulation or anti-sweating work is not required for the piping inside buildings.

In case of the conditions below, however, thermal insulation is required.

- When well water is used for heat source water.
- When piped to outdoor or a place where freezing may be caused.
- When vapor condensation may be generated on piping due to an increase in dry bulb temperature caused by the entry of fresh outdoor air.

System example of water circuit




5) Practical System Examples and Circulation Water Control

Since the water heat source CITY MULTI is of water heat source system, versatile systems can be constituted by combining it with various heat sources.

The practical system examples are given below.


Either cooling or heating operation can be performed if the circulation water temperature of the water heat source CITY MULTI stays within a range of 15~45°C [59~113°F]. However, the circulation water temperature near 32°C [90°F] for cooling and 20°C [68°F] for heating is recommended by taking the life, power consumption and capacity of the air conditioning units into consideration. The detail of the control is also shown below.

Example-1 Combination of closed type cooling tower and hot water heat storage tank (using underground hollow slab)



Example-2 Combination of closed type cooling tower and hot water heat storage tank

- T1 : Proportional type, insertion system thermostat
 T2 : Proportional type, insertion system thermostat
 T3 : Proportional type, insertion system thermostat
 V1 : Proportional type, motor-driven 3-way valve
 V2 : Proportional type, motor-driven 3-way valve
 XS : Auxiliary switch (Duplex switch type)
 SC : Step controller
 R : Relay
 MG : Magnetic



In the summer, as the circulation water temperature rises exceeding the set temperature of T1, the bypass port of V1 will open to lower the circulation water temperature. In the winter, if the circulation water temperature stays below 25°C [77°F], V2 will open/close by the command of T2 to keep the circulation water temperature constant.


The temperature of the hot water inside the heat storage tank will be controlled through the step control of the electric heater by step controller operation following the command of T3.

During the stopping of the heat source water pump, the bypass port of V2 will be closed fully by interlocking thus preventing the high temperature water from entering into the system at the starting of the pump.

The start/stop control of the fan and pump of the closed type cooling tower is applied with the step control of the fan and pump following the command of the auxiliary switch XS of V1, that operates only the fan at the light load while the fan and pump at the maximum load thus controlling water temperature and saving motor power.

Example-3 Combination of closed type cooling tower and boiler


- T1 : Proportional type, insertion system thermostat
 T2 : Proportional type, insertion system thermostat
 T3 : Proportional type, insertion system thermostat
 V1 : Proportional type, motor-driven 3-way valve
 S : Selector switch
 R : Relay
 XS : Auxiliary switch (Duplex switch type)



In the summer, as the circulation water temperature rises exceeding the set temperature of T1, the bypass port of V1 will close to lower the circulation water temperature. In the winter, if the circulation water temperature drops below 25°C [77°F], V2 will conduct water temperature control to keep the circulation water temperature constant. During the stopping of the heat source water pump, the bypass port of V2 will be closed fully by interlocking. The start/stop control of the fan and pump of the closed type cooling tower is applied with the step control following the command of the auxiliary switch XS of V1, thus controlling water temperature and saving motor power.

Example-4 Combination of closed type cooling tower and heat exchanger (of other heat source)


- T1 : Proportional type, insertion system thermostat
- T2 : Proportional type, insertion system thermostat
- V1 : Proportional type, motor-driven 3-way valve
- V2 : Proportional type, motor-driven 3-way valve
- S : Selector switch
- R : Relay
- XS : Auxiliary switch (Duplex switch type)



In the summer, as the circulation water temperature rises exceeding the set temperature of T1, the bypass port of V1 will close to lower the circulation water temperature. In the winter, if the circulation water temperature drops below 26°C [79°F], V2 will conduct water temperature control to keep the circulation water temperature constant. During the stopping of the heat source water pump, the bypass port of V2 will be closed fully by interlocking. The start/stop control of the fan and pump of the closed type cooling tower is applied with the step control following the command of the auxiliary switch XS of V1, thus controlling water temperature and saving motor power.

6) Pump interlock circuit


WR2



- Plural indoor units being connected to a single refrigerant system can be controlled individually.
- The transmission line is of a jumper wiring system using non-polar 2 wires.

Wiring diagram

This circuit uses the "Terminal block for pump interlock (TB8)" inside the electrical parts box of the heat source equipment. This circuit is for interlocking of the heat source equipment operation and the heat source water pump.



- X : Relay
- Rated voltage : L1 - N : 220 ~ 240V
- Rated load : 1A
- FS : Flow switch
- 52P : Magnetic contactor for heat source water pump
- MP : Heat source water pump
- MCB : Circuit breaker

*Remove the short circuit wire between 3 and 4 when wiring to TB8.

*Pump interlock
Operating the heat source unit without circulation water inside the water piping can cause troubles. Be sure to provide interlocking for the unit operation and water circuit (pump interlock). Since the terminal block is being provided inside the unit, use it as required.

Use the flow switch (FS)


Operation ON signal

Terminal No.	TB8-1, 2																														
Output	Relay contacts output Rated voltage : L1 - N : 220 ~ 240V Rated load : 1A																														
Operation	<ul style="list-style-type: none"> When setting No.917 for Dip switch 4 (Dip switch 6-10 is ON) is OFF. The relay closes during compressor operation. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th colspan="10">SW4 0: OFF, 1: ON</th> </tr> <tr> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td> </tr> <tr> <td>1</td><td>0</td><td>1</td><td>0</td><td>1</td><td>0</td><td>0</td><td>1</td><td>1</td><td>1</td> </tr> </table> <ul style="list-style-type: none"> When setting No.917 for Dip switch 4 (Dip switch 6-10 is ON) is ON. The relay closes during reception of cooling or the heating operation signal from the controller. (Note : It is output even if the thermostat is OFF (when the compressor is stopped).) 	SW4 0: OFF, 1: ON										1	2	3	4	5	6	7	8	9	10	1	0	1	0	1	0	0	1	1	1
SW4 0: OFF, 1: ON																															
1	2	3	4	5	6	7	8	9	10																						
1	0	1	0	1	0	0	1	1	1																						

Pump Interlock

Terminal No.	TB8-3, 4
Input	Level signal
Operation	If the circuit between TB8-3 and TB8-4 is open, compressor operation is prohibited.

*Remove the short circuit wire between 3 and 4 when wiring to TB8.
To prevent a false detection of error resulting from contact failure, use a flow switch with a minimum guaranteed current of 5 mA or below for FS.




8-2. Water piping work

Although the water piping for the CITY MULTI WR2 system does not differ from that for ordinary air conditioning systems, pay special attention to the items below in conducting the piping work.

1) Items to be observed on installation work

- In order to equalize piping resistance for each unit, adapt the reverse return system.
- Mount a joint and a valve onto the water outlet/inlet of the unit to allow for maintenance, inspection and replacement work. Be sure to mount a strainer at the water inlet piping of the unit. (The strainer is required at the circulation water inlet to protect the heat source unit.)
- * The installation example of the heat source unit is shown right.
- Be sure to provide an air relief opening on the water piping properly, and purge air after feeding water to the piping system.
- Condensate will generate at the low temperature part inside the heat source equipment. Connect drain piping to the drain piping connection located at the bottom of the heat source equipment to discharge it outside the equipment.
- At the center of the header of the heat exchanger water inlet inside the unit, a plug for water discharge is being provided.
Use it for maintenance work or the like.
- Mount a backflow prevention valve and a flexible joint for vibration control onto the pump.
- Provide a sleeve to the penetrating parts of the wall to prevent the piping.
- Fasten the piping with metal fitting, arrange the piping not to expose to cutting or bending force, and pay sufficient care for possible vibration.
- Be careful not to erroneously judge the position of the inlet and outlet of water.
(Lower position : Inlet, Upper position : Outlet)
- When connecting heat source unit water piping and water piping on site, apply liquid sealing material for water piping over the sealing tape before connection. (for Maximum water pressure above 1.0MPa)
- Wrap the sealing tape as follows.
 - a) Wrap the joint with sealing tape in the direction of the threads (clockwise), and do not let the tape run over the edge.
 - b) Overlap the sealing tape by two-thirds to three-fourths of its width on each turn. Press the tape with your fingers so that it is pressed firmly against each thread.
 - c) Leave the 1.5th through 2nd farthest threads away from the pipe end unwrapped.
- Hold the pipe on the unit side in place with a spanner when installing the pipes or strainer. Tighten screws to a torque of 150N·m.



3) Water treatment and water quality control

For the circulation water cooling tower of the CITY MULTI WR2 system, employment of the closed type is recommended to keep water quality. However, in the case that an open type cooling tower is employed or the circulating water quality is inferior, scale will adhere onto the water heat exchanger leading to the decreased heat exchange capacity or the corrosion of the heat exchanger. Be sufficiently careful for water quality control and water treatment at the installation of the circulation water system

- Removal of impurities inside piping
Be careful not to allow impurities such as welding fragment, remaining sealing material and rust from mixing into the piping during installation work.
- Water treatment
The water quality standards have been established by the industry (Japan Refrigeration, Air Conditioning Industry Association, in case of Japan) for water treatment to be applied.

2) Thermal insulation work

Thermal insulation or anti sweating work is not required for the piping inside buildings in the case of the CITY MULTI WR2 system if the operating temperature range of circulation water stays within the temperature near the normal (summer : 29.4°C[85°F], winter : 21.1°C[70°F]). In case of the conditions below, however, thermal insulation is required.

- Use of well water for heat source water
- Outdoor piping portions
- Indoor piping portions where freezing may be caused in winter
- A place where vapor condensation may be generated on piping due to an increase in dry bulb temperature inside the ceiling caused by the entry of fresh outdoor air
- Drain piping portions

Items	Lower mid-range temperature water system		Tendency	
	Recirculating water [20<T<60°C] [68<T<140°F]	Make-up water	Corrosive	Scale-forming
pH (25°C[77°F])	7.0 ~ 8.0	7.0 ~ 8.0	○	○
Electric conductivity (mS/m) (25°C[77°F])	30 or less	30 or less	○	○
(µS/cm) (25°C[77°F])	[300 or less]	[300 or less]		
Chloride ion (mg Cl/l)	50 or less	50 or less	○	
Sulfate ion (mg SO ₄ ²⁻ /l)	50 or less	50 or less	○	
Acid consumption (pH4.8) (mg CaCO ₃ /l)	50 or less	50 or less		○
Total hardness (mg CaCO ₃ /l)	70 or less	70 or less		○
Calcium hardness (mg CaCO ₃ /l)	50 or less	50 or less		○
Ionic silica (mg SiO ₂ /l)	30 or less	30 or less		○
Iron (mg Fe/l)	1.0 or less	0.3 or less	○	○
Copper (mg Cu/l)	1.0 or less	0.1 or less	○	
Sulfide ion (mg S ²⁻ /l)	not to be detected	not to be detected	○	
Ammonium ion (mg NH ₄ ⁺ /l)	0.3 or less	0.1 or less	○	
Residual chlorine (mg Cl/l)	0.25 or less	0.3 or less	○	
Free carbon dioxide (mg CO ₂ /l)	0.4 or less	4.0 or less	○	
Ryzner stability index	-	-	○	○

Reference : Guideline of Water Quality for Refrigeration and Air Conditioning Equipment. (JRA GL02E-1994)

In order to keep the water quality within such standards, you are kindly requested to conduct bleeding-off by overflow and periodical water quality tests, and use inhibitors to suppress condensation or corrosion. Since piping may be corroded by some kinds of inhibitor, consult an appropriate water treatment expert for proper water treatment.


4) Pump interlock

Operating the heat source unit without circulation water inside the water piping can cause a trouble. Be sure to provide interlocking for the unit operation and water circuit. Since the terminal block is being provided inside the unit, use it as required.

5) Handling plate heat exchangers for heat-source units

<Designing the piping system>

- Install a strainer (50 mesh or finer recommended) near the heat-source unit on the inlet side of the hot/cold water pipe and cooling-water pipe (hereafter referred to as water pipes) to prevent an infiltration of foreign materials of solid nature, such as dirt and sand, into the plate heat exchanger.
- Depending on the water quality, scale may form inside plate heat exchangers. Plate heat exchangers must be chemically cleaned regularly to remove scale formation. Install sluice valves on the water pipes, and provide ports for connecting a pipe between the sluice valves and the heat-source unit for chemical cleaning.
- On both the inlet and outlet sides of water pipes, provide a plug to remove trapped air and water (also to be used for cleaning heat-source units and for purging water before a period of nonuse in winter or at the end of an air conditioning season). Also, provide automatic air-vent valves where air is likely to be trapped (such as a pipe that runs vertically).
- In addition to installing the above-mentioned strainers, install a cleanable strainer near the pump pipe inlet.
- Keep the pipes properly insulated and take an appropriate measure against humidity to minimize heat loss and prevent freeze damage in severe cold climate.
- If the system is stopped during winter or at night in subfreezing temperatures, take appropriate measures to protect pipes from freezing (i.e., pipe purging and use of water-circulation pump or heater) and prevent resultant damage to the plate heat exchanger.



<Test run>

- Before performing a test run, check that the piping system is properly installed, especially the strainers, air-vents, automatic water-supply valves, expansion tanks, and systems.
- After the pipe system is filled with water, first, operate the pump alone to check the system for trapped air and adjust the water flow rate to prevent the plate heat exchanger from freezing. Take into consideration the water pressure loss before and after each heat-source unit, and make sure the water flow rate falls within the design water flow rate range. Stop the test run and correct any problems found, if any.
- At the completion of a test run, check the strainer at the inlet pipe of the heat-source unit and clean it as necessary.

<Daily maintenance>

- Controlling the water quality
Plate heat exchangers cannot be disassembled for cleaning and have no replaceable parts. Watch the water quality to prevent corrosion and scale formation. The quality of the water to be used for plate heat exchangers must meet the water quality guidelines JRA GL-02-1994 specified by Japan Refrigeration and Air conditioning Industry Association (JRAIA). (Refer to section 3) Water treatment and water quality control.)
- Controlling the circulation water flow rate
Insufficient water rate will cause freeze damage to plate heat exchangers. Check for insufficient water flow caused by clogged strainer, trapped air in the system, or malfunction of the circulation water pump. Flow rate can also be checked by measuring the temperature or pressure difference between the inlet and outlet of plate heat exchangers. If the temperature or pressure difference goes outside of the specified range, stop the operation, remove the cause of the problem, and resume operation.
- What to do when the freeze protection trips
If the freeze protection trips during operation, be sure to remove its cause before resuming operation. Tripped freeze protection indicates that the system is partially frozen, and resuming operation without removing the cause of the problem will result in freeze damage to plate heat exchangers and/or pipes as well as resultant refrigerant leaks and infiltration of water into the refrigerant circuit.

<Maintaining plate heat exchangers>

Plate heat exchangers must be maintained in a planned and periodical manner to prevent scale formation, which may cause performance loss or decrease water flow rate that result in freeze damage to the plate heat exchanger.

- ♦ Check the following items before the operating season.
 1. Check that the water quality meets the specified water quality.
 2. Clean the strainers.
 3. Check that the water flow rate is adequate.
 4. Check for proper operation (e.g., pressure, flow rate, inlet/outlet temperatures).

- ♦ Plate heat exchangers cannot be disassembled for cleaning. Clean them in the following way.
 1. Make sure that there is a pipe connection port on the water inlet pipe.
Use formic acid, citric acid, oxalic acid, acetic acid, or phosphoric acid diluted to 5% to clean plate heat exchangers. Do not use highly corrosive acids, such as hydrochloric acid, sulfuric acid, or nitric acid.
 2. Make sure that valves are installed before the inlet connection port and after the outlet connection port.
 3. Connect a pipe for circulating cleaning solution to the inlet/outlet pipes of the plate heat exchanger, fill the plate heat exchanger with cleaning solution at a temperature between 50 and 60°C, and circulate the cleaning solution with a pump for 2 to 5 hours. The cleaning time will depend on the temperature of the cleaning solution and the degree of scale formation. Use the color of the cleaning solution as a guide to determine how long the system needs to be cleaned.
 4. When done, discharge the cleaning solution out of the plate heat exchanger, fill it with sodium hydrate (NaOH) or sodium bicarbonate (NaHCO₃) diluted with water to 1 to 2%, and let the solution be circulated for 15 to 20 minutes until the cleaning solution is neutralized.
 5. After neutralizing the cleaning solution, thoroughly rinse the plate heat exchanger with clean water.
 6. When using a commercially available cleaning solution, make sure to use a solution not corrosive to stainless steel or copper.
 7. Consult the cleaning solution manufacture for details.

- ♦ At the completion of cleaning, check the system for proper operation.

WR2


9-1. JOINT

CITY MULTI units can be easily connected by using Joint sets and Header sets provided by Mitsubishi Electric. Three kinds of Joint sets are available for use. Refer to section 3 in "System Design" or the Installation Manual that comes with the Joint set for how to install the Joint set.


CMY-Y102SS-G2

mm

For Gas pipe:



For Liquid pipe:




*Pipe diameter is indicated by inside diameter.


CMY-Y102LS-G2

mm

For Gas pipe:



For Liquid pipe:




*Pipe diameter is indicated by inside diameter.


CMY-Y202S-G2

mm

For Gas pipe:





For Liquid pipe:




*Pipe diameter is indicated by inside diameter.

9-2. OUTDOOR TWINNING KIT

The following optional Outdoor Twinning Kit is needed to use to combine multiple refrigerant pipes. Refer to the chapter entitled System Design Section for the details of selecting a proper twinning kit.



Note 1. Refer to the figure below for the installation position of the twinning pipe.



Slope of the twinning pipe is at an angle within $\pm 15^\circ$ to the horizontal plane.

2. Use the attached pipe to braze the port-opening of the distributor.
3. Pipe diameter is indicated by inside diameter.
4. Only use the Twinning pipe by Mitsubishi (optional parts) .

9-3. JOINT KIT "CMY-R160-J1" FOR BC CONTROLLER

Joint kit "CMY-R160-J1" for BC controller is used to combine 2 ports of the BC controller at a PURY/PQRY system so as to enable down-stream Indoor capacity above P80 as shown in Fig. 1.

The Joint kit include following items:



① Instruction	② Joint pipe(Small)	③ Joint pipe(Large)	④ Cover 1	⑤ Cover 2	⑥ Cover 3	⑦ Band	⑧ Reducer 1	⑨ Reducer 2
This sheet 1pc	1pc	1pc	2pcs	1pc for gas side	1pc for liquid side	8pcs	OD19.05-ID22.2 1pc	OD19.05-ID15.88 1pc

Please prepare the following items in the field. ①Tape for insulation material sealing ②Extension pipe for refrigerant circuit

② Joint pipe (for liquid side)

③ Joint pipe (for gas side)

mm (in.)



1. Designing CMY-R160-J1 to a PURY/PQRY system

The maximum down-stream Indoor capacity for 1 port of BC controller is P80. When the down-stream Indoor capacity is above P80, Joint kit CMY-R160-J1 is needed to combined 2 ports of BC controller to enlarge the capacity, like Group 2 and 3 in Fig. 1.

Maximum 3 Indoor units are allowed to connect to 1 port of BC controller or 2 combined ports of BC controller using CMY-R160-J1.

When connecting Indoor units to 1 port of BC controller or 2 combined ports of BC controller using CMY-R160-J1 or CMY-Y102SS-G2 is applicable, like Group 1 and 2 in Fig. 1

Caution: Mixed cooling and heating mode at the same time for Indoor units connecting to 1 port or 2 combined ports is not available.




Fig.1. CMY-R160-J1 applying scheme

2. Piping at the installation site

The connection of CMY-R160-J1 to BC controller and pipe leading to Indoor units is referable to Fig. 2. Non-oxidized brazing is necessary. All piping must be careful to avoid foreign material getting inside.

After piping and air-tight testing, insulation work to the Joint and pipe should be done. Details is available at the Installation Manual.




Fig.2. Connecting CMY-R160-J1



CITY MULTI

SYSTEM DESIGN WY SERIES

1. Electrical work.....	166
1-1.General cautions	166
1-2.Power supply for Indoor unit and Heat source unit.....	167
1-3.Power cable specifications	168
1-4.Power supply examples.....	169
2. M-NET control.....	171
2-1.Transmission cable length limitation.....	171
2-2.Transmission cable specifications	172
2-3.System configuration restrictions.....	173
2-4.Address setting.....	177
3. Piping Design.....	190
3-1.R410A Piping material	190
3-2.Piping Design	192
3-3.Refrigerant charging calculation	194
4. Installation.....	196
4-1.Requirement on installation site	196
4-2.Spacing.....	196
4-3.Caution on selecting heat source unit	196
4-4.Piping direction	197
5. Installation information.....	198
5-1.General precautions	198
5-2.Precautions for Indoor unit	199
5-3.Precautions for Fresh air intake type indoor unit.....	200
5-4.Precautions for Outdoor unit/Heat source unit	200
5-5.Precautions for Control-related items	201
6. Caution for refrigerant leakage	202
6-1.Refrigerant property.....	202
6-2.Confirm the Critical concentration and take countermeasure.....	202

1-1. General cautions

- ① Follow ordinance of your governmental organization for technical standard related to electrical equipment, wiring regulations, and guidance of each electric power company.
- ② Wiring for control (hereinafter referred to as transmission cable) shall be (50mm[1-5/8in.] or more) apart from power source wiring so that it is not influenced by electric noise from power source wiring. (Do not insert transmission cable and power source wire in the same conduit.)
- ③ Be sure to provide designated grounding work to Heat source unit.
- ④ Give some allowance for wiring for electrical part box of indoor and Heat source unit, because the box is sometimes removed at the time of service work.
- ⑤ Never connect 380~415V(220~240V) power source to terminal block of transmission cable. If connected, electrical parts will be damaged.
- ⑥ Use 2-core shield cable for transmission cable. If transmission cables of different systems are wired with the same multiple-core cable, the resultant poor transmitting and receiving will cause erroneous operations.
- ⑦ When extending the transmission line, make sure to extend the shield cable as well.



1-2. Power supply for Indoor unit and Heat source unit

1-2-1. Electrical characteristics of Heat source unit at cooling mode

Symbols: MCA (Max Circuit Amps)

RLA (Rated Load Amps), SC (Starting Current)

PQHY-P-Y(S)LM	Unit combination	Heat source units			Compressor		RLA(A)		
		Hz	Volts	Voltage range	MCA(A)	Output (kW)	SC(A)	Cooling 380/400/415V	Heating 380/400/415V
PQHY-P200YLM-A	-	50/60	380 400 415	Max:456 Min:342	16.1	4.8	8	6.2/5.9/5.7	6.7/6.3/6.1
PQHY-P250YLM-A	-				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
PQHY-P300YLM-A	-				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
PQHY-P350YLM-A	-				23.1	9.5		12.0/11.4/11.0	12.7/12.0/11.6
PQHY-P400YLM-A	-				27.6	10.7		13.5/12.8/12.4	14.1/13.4/12.9
PQHY-P450YLM-A	-				32.9	11.6		15.6/14.8/14.3	16.5/15.7/15.1
PQHY-P500YLM-A	-				39.2	13.0		18.8/17.9/17.2	19.2/18.3/17.6
PQHY-P550YLM-A	-				40.5	15.0		21.1/20.1/19.3	20.7/19.6/18.9
PQHY-P600YLM-A	-				40.5	16.1		24.4/23.2/22.3	24.4/23.2/22.4
PQHY-P400YSLM-A	PQHY-P200YLM-A				16.1	4.8		6.2/5.9/5.7	6.7/6.3/6.1
	PQHY-P200YLM-A				16.1	4.8		6.2/5.9/5.7	6.7/6.3/6.1
PQHY-P450YSLM-A	PQHY-P200YLM-A				16.1	4.8		6.2/5.9/5.7	6.7/6.3/6.1
	PQHY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
PQHY-P500YSLM-A	PQHY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
	PQHY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
PQHY-P550YSLM-A	PQHY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
	PQHY-P300YLM-A				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
PQHY-P600YSLM-A	PQHY-P300YLM-A				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
	PQHY-P300YLM-A				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
PQHY-P700YSLM-A	PQHY-P350YLM-A				23.1	9.5		12.0/11.4/11.0	12.7/12.0/11.6
	PQHY-P350YLM-A	23.1	9.5	12.0/11.4/11.0	12.7/12.0/11.6				
PQHY-P750YSLM-A	PQHY-P350YLM-A	23.1	9.5	12.0/11.4/11.0	12.7/12.0/11.6				
	PQHY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
PQHY-P800YSLM-A	PQHY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
	PQHY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
PQHY-P850YSLM-A	PQHY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
	PQHY-P450YLM-A	32.9	11.6	15.6/14.8/14.3	16.5/15.7/15.1				
PQHY-P900YSLM-A	PQHY-P450YLM-A	32.9	11.6	15.6/14.8/14.3	16.5/15.7/15.1				
	PQHY-P450YLM-A	32.9	11.6	15.6/14.8/14.3	16.5/15.7/15.1				

1-3. Power cable specifications

Thickness of wire for main power supply, capacities of the switch and system impedance

	Model	Minimum wire thickness (mm ²)			Ground-fault interrupter *1	Local switch (A)		Breaker for wiring (A) (Non-fuse breaker)	Max. Permissible System Impedance
		Main cable	Branch	Ground		Capacity	Fuse		
Heat source unit	PQHY-P200YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQHY-P250YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQHY-P300YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQHY-P350YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQHY-P400YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	32	32	30	0.26Ω
	PQHY-P450YLM-A	6.0	-	6.0	40A 100mA 0.1sec. or less	40	40	40	0.22Ω
	PQHY-P500YLM-A	6.0	-	6.0	40A 100mA 0.1sec. or less	40	40	40	0.18Ω
	PQHY-P550YLM-A	10.0	-	10.0	60A 100mA 0.1sec. or less	63	63	60	0.17Ω
Total operating current of the indoor unit	F0 = 16A or less *3	1.5	1.5	1.5	20A current sensitivity *4	16	16	20	(apply to IEC61000-3-3)
	F0 = 25A or less *3	2.5	2.5	2.5	30A current sensitivity *4	25	25	30	(apply to IEC61000-3-3)
	F0 = 32A or less *3	4.0	4.0	4.0	40A current sensitivity *4	32	32	40	(apply to IEC61000-3-3)

*1 The Ground-fault interrupter should support Inverter circuit.

The Ground-fault interrupter should combine using of local switch or wiring breaker.

*2 Meet technical requirements of IEC61000-3-3.

*3 Please take the larger of F1 or F2 as the value for F0.

F1 = Total operating maximum current of the indoor units × 1.2

F2 = {V1 × (Quantity of Type1)/C} + {V1 × (Quantity of Type2)/C} + {V1 × (Quantity of Type3)/C} + {V1 × (Quantity of Others)/C}

Indoor unit		V1	V2
Type1	PLFY-VBM, PMFY-VBM, PEFY-VMS1, PCFY-VKM, PKFY-VHM, PKFY-VKM, PFFY-VKM, PFFY-VLRMM	18.6	2.4
Type2	PEFY-VMA	38	1.6
Type3	PEFY-VMHS	13.8	4.8
Others	Other indoor unit	0	0

C: Multiple of tripping current at tripping time 0.01s

Please pick up "C" from the tripping characteristic of the breaker.


<Example of "F2" calculation>

*Condition PEFY-VMS1 × 4 + PEFY-VMA × 1, C = 8 (refer to right sample chart)

F2 = 18.6 × 4/8 + 38 × 1/8

= 14.05

→16 A breaker (Tripping current = 8 × 16 A at 0.01s)



*4 Current sensitivity is calculated using the following formula.

G1 = (V2 × Quantity of Type1) + (V2 × Quantity of Type2) + (V2 × Quantity of Type3) + (V2 × Quantity of Others) + (V3 × Wire length [km])

G1	Current sensitivity	Wire thickness	V3
30 or less	30 mA 0.1sec or less	1.5 mm ²	48
100 or less	100 mA 0.1sec or less	2.5 mm ²	56
		4.0 mm ²	66

1. Use dedicated power supplies for the outdoor unit and indoor unit. Ensure OC and OS are wired individually.
2. Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
3. The wire size is the minimum value for metal conduit wiring. If the voltage drops, use a wire that is one rank thicker in diameter. Make sure the power-supply voltage does not drop more than 10%. Make sure that the voltage imbalance between the phases is 2% or less.
4. Specific wiring requirements should adhere to the wiring regulations of the region.
5. Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 245 IEC57). For example, use wiring such as YZW.
6. A switch with at least 3 mm contact separation in each pole shall be provided by the Air Conditioner installer.

WARNING

- ◆ Be sure to use specified wires for connections and ensure no external force is imparted to terminal connections. If connections are not fixed firmly, heating or fire may result.
- ◆ Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current.

CAUTION

- ◆ The breakers for current leakage should support Inverter circuit. (e.g. Mitsubishi Electric's NV-S series or equivalent). If no earth leakage breaker is installed, it may cause an electric shock.
- ◆ Breakers for current leakage should combine using of switch.
- ◆ Do not use anything other than a breaker with the correct capacity. Using a breaker of too large capacity may cause malfunction or fire.
- ◆ If a large electric current flows due to malfunction or faulty wiring, earth-leakage breakers on the unit side and on the upstream side of the power supply system may both operate. Depending on the importance of the system, separate the power supply system or take protective coordination of breakers.

Note

- ◆ This device is intended for the connection to a power supply system with a maximum permissible system impedance shown in the above table at the interface point (power service box) of the user's supply.
- ◆ The user must ensure that this device is connected only to a power supply system which fulfils the requirement above. If necessary, the user can ask the public power supply company for the system impedance at the interface point.
- ◆ This equipment complies with IEC 61000-3-12 provided that the short-circuit power Ssc is greater than or equal to Ssc(*2) at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power Ssc greater than or equal to Ssc(*2).


Ssc(*2)

Model	PQHY-P200YLM-A	PQHY-P250YLM-A	PQHY-P300YLM-A	PQHY-P350YLM-A	PQHY-P400YLM-A	PQHY-P450YLM-A	PQHY-P500YLM-A	PQHY-P550YLM-A	PQHY-P600YLM-A
Ssc (MVA)	1.25	1.25	1.44	1.79	2.14	2.55	3.04	3.14	3.14

1-4. Power supply examples


The local standards and/or regulations is applicable at a higher priority.

1-4-1. PQHY-P200-600YLM



Note:

- 1 The transmission cable is not-polarity double-wire.
- 2 Symbol © means a screw terminal for wiring.
- 3 The shield wire of transmission cable should be connected to the grounding terminal at Heat source unit. All shield wire of M-Net transmission cable among Indoor units should be connected to the S terminal at Indoor unit or all shield wire should be connected together.
The broken line at the scheme means shield wire.
- 4 When the Heat source unit connected with system controller, power-supply to TB7 of the heat source unit(s) is needed. The connector change from CN41 to CN40 at one of the heat source units will enable the heat source unit to supply power to TB7, or an extra power supplying unit PAC-SC51KUA should be used. The transmission cable (above 1.25mm², shielded, CVVS/CPEVS/MVVS) among Heat source units and system controllers is called centralized control transmission cable. The shield wire of whose centralized control transmission cable must be grounded at the Heat source unit whose CN41 is changed to CN40. When the power supplying unit PAC-SC51KUA is used, connect the shielded cable to the ground terminal on the PAC-SC51KUA.
- 5 MA R/C transmission cable (0.3-1.25mm²) must be less than 200m in length, while ME R/C transmission cable (0.3-1.25mm²) must be less than 10m in length. But transmission cable to the ME R/C can be extend using a M-NET cable (>=1.25mm²) when the length is counted in the M-Net length.
- 6 MA remote controller and ME remote controller should not be grouped together. When a PAR-3X MAA series (X indicates 1, 2, ...) is connected to a group, no other MA remote controllers can be connected to the same group.
- 7 If using 1 or 2 (main/sub) MA remote controller to control more than 1 Indoor unit, use MA transmission cable to connect all the TB15 terminals of the Indoor units. It is called "Grouping".
If using 1 or 2 (main/sub) ME remote controller control more than 1 Indoor unit, set address to Indoor unit and ME remote controller. For the method, refer to 2-4. "Address Setting".
- 8 Indoor board consumes power from TB3. The power balance should be considered according to System Design 2-3 "System configuration restrictions".
- 9 If Transmission booster is needed, be sure to connect the shield wires to the both sides to the booster.
- 10 The critical current for choosing power source equipment is approximate 1.4 times of total rated current of the Heat source unit(s) or Indoor unit(s).
- 11 When System controller (SC) is connected to the system, turn the SW5-1 on.
- 12 The phases of electricity power must be confirmed to be right used. Phase-reverse, or phase-missing could break the controllers.




Symbol	Model	Ground-fault interrupter *1, *2, *4	Local switch		Wiring breaker*4 (NFB) <A>	Minimum Wire thickness		
			BKC <A>	OCP*3, *4 <A>		Power wire <mm²>	Earth wire <mm²>	
GFI	Ground-fault interrupter	PQHY-P200YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
LW	Local switch	PQHY-P250YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
BKC	Breaker capacity	PQHY-P300YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
OCP	Over-current protector	PQHY-P350YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
WB	Wiring breaker	PQHY-P400YLM-A	30A 100mA 0.1sec. or less	32	32	30	4	4
NFB	Non-fuse breaker	PQHY-P450YLM-A	40A 100mA 0.1sec. or less	40	40	40	6	6
HU	Heat source unit	PQHY-P500YLM-A	40A 100mA 0.1sec. or less	40	40	40	6	6
IU	Indoor unit	PQHY-P550YLM-A	60A 100mA 0.1sec. or less	63	63	60	10	10
SC	System controller	PQHY-P600YLM-A	60A 100mA 0.1sec. or less	63	63	60	10	10

*1 The Ground-fault interrupter should support Inverter circuit. (e.g. Mitsubishi Electric's NV-S series or equivalent).
 *2 Ground-fault interrupter should combine using of local switch or wiring breaker.
 *3 It shows data for B-type fuse of the breaker for current leakage.
 *4 If a large electric current flows due to malfunction or faulty wiring, earth-leakage breakers on the unit side and on the centralized controller side may both operate.
 Depending on the importance of the system, separate the power supply system or take protective coordination of breakers.

The local standards and/or regulations is applicable at a higher priority.



1-4-2. PQHY-P400-900YSLM

<In the case a system controller is connected.>



Note:

- 1 The transmission cable is not-polarity double-wire.
- 2 Symbol Ⓞ means a screw terminal for wiring.
- 3 The shield wire of transmission cable should be connected to the grounding terminal at Heat source unit. All shield wire of M-Net transmission cable among indoor units should be connected to the S terminal at Indoor unit or all shield wire should be connected together.
The broken line at the scheme means shield wire.
- 4 When the Heat source unit connected with system controller, power-supply to TB7 of the heat source unit(s) is needed. The connector change from CN41 to CN40 at one of the heat source units will enable the heat source unit to supply power to TB7, or an extra power supplying unit PAC-SC51KUA should be used. The transmission cable (above 1.25mm², shielded, CVVS/CPEVS/MVVS) among Heat source units and system controllers is called centralized control transmission cable. The shield wire of the centralized control transmission cable must be grounded at the Heat source unit whose CN41 is changed to CN40. When the power supplying unit PAC-SC51KUA is used, connect the shielded cable to the ground terminal on the PAC-SC51KUA.
- 5 MA R/C transmission cable (0.3-1.25mm²) must be less than 200m in length, while ME R/C transmission cable (0.3-1.25mm²) must be less than 10m in length. But transmission cable to the ME R/C can be extend using a M-NET cable (>=1.25mm²) when the length is counted in the M-Net length.
- 6 MA remote controller and ME remote controller should not be grouped together. When a PAR-3X MAA series (X indicates 1, 2,...) is connected to a group, no other MA remote controllers can be connected to the same group.
- 7 If using 1 or 2 (main/sub) MA remote controller to control more than 1 Indoor unit, use MA transmission cable to connect all the TB15 terminals of the Indoor units. It is called "Grouping".
If using 1 or 2 (main/sub) ME remote controller control more than 1 indoor unit, set address to Indoor unit and ME remote controller. For the method, refer to 2-4. "Address Setting".
- 8 Indoor board consumes power from TB3. The power balance should be considered according to System Design 2-3 "System configuration restrictions".
- 9 If Transmission booster is needed, be sure to connect the shield wires to the both sides to the booster.
- 10 The critical current for choosing power source equipment is approximate 1.4 times of total rated current of the Heat source unit(s) or Indoor unit(s).
- 11 When System controller (SC) is connected to the system, turn the SW5-1 on.
- 12 The phases of electricity power must be confirmed to be right used. Phase-reverse, or phase-missing could break the controllers.



Symbol	Model	Ground-fault interrupter *1, *2, *4	Local switch			Wiring breaker*4		Minimum Wire thickness	
			BKC <A>	OCP*3, *4 <A>	(NFB) <A>	Power wire <mm ² >	Earth wire <mm ² >		
GFI	Ground-fault interrupter	PQHY-P200YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4	
LW	Local switch	PQHY-P250YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4	
BKC	Breaker capacity	PQHY-P300YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4	
OCP	Over-current protector	PQHY-P350YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4	
WB	Wiring breaker	PQHY-P400YLM-A	30A 100mA 0.1sec. or less	32	32	30	4	4	
NFB	Non-fuse breaker	PQHY-P450YLM-A	40A 100mA 0.1sec. or less	40	40	40	6	6	

*1 The Ground-fault interrupter should support Inverter circuit. (e.g. Mitsubishi Electric's NV-S series or equivalent).

*2 Ground-fault interrupter should combine using of local switch or wiring breaker.

*3 It shows data for B-type fuse of the breaker for current leakage.

*4 If a large electric current flows due to malfunction or faulty wiring, earth-leakage breakers on the unit side and on the centralized controller side may both operate.


Depending on the importance of the system, separate the power supply system or take protective coordination of breakers.

2-1. Transmission cable length limitation

2-1-1. Using MA Remote controller

Long transmission cable causes voltage down, therefore, the length limitation should be obeyed to secure proper transmission.

Max. length via Heat source (M-NET cable)	$L1+L2+L3, L1+L2+L4+L5, L3+L4+L5$	$\leq 500m[1640ft.]$	1.25mm ² [AWG16] or thicker
Max. length to Heat source (M-NET cable)	$L1+L6, L3, L4, L2+L4+L6, L5$	$\leq 200m[656ft.]$	1.25mm ² [AWG16] or thicker
Max. length from MA to Indoor	$a1+a2, a1+a2+a3+a4$	$\leq 200m[656ft.]$	0.3-1.25 mm ² [AWG22-16]
24VDC to AG-150A	n	$\leq 50m[164ft.]$	0.75-2.0 mm ² [AWG18-14]




OC, OS: Heat source unit controller; IC: Indoor unit controller; MA: MA remote controller

2-1-2. Using ME Remote controller

Long transmission cable causes voltage down, therefore, the length limitation should be obeyed to secure proper transmission.

Max. length via Heat source (M-NET cable)	$L1+L2+L3+L4, L1+L2+L6+L7, L1+L2+L3+L5, L3+L4+L6+L7$	$\leq 500m[1640ft.]$	1.25mm ² [AWG16] or thicker
Max. length to Heat source (M-NET cable)	$L1+L8, L3+L4, L6, L2+L6+L8, L7, L3+L5$	$\leq 200m[656ft.]$	1.25mm ² [AWG16] or thicker
Max. length from ME to Indoor	$e1, e2+e3, e4$	$\leq 10m[32ft.]*1$	0.3-1.25 mm ² [AWG22-16] *1
24VDC to AG-150A	n	$\leq 50m[164ft.]$	0.75-2.0 mm ² [AWG18-14]

*1. If the length from ME to Indoor exceed 10m, use 1.25 mm² [AWG16] shielded cable, but the total length should be counted into Max. length via Heat source.



OC, OS: Heat source unit controller; IC: Indoor unit controller; ME: ME remote controller

2-2. Transmission cable specifications

	Transmission cables (Li)	M-NET remote controller cables (ei)	MA Remote controller cables (ai)
Type of cable	Shielding wire (2-core) CVVS, CPEVS or MVVS	Sheathed 2-core cable (unshielded) CVV	
Cable size	More than 1.25 mm ² [AWG16]	0.3 ~ 1.25 mm ² [AWG22~16]	0.3 ~ 1.25 mm ² [AWG22 ~16]*1
Remarks	Max length: within 200 m	When 10 m [32ft] is exceeded, use cables with the same specification as transmission cables.	Max length: 200 m [656ft]

*1 To wire PAR-3X MAA series (X indicates 1, 2...) and Simple
MA remote controller use a wire with a diameter of 0.3 mm² [AWG22]

CVVS, MVVS: PVC insulated PVC sheathed shielded control cable
CPEVS: PE insulated PVC sheathed shielded communication cable
CVV: PVC insulated PVC sheathed control cable

2-3. System configuration restrictions

2-3-1. Common restrictions for the CITYMULTI system

For each Heat source unit, the maximum connectable quantity of Indoor unit is specified at its Specifications table.

- A) 1 Group of Indoor units can have 1-16 Indoor units;
*OA processing unit GUF-RD(H) is considered as Indoor unit.
- B) Maximum 2 remote controllers for 1 Group;
*MA/ME remote controllers cannot be present together in 1group.
*When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.
- C) 1 LOSSNAY unit can interlock maximum 16 Indoor units; 1 Indoor unit can interlock only 1 LOSSNAY unit.
- D) Maximum 3 System controllers are connectable when connecting to TB3 of the Heat source unit.
- E) 4 System controllers or more are connectable when connecting to TB7 of the Heat source unit, if the transmission power is supplied by the power supply unit PAC-SC51KUA. Details refer to (C) below.
*System controller connected as described in D) and E) would have a risk that the failure of connected Heat source unit would stop power supply to the System controller.

2-3-2. Ensuring proper communication power and the number of connected units for M-NET

In order to ensure proper communication among Outdoor/Heat source unit, Indoor unit, LOSSNAY, OA processing unit GUF-RD(H), and Controllers, the transmission power situation for the M-NET should be observed. In some cases, Transmission booster should be used. Taking the power consumption of Indoor unit sized P15-P140 as 1, the equivalent power consumption or supply of others are listed at Table 1 and Table 2.

Both the transmission line for centralized controller and indoor-outdoor transmission line must meet the conditions listed below. (Both conditions a) and b) must be met.)

- a) [Total equivalent power consumption] ≤ [The equivalent power supply]
- b) [Total equivalent number of units] ≤ [40]

Table 1 The equivalent power consumption and the equivalent number of units

Category	Model	The equivalent power consumption	The equivalent number of units
Indoor, OA unit	Sized P15-P140 GUF-50, 100	1	1
Indoor unit	Sized P200, P250	7	2
BC controller	CMB	2	1
PWFY	P100VM-E-BU	6	1
	P100VM-E1-AU P100VM-E2-AU	1	1
	P200VM-E1-AU P200VM-E2-AU	5	1
MA remote controller/LOSSNAY	PAR-31MAAE PAC-YT52CRA PAR-FA32MA LGH-RX5-E PZ-60DR-E PZ-43SMF-E	0	0
ME remote controller	PAR-U02MEDA PAC-IF01AHC-J	0.5	1
System controller	AE-200E AE-50E EW-50E	0	0
	AG-150A EB-50GU-J	0.5	1
	AT-50B	1.5	5
	PAC-YG60MCA PAC-YG66DCA PAC-YG63MCA	0.25	1
ON/OFF controller	PAC-YT40ANRA	1	1
MN converter	CMS-MNG-E	2	1
Outdoor/Heat source unit	TB7 power consumption	0	0

Table 2 The equivalent power supply

Category	Model	The equivalent power supply
Transmission Booster	PAC-SF46EPA	25
Power supply unit	PAC-SC51KUA	5
Expansion controller	PAC-YG50ECA	6
BM ADAPTER	BAC-HD150	6
System controller	AE-200E/AE-50E	0 *1
	EW-50E	1.5 *1
Outdoor/Heat source unit	Connector TB3 and TB7 total *	32
	Connector TB7 only	6


*If PAC-SC51KUA is used to supply power at TB7 side, no power supply need from Outdoor/Heat source unit at TB7, Connector TB3 itself will therefore have 32. Not applicable to the PUMY model.

*1 AE-200E/AE-50E/EW-50E has a built-in function to supply power to the M-NET transmission line. The amount of power that an AE-200E or an AE-50E can supply is equivalent to the power required by an MN converter (CMS-MNG-E) that is used for maintenance. An MN converter is connectable to EW-50E only when the equivalent power consumption is less than 1.5.

With the equivalent power consumption values and the equivalent number of units in Table 1 and Table 2, PAC-SF46EPA can be designed into the air-conditioner system to ensure proper system communication according to (A), (B), (C).

- (A) Firstly, count from TB3 at TB3 side the total equivalent number of units of Indoor units, OA processing units, ME remote controller, and System controllers. If the total equivalent number of units reaches 40, a PAC-SF46EPA should be set. In this case, Indoor units sized P200 and 250 are counted as 2, AT-50B is counted as 5, but MA remote controller(s), PZ-60DR-E, and PZ-43SMF-E are NOT counted.
- (B) Secondly, count from TB7 side to TB3 side the total transmission power consumption. If the total power consumption reaches 32, a PAC-SF46EPA should be set. Yet, if a PAC-SC51KUA or another controller with a built-in power supply, such as PAC-YG50ECA, is used to supply power at TB7 side, count from TB3 side only.
- (C) Thirdly, count from TB7 at TB7 side the total transmission power consumption, If the total power consumption reaches 6, a PAC-SF46EPA should be set. Also, count from TB7 at TB7 side the total equivalent number of units of System controllers, and so on. If the total equivalent number of units reaches 40, a PAC-SF46EPA should be set.

■ System example



2-3-3. Ensuring proper power supply to System controller

The power to System controller (excluding AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) is supplied via M-NET transmission line. M-NET transmission line at TB7 side is called Centralized control transmission line while one at TB3 side is called Indoor-Heat source transmission line. There are 3 ways to supply power to the System controller.


- A) Connecting to TB3 of the Heat source unit and receiving power from the Heat source unit.
- B) Connecting to TB7 of the Heat source unit and receiving power from the Heat source unit.
- C) Connecting to TB7 of the Heat source unit but receiving power from power supply unit PAC-SC51KUA.

* System controllers (AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) have a built-in function to supply power to the M-NET transmission lines, so no power needs to be supplied to the M-NET transmission lines from the Heat source units or from PAC-SC51KUA.

2-3-3-A. When connecting to TB3 of the Heat source unit and receiving power from the Heat source unit.

Maximum 3 System controllers can be connected to TB3. If there is more than 1 Heat source unit, it is necessary to replace power supply switch connector CN41 with CN40 on one Heat source unit.


Fig. 2-3-3-A



2-3-3-B. When connecting to TB7 of the Heat source unit and receiving power from the Heat source unit.

Maximum 6 System controllers can be connected to TB7 and receiving power from the Heat source unit. It is necessary to replace power supply switch connector CN41 with CN40 on one Heat source unit.

Fig. 2-3-3-B




2-3-3-C. When connecting to TB7 of the Heat source unit but receiving power from PAC-SC51KUA.

When using PAC-SC51KUA to supply transmission power, the power supply connector CN41 on the Heat source units should be kept as it is. It is also a factory setting.

1 PAC-SC51KUA supports maximum 1 AG-150A or 1 EB-50GU-J unit due to the limited power 24VDC at its TB3. However, 1 PAC-SC51KUA supplies transmission power at its TB2 equal to 5 Indoor units, which is referable at Table 2. If System controller, ON/OFF controller connected to TB7 consume transmission power more than 5 (Indoor units), Transmission booster PAC-SF46EPA is needed. PAC-SF46EPA supplies transmission power equal to 25 Indoor units.

Fig. 2-3-3-C



CAUTION

■ AG-150A/EB-50GU-J*1 are recommended to connect to TB7 because it performs back-up to a number of data.

In an air conditioner system has more than 1 Heat source units, AG-150A/EB-50GU-J receiving transmission power at TB3 or TB7 on one of the Heat source units would have a risk that the connected Heat source unit failure would stop power supply to AG-150A/EB-50GU-J, and disrupt the whole system.

When applying apportioned electric power function, AG-150A/EB-50GU-J are necessary to connected to TB7 and has its own power supply unit PAC-SC51KUA.


Note: Power supply unit PAC-SC51KUA is for AG-150A/EB-50GU-J.

*1: AG-150A is an example model of system controllers.

■ How to connect system controllers (AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) to a given system System controllers (AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) have a built-in function to supply power to the M-NET transmission lines, so no power needs to be supplied to the M-NET transmission lines from the Heat source units or from PAC-SC51KUA.

Leave the power supply connector on the Heat source unit connected to CN41 as it is. Refer to 2-3-2 for information about the power-supply capacity of each system controller (EW-50E, BAC-HD150, LM-AP) to the low-level system controllers.

Fig. 2-3-3-D



2-3-4. Power supply to LM-AP

1-phase 220-240VAC power supply is needed.

The power supply unit PAC-SC51KUA is not necessary when connecting only the LM-AP. Yet, make sure to change the power supply changeover connector CN41 to CN40 on the LM-AP.

2-3-5. Power supply to expansion controller

1-phase 100-240VAC power supply is needed.

The power supply unit PAC-SC51KUA is not necessary.

The expansion controller supplies power through TB3, which equals 6 indoor units. (refer to Table 2)

2-3-6. Power supply to BM ADAPTER

1-phase 100-240VAC power supply is needed.

The power supply unit PAC-SC51KUA is not necessary when only BM ADAPTER is connected.

Yet, make sure to move the power jumper from CN41 to CN40 on the BM ADAPTER.

2-3-7. Power supply to AE-200E/AE-50E/EW-50E

1-phase 100-240VAC power supply is needed.


The power supply unit PAC-SC51KUA is not necessary when connecting only the AE-200E/AE-50E/EW-50E.

2-4. Address setting

2-4-1. Switch operation

In order to constitute CITY MULTI in a complete system, switch operation for setting the unit address No. and connection No. is required.

- ① Address No. of Heat source unit, indoor unit and remote controller.
The address No. is set at the address setting board.
In the case of WR2 system, it is necessary to set the same No. at the branch No. switch of indoor unit as that of the BC controller connected. (When connecting two or more branches, use the lowest branch No.)



② Caution for switch operations

- Be sure to shut off power source before switch setting. If operated with power source on, switch can not operate properly.
- No units with identical unit address shall exist in one whole air conditioner system. If set erroneously, the system can not operate.

③ MA remote controller

- When connecting only one remote controller to one group, it is always the main remote controller. When connecting two remote controllers to one group, set one remote controller as the main remote controller and the other as the sub remote controller.
- The factory setting is "Main".

PAR-3X MAA series (X indicates 1, 2...)

The MA remote controller does not have the switches listed above.
Refer to the installation manual for the function setting.





































PAC-YT52CRA

Setting the dip switches

There are switches on the back of the top case. Remote controller Main/Sub and other function settings are performed using these switches. Ordinarily, only change the Main/Sub setting of SW1.
(The factory settings are ON for SW1, 2, and 3 and OFF for SW4.)

SW No.	SW contents Main	ON	OFF	Comment
1	Remote controller Main/Sub setting	Main	Sub	Set one of the two remote controllers at one group to "ON".
2	Temperature display units setting	Celsius	Fahrenheit	When the temperature is displayed in [Fahrenheit], set to "OFF".
3	Cooling/heating display in AUTO mode	Yes	No	When you do not want to display "Cooling" and "Heating" in the AUTO mode, set to "OFF".
4	Indoor temperature display	Yes	No	When you want to display the indoor temperature, set to "ON".

2-4-2. Rule of setting address

Unit		Address setting	Example	Note
Indoor unit		01 ~ 50	 	Use the most recent address within the same group of indoor units. Make the indoor units address connected to the BC controller (Sub) larger than the indoor units address connected to the BC controller (Main). If applicable, set the sub BC controllers in an PQR system in the following order: (1) Indoor unit to be connected to the BC controller (Main) (2) Indoor unit to be connected to the BC controller (No.1 Sub) (3) Indoor unit to be connected to the BC controller (No.2 Sub) Set the address so that (1)<(2)<(3)
Heat source unit		51 ~ 99, 100 (Note1)	 	The smallest address of indoor unit in same refrigerant system + 50 Assign sequential address numbers to the heat source units in one refrigerant circuit system. OC and OS are automatically detected. (Note 2) *Please reset one of them to an address between 51 and 99 when two addresses overlap. *The address automatically becomes "100" if it is set as "01~ 50"
BC controller (Main)		52 ~ 99, 100	 	The address of heat source unit + 1 *Please reset one of them to an address between 51 and 99 when two addresses overlap. *The address automatically becomes "100" if it is set as "01~ 50"
BC controller (Sub)		52 ~ 99, 100	 	Lowest address within the indoor units connected to the BC controller (Sub) plus 50.
Local remote controller	ME Remote controller (Main)	101 ~ 150	1 Fixed  	The smallest address of indoor unit in the group + 100 *The place of "100" is fixed to "1"
	ME Remote controller (Sub)	151 ~ 199, 200	1 Fixed  	The address of main remote controller + 50 *The address automatically becomes "200" if it is set as "00"
System controller	ON/OFF remote controller	000, 201 ~ 250	  	The smallest group No. to be managed + 200 * The smallest group No. to be managed is changeable.
	AE-200E/AE-50E AG-150A AT-50B EB-50GU-J EW-50E	000, 201 ~ 250	  	
	PAC-YG50ECA	000, 201 ~ 250	  	* Settings are made on the initial screen of AG-150A.
	BAC-HD150	000, 201 ~ 250	  	* Settings are made with setting tool of BM ADAPTER.
	LMAP04-E	201 ~ 250	2 Fixed  	
PI, AI, DIDO	PAC-YG60MCA	01 ~ 50	 	
	PAC-YG63MCA	01 ~ 50	 	
	PAC-YG66DCA	01 ~ 50	 	
Lossnay, OA processing unit		01 ~ 50	 	After setting the addresses of all the indoor units, assign an arbitrary address.
PAC-IF01AHC		201 ~ 250	2 Fixed  	

Note1: To set the address to "100", set it to "50"

Note2: Heat source units OC and OS in one refrigerant circuit system are automatically detected.

OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.

2-4-3. System examples

Factory setting


Original switch setting of the heat sources, indoors, controllers, LM-AP, and BM ADAPTER at shipment is as follows.

- Heat source unit : Address: 00, CN41: ON (Jumper), DipSW5-1: OFF
- Indoor unit : Address: 00
- ME remote controller : Address: 101
- LM-AP : Address: 247, CN41: ON (Jumper), DipSW1-2: OFF
- BM ADAPTER : Address: 000, CN41: ON (Jumper)
- AE-200E/AE-50E/EW-50E : Address: 000, CN21: ON (Jumper)

Setting at the site

- DipSW5-1(Heat source) : When the System Controller is used, all the Dip SW5-1 at the heat source units should be set to "ON". * Dip SW5-1 remains OFF when only LM-AP is used.
- DipSW1-2(LM-AP) : When the LM-AP is used together with System Controller, DipSW1-2 at the LM-AP should be set to "ON".
- CN40/CN41 : Change jumper from CN41 to CN 40 at heat source control board will activate central transmission power supply to TB7;
(Change jumper at only one heat source unit when activating the transmission power supply without using a power supply unit.)
Change jumper from CN41 to CN 40 at LM-AP/BM ADAPTER will activate transmission power supply to LM-AP/BM ADAPTER itself;
Power supply unit is recommended to use for a system having more than 1 heat source unit, because the central transmission power supply from TB7 of one of heat source units is risking that the heat source unit failure may let down the whole central control system.
- CN21(AE-200E/AE-50E/EW-50E) : Activates the power supply to M-NET transmission line from AE-200E/AE-50E/EW-50E (CN21: ON (power supplied), OFF (power not supplied))


2-4-3-1. MA remote controller, Single-refrigerant-system, No System Controller




*1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.

NOTE:

1. Heat source units OC and OS in one refrigerant circuit system are automatically detected. OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.
2. No address setting is needed.
3. For a system having more than 32 indoor unit (P15-P140), confirm the need of Booster at 2-3 "System configuration restrictions".
4. When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.





2-4-3-3. MA remote controller, Multi-refrigerant-system, System Controller at TB7/TB3 side, Booster for long M-NET wiring




- *1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.
- *2 System controller should connect to TB7 at Heat source unit and use power supply unit together in Multi-Refrigerant-System.
For AG-150A, 24V DC should be used with the PAC-SC51KUA.
For AE-200E, AE-50E, and EW-50E the power supply unit PAC-SC51KUA is unused.
- *3 When multiple system controllers are connected in the system, set the controller with more functions than others as a "main" controller and others as "sub".
AE-200E, AE-50E, EW-50E, BAC-HD150, and LM-AP are for exclusive use as a "main" system controller and cannot be used as a "sub" system controller.
Make the setting to only one of the system controllers for "prohibition of operation from local remote controller".
- *4 The power supply unit is not necessary for AE-200E, AE-50E, EW-50E, BAC-HD150, and LM-AP.

NOTE:

1. Heat source units OC and OS in one refrigerant circuit system are automatically detected.
OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.
2. Address should be set to Indoor units, LOSSNAY and system controller.
3. M-NET power is supplied by the Heat source unit at TB3, while Indoor unit and ME remote controller consume the M-NET power for transmission use. The power balance is needed to consider for long M-NET wiring. Details refer to 2-3 "System configuration restrictions".
4. When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.



2-4-3-6. ME remote controller, Multi-refrigerant-system, System Controller at TB 7side, LOSSNAY, Booster for long M-NET wiring



*1 System controller should connect to TB7 at Heat source unit and use power supply unit together in Multi-Refrigerant-System.

For AG-150A, 24V DC should be used with the PAC-SC51KUA.

For AE-200E, AE-50E, and EW-50E the power supply unit PAC-SC51KUA is unused.

*2 When multiple system controllers are connected in the system, set the controller with more functions than others as a "main" controller and others as "sub".


AE-200E, AE-50E, EW-50E, BAC-HD150, and LM-AP are for exclusive use as a "main" system controller and cannot be used as a "sub" system controller.

*3 The power supply unit is not necessary for AE-200E, AE-50E, EW-50E, BAC-HD150, and LM-AP.

NOTE:

- Heat source units OC and OS in one refrigerant circuit system are automatically detected. OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.
- M-NET power is supplied by the Heat source unit at TB3, while Indoor unit and ME remote controller consume the M-NET power for transmission use. The power balance is needed to consider for long M-NET wiring. Details refer to 2-3 "System configuration restrictions".


2-4-3-7. ME remote controller, Multi-refrigerant-system, No Power supply unit



NOTE

- It is necessary to change the connector to CN40 on the heat source unit control board (only one heat source unit) when the group is set between other refrigerant systems.
- It is necessary to set on the remote controller by manual when group sets on the different refrigerant system. Please refer to remote controller installation manual.


2-4-3-8. ME remote controller, Multi-refrigerant-system, System Controller at TB7 side, No Power supply unit



NOTE

- It is necessary to change the connector to CN40 on the heat source unit control board (only one heat source unit) when the group is set between other refrigerant systems.
- It is necessary to set on the remote controller by manual when group sets on the different refrigerant system. Please refer to remote controller installation manual.


2-4-3-9. TG-2000A(*1)+AE-200E/AE-50E/EW-50E
 AE-200E can control max. 50 indoor units;
 TG-2000A can control max. 40 of AE-200E/AE-50E/EW-50E;*2
 TG-2000A can control max. 2000 indoor units.



*1 TG-2000A (Ver.6.5 or later) supports AE-200E/AE-50E (Ver.7.10 or later).
 TG-2000A (Ver.6.60 or later) supports EW-50E.
 *2 When AE-200E connected with AE-50E is connected, the number of AE-50E will be the maximum controllable number.
 TG-2000A can control up to 40 AE-200E/AE-50E or AE-200E without AE-50E connection.
 *3 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.
 *4 When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-10. AE-200E + AE-50E/EW-50E

AE-200E can control max. 200 indoor units/via AE-50E/EW-50E.




*1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.

*2 When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-11. LM-AP


LM-AP can transmit for max. 50 indoor units;
 If system controller (SC) is used, DipSW1-2 at LM-AP and DipSW5-1 at Heat source unit should set to "ON".
 Change Jumper from CN41 to CN40 to activate power supply to LM-AP itself for those LM-AP connected without system controller (SC).



2-4-3-12. BM ADAPTER


BM ADAPTER can transmit for max. 50 indoor units;
 Change Jumper from CN41 to CN40 to activate power supply to BM ADAPTER itself for those BM ADAPTER connected without the power supply unit.

BM ADAPTER can transmit for max. 50 indoor units in single-refrigerant-system or multi-refrigerant-system.



*1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.
 *2 When a PAR-3X MAA series (X indicates 1, 2,...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-13. BM ADAPTER+AE-200E/AE-50E/EW-50E



NOTE

- It is not necessary to connect the M-NET transmission line to the TB3 on BM ADAPTER. Leave the power jumper of BM ADAPTER connected to CN41.
- *1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.
- *2 Consult your dealer for restrictions when connecting both AE-200E/AE-50E/EW-50E and BM ADAPTER.
- *3 When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.
- *4 In a system that uses AE-200E and/or AE-50E/EW-50E, each BM-ADAPTER must be connected to the M-NET line.

3-1. R410A Piping material

Refrigerant pipe for CITY MULTI shall be made of phosphorus deoxidized copper, and has two types.

A. Type-O: Soft copper pipe (annealed copper pipe), can be easily bent with human's hand.

B. Type-1/2H pipe: Hard copper pipe (Straight pipe), being stronger than Type-O pipe of the same radical thickness.

The maximum operation pressure of R410A air conditioner is 4.30 MPa [623psi]. The refrigerant piping should ensure the safety under the maximum operation pressure. MITSUBISHI ELECTRIC recommends pipe size as Table 3-1, or You shall follow the local industrial standard. Pipes of radical thickness 0.7mm or less shall not be used.

Table 3-1. Copper pipe size and radial thickness for R410A CITY MULTI.



Size (mm)	Size (inch)	Radial thickness (mm)	Radial thickness (mil)	Pipe type
ø6.35	ø1/4"	0.8	[32]	Type-O
ø9.52	ø3/8"	0.8	[32]	Type-O
ø12.7	ø1/2"	0.8	[32]	Type-O
ø15.88	ø5/8"	1.0	[40]	Type-O
ø19.05	ø3/4"	1.2	[48]	Type-O
ø19.05	ø3/4"	1.0	[40]	Type-1/2H or H
ø22.2	ø7/8"	1.0	[40]	Type-1/2H or H
ø25.4	ø1"	1.0	[40]	Type-1/2H or H
ø28.58	ø1-1/8"	1.0	[40]	Type-1/2H or H
ø31.75	ø1-1/4"	1.1	[44]	Type-1/2H or H
ø34.93	ø1-3/8"	1.2	[48]	Type-1/2H or H
ø41.28	ø1-5/8"	1.4	[56]	Type-1/2H or H

* For pipe sized ø19.05 (3/4") for R410A air conditioner, choice of pipe type is up to you.

* The figures in the radial thickness column are based on the Japanese standards and provided only as a reference. Use pipes that meet the local standards.

Flare

Due to the relative higher operation pressure of R410A compared to R22, the flare connection should follow dimensions mentioned below so as to achieve enough the air-tightness.


Flare pipe	Pipe size	A (For R410A) (mm[in.])	Flare nut	Pipe size	B (For R410A) (mm[in.])
	ø6.35 [1/4"]	9.1		ø6.35 [1/4"]	17.0
	ø9.52 [3/8"]	13.2		ø9.52 [3/8"]	22.0
	ø12.70 [1/2"]	16.6		ø12.70 [1/2"]	26.0
	ø15.88 [5/8"]	19.7		ø15.88 [5/8"]	29.0
	ø19.05 [3/4"]	24.0		ø19.05 [3/4"]	36.0

Procedures for installing the branched pipes


Refer to the instructions that came with the branched pipe kit (separately sold) for details.

[1] Branches on the indoor-unit side

■Joint




Horizontal installation



Vertical installation



(The branched pipes must face up.)
Indoor-unit side (branched pipe)



Outdoor/heat source-unit side (main pipe)

- Restrictions for installing the joint described here only apply to CMY-Y202S-G2 and CMY-Y302S-G2 in the gas line.
- CMY-Y202S-G2 and CMY-Y302S-G2 in the gas line must be installed horizontally (see figure above) or with the branched pipes facing up.
- If the size of the refrigerant pipe that is selected by following the instructions under 3-2. Piping Design does not match the size of the joint, use a reducer to connect them. A reducer is included in the kit.


■Header



- No restrictions apply to the installation of the header.
- If the size of the refrigerant pipe that is selected by following the instructions under 3-2. Piping Design does not match the size of the header, cut the pipe to an appropriate size using a pipe cutter, or use a reducer to connect them.
- If the number of header branches exceeds the number of pipes to be connected, cap the unused header branches. Caps are included in the kit.

[2] Branches on the outdoor/heat source-unit side

Note. Refer to the figure below for the installation position of the twinning pipe.




Slope of the twinning pipes are at an angle within $\pm 15^\circ$ to the horizontal plane.

- Inclination of the branched pipes
The inclination of the branched pipes must be $\pm 15^\circ$ or less against the horizontal plane. Excessive inclination of the branched pipes may damage the unit.
- Minimum length of the straight section of the pipe before the branched pipes
Always use the pipes supplied in the branched pipe kit, and make sure the straight section of the pipe immediately before it connects to the branched pipe is at least 500 mm. Failure to do so may damage the unit.

3-2. Piping Design

3-2-1. PQHY-P200-600YLM Piping



Note1. No Joint after Header; Piping direct to Indoor Unit from Header;
 Note2. As bents cause pressure loss on transportation of refrigerant, fewer bents design is better;
 Piping length needs to consider the actual length and equivalent length which bents are counted.
 Equivalent piping length (m)=Actual piping length+"M" x Number of bent.

Fig. 3-2-1A Piping scheme

IU: Indoor unit, HU: Heat source unit

Piping length			(m [ft.])		Bent equivalent length "M"	
Item	Piping in the figure	Max. length	Max. equivalent length	Heat source Model	M (m/bent)	M (ft./bent)
Total piping length	A+B+C+D+E+a+b+c+d+e+f+g	*1	-	PQHY-P200YLM	0.35	[1.15]
Farthest IU from HU (L1)	A+C+D+E+g / A+B+c	165 [541']	190 [623']	PQHY-P250YLM	0.42	[1.38]
Farthest IU from first Joint (L2)	C+D+E+g / B+c	40 [131']	40 [131']	PQHY-P300YLM	0.42	[1.38]
Height between HU and IU (HU above IU)	H	50 [164']	-	PQHY-P350YLM	0.50	[1.64]
Height between HU and IU (HU under IU)	H'	40 [131']	-	PQHY-P400YLM	0.50	[1.64]
Height between IU and IU	h1	15 [49']	-	PQHY-P450YLM	0.50	[1.64]
				PQHY-P500YLM	0.50	[1.64]
				PQHY-P550YLM	0.50	[1.64]
				PQHY-P600YLM	0.50	[1.64]

HU: Heat source Unit, IU: Indoor Unit
 *1 300 [984] for PQHY-P200-300YLM, 500 [1640] for PQHY-P350-600YLM

Piping "A" size selection rule (mm [in.])

Heat source unit	Pipe(Liquid)	Pipe(Gas)
PQHY-P200YLM	ø9.52 [3/8"]	ø19.05 [3/4"]
PQHY-P250YLM	ø9.52 [3/8"]*1	ø22.20 [7/8"]
PQHY-P300YLM	ø9.52 [3/8"]*2	ø22.20 [7/8"]
PQHY-P350YLM	ø12.70 [1/2"]	ø28.58 [1-1/8"]
PQHY-P400-600YLM	ø15.88 [5/8"]	ø28.58 [1-1/8"]

*1. L1>=90m [295ft.], ø12.70mm [1/2in.]; L1<90m [295ft.], ø9.52mm [3/8in.]
 *2. L1>=40m [131ft.], ø12.70mm [1/2in.]; L1<40m [131ft.], ø9.52mm [3/8in.]

Selection criteria for joints

Total down-stream Indoor capacity	Joint
~ P200	CMY-Y102SS-G2
P201 ~ P400	CMY-Y102LS-G2
P401 ~ P650	CMY-Y202S-G2
P651 ~	CMY-Y302S-G2

*Concerning detailed usage of Joint parts, refer to its Installation Manual.

See the table below for the first joint of the heat source unit described below.

Heat source unit model	Joint model
P250 to P300	CMY-Y102LS-G2
P350 to P600	CMY-Y202S-G2

Piping "B", "C", "D", "E" size selection rule (mm [in.])

Total down-stream Indoor capacity	Pipe(Liquid)	Pipe(Gas)
~ P140	ø9.52 [3/8"]	ø15.88 [5/8"]
P141 ~ P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P201 ~ P300	ø9.52 [3/8"]	ø22.20 [7/8"]
P301 ~ P400	ø12.70 [1/2"]	ø28.58 [1-1/8"]
P401 ~ P650	ø15.88 [5/8"]	ø28.58 [1-1/8"]
P651 ~ P800	ø19.05 [3/4"]	ø34.93 [1-3/8"]
P801 ~	ø19.05 [3/4"]	ø41.28 [1-5/8"]

Header selection rule

	4-branch Header	8-branch Header	10-branch Header
	CMY-Y104-G	CMY-Y108-G	CMY-Y1010-G
Total down-stream Indoor capacity	<=P200	<=P350	<=P600

* CMY-Y104-G can directly connect PQHY-P200YLM-A, but can NOT directly connect PQHY-P250YLM-A or above;
 * CMY-Y108-G can directly connect PQHY-P200-350YLM-A, but can NOT directly connect PQHY-P400Y(S)LM-A or above;
 * CMY-Y1010-G can directly connect PQHY-P200-600Y(S)LM-A;
 * CMY-Y104-G can NOT connect P200,P250 Indoor, but CMY-Y108, Y1010-G can do;
 * Concerning detailed usage of Header parts, refer to its Installation Manual.

Piping "a", "b", "c", "d", "e", "f", "g" size selection rule (mm [in.])

Indoor Unit size	Pipe(Liquid)	Pipe(Gas)
P15,P20,P25,P32,P40,P50,GUF-50RD(H)	ø6.35 [1/4"]	ø12.70 [1/2"]
P63,P71,P80,P100,P125,P140,GUF-100RD(H)	ø9.52 [3/8"]	ø15.88 [5/8"]
P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P250	ø9.52 [3/8"]	ø22.20 [7/8"]

Note3. Indoor capacity is described as its model size;
 For example, PEFY-P32VMA-E, its capacity is P32;
 Note4. Total down-stream Indoor capacity is the summary of the model size of Indoors downstream.
 For example, PEFY-P25VMA-E+PEFY-P32VMA-E: Total Indoor capacity=P25+P32=P57
 Note5. Piping sized determined by the Total down-stream indoor capacity is NOT necessary to be bigger than the up-stream one.
 i.e. A>=B; A>C>=D

3-2-2. PQHY-P400-900YSLM Piping

Note1. No Joint after Header; Piping direct to Indoor Unit from Header;
 Note2. As bents cause pressure loss on transportation of refrigerant, fewer bents design is better;
 Piping length needs to consider the actual length and equivalent length which bents are counted.
 Equivalent piping length (m)=Actual piping length+"M" x Number of bent.




Fig. 3-2-2A Piping scheme

IU: Indoor unit, HU: Heat source unit

Piping length		(m [ft.])		Bent equivalent length "M"	
Item	Piping in the figure	Max. length	Max. equivalent length	Heat source Model	M (m/bent [ft./bent])
Total piping length	S+T+A+B+C+D+E+a+b+c+d+e+f+g	500 [1640']	-	PQHY-P400YSLM	0.50 [1.64]
Distance between HU and HU	S+T	10[32']	-	PQHY-P450YSLM	0.50 [1.64]
Height between HU and HU	h2	0.1[0.3']	-	PQHY-P500YSLM	0.50 [1.64]
Farthest IU from HU (L1)	S(T)+A+C+D+E+g / S(T)+A+B+c	165 [541']	190 [623']	PQHY-P550YSLM	0.50 [1.64]
Farthest IU from the first Joint (L2)	C+D+E+g / B+c	40 [131']	40 [131']	PQHY-P600YSLM	0.50 [1.64]
Height between HU and IU (HU above IU)	H	50 [164']	-	PQHY-P700YSLM	0.70 [2.29]
Height between HU and IU (HU under IU)	H'	40 [131']	-	PQHY-P750YSLM	0.70 [2.29]
Height between IU and IU	h1	15 [49']	-	PQHY-P800YSLM	0.70 [2.29]
				PQHY-P850YSLM	0.80 [2.62]
				PQHY-P900YSLM	0.80 [2.62]

HU: Heat source Unit, IU: Indoor Unit

Piping "A" size selection rule (mm [in.])

Heat source unit	Pipe(Liquid)	Pipe(Gas)
PQHY-P400-600YSLM	ø15.88 [5/8"]	ø28.58 [1-1/8"]
PQHY-P700-800YSLM	ø19.05 [3/4"]	ø34.93 [1-3/8"]
PQHY-P850-900YSLM	ø19.05 [3/4"]	ø41.28 [1-5/8"]

For Piping size "S", "T", please refer to specification of the Twinning kit CMY-Y100VBK3, CMY-Y200VBK2 at the Heat source unit's external drawing.

Selection criteria for joints

Total down-stream Indoor capacity	Joint
~ P200	CMY-Y102SS-G2
P201 ~ P400	CMY-Y102LS-G2
P401 ~ P650	CMY-Y202S-G2
P651 ~	CMY-Y302S-G2

*Concerning detailed usage of joint parts, refer to its Installation Manual.
 *The total capacity of the units in the downstream of the branch joint on at least one of the piping lines that are connected to the branch joint should be 650 or below.
 If the total capacity of the units in the downstream of the branch joints on both lines is 650 or above use two branch joints (CMY-Y302S-G2).

Piping "B", "C", "D", "E" size selection rule (mm [in.])

Total down-stream Indoor capacity	Pipe(Liquid)	Pipe(Gas)
~ P140	ø9.52 [3/8"]	ø15.88 [5/8"]
P141 ~ P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P201 ~ P300	ø9.52 [3/8"]	ø22.20 [7/8"]
P301 ~ P400	ø12.70 [1/2"]	ø28.58 [1-1/8"]
P401 ~ P650	ø15.88 [5/8"]	ø28.58 [1-1/8"]
P651 ~ P800	ø19.05 [3/4"]	ø34.93 [1-3/8"]
P801 ~	ø19.05 [3/4"]	ø41.28 [1-5/8"]

See the table below for the first joint of the heat source unit described below.

Heat source unit model	Joint model
P400 to P600	CMY-Y202S-G2
P700 to P900	CMY-Y302S-G2

Piping "a", "b", "c", "d", "e", "f", "g" size selection rule (mm [in.])

Indoor Unit size	Pipe(Liquid)	Pipe(Gas)
P15,P20,P25,P32,P40,P50,GUF-50RD(H)	ø6.35 [1/4"]	ø12.70 [1/2"]
P63,P71,P80,P100,P125,P140,GUF-100RD(H)	ø9.52 [3/8"]	ø15.88 [5/8"]
P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P250	ø9.52 [3/8"]	ø22.20 [7/8"]

Header selection rule

	4-branch Header	8-branch Header	10-branch Header
	CMY-Y104-G	CMY-Y108-G	CMY-Y1010-G
Total down-stream Indoor capacity	<=P200	<=P350	<=P600

* CMY-Y104-G can directly connect PQHY-P200YLM-A, but can NOT directly connect PQHY-P250YLM-A or above;
 * CMY-Y108-G can directly connect PQHY-P200-350YLM-A, but can NOT directly connect PQHY-P400Y(S)LM-A or above;
 * CMY-Y1010-G can directly connect PQHY-P200-600Y(S)LM-A;
 * CMY-Y104-G can NOT connect P200,P250 Indoor, but CMY-Y108, Y1010-G can do;
 * Concerning detailed usage of Header parts, refer to its Installation Manual.

Note3. Indoor capacity is described as its model size;
 For example, PEFY-P32VMA-E, its capacity is P32;
 Note4. Total down-stream Indoor capacity is the summary of the model size of Indoors downstream.
 For example, PEFY-P25VMA-E+PEFY-P32VMA-E: Total Indoor capacity=P25+P32=P57
 Note5. Piping sized determined by the Total down-stream indoor capacity is NOT necessary to be bigger than the up-stream one.
 i.e. A>=B; A>=C>=D

3-3. Refrigerant charging calculation

At the time of shipping, the heat source unit is charged with the refrigerant. As this charge does not include the amount needed for extended piping, additional charging for each refrigerant line will be required on site. In order that future servicing may be properly provided, always keep a record of the size and length of each refrigerant line and the amount of additional charge by writing it in the space provided on the heat source unit.

(1) Calculation of additional refrigerant charge

- Calculate the amount of additional charge based on the length of the piping extension and the size of the refrigerant line.
- Use the table below as a guide to calculate the amount of additional charging and charge the system accordingly.
- If the calculation results in a fraction of less than 0.1kg, round up to the next 0.1kg. For example, if the result of the calculation was 12.33kg, round the result up to 12.4kg.
- * When connecting PEFY-P20VMA3-E units, add 0.54 kg of refrigerant for each of these units.
- * When connecting PEFY-P25/32/40VMA3-E units, add 0.74 kg of refrigerant for each of these units.
- * When connecting PEFY-P50/63/71/80/100/125VMA3-E units, add 1.16 kg of refrigerant for each of these units.

<Additional Charge>

Units "m" and "kg"

<Formula>

- When the piping length from the heat source unit to the farthest indoor unit is 30.5 m (100 ft) or shorter

$$\begin{matrix} \boxed{\text{Amount of}} \\ \boxed{\text{additional}} \\ \boxed{\text{charge (kg)}} \end{matrix} = \begin{matrix} \boxed{\varnothing 19.05 \text{ total length}} \\ \boxed{\times 0.29 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 15.88 \text{ total length}} \\ \boxed{\times 0.2 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 12.7 \text{ total length}} \\ \boxed{\times 0.12 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 9.52 \text{ total length}} \\ \boxed{\times 0.06 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 6.35 \text{ total length}} \\ \boxed{\times 0.024 \text{ (kg/m)}} \end{matrix}$$


Heat source unit model	Amount (kg)	Total capacity of connected indoor units	Amount (kg)
P200	0	80 or below	2.0
P250	0	81 to 160	2.5
P300	0	161 to 330	3.0
P350	0	331 to 390	3.5
P400	0	391 to 480	4.5
P450	0	481 to 630	5.0
P500	0	631 to 710	6.0
P550	1	711 to 800	8.0
P600	1	801 to 890	9.0
		891 to 1070	10.0
		1071 to 1250	12.0
		1251 or above	14.0

- When the piping length from the heat source unit to the farthest indoor unit is longer than 30.5 m (100 ft)

$$\begin{matrix} \boxed{\text{Amount of}} \\ \boxed{\text{additional}} \\ \boxed{\text{charge (kg)}} \end{matrix} = \begin{matrix} \boxed{\varnothing 19.05 \text{ total length}} \\ \boxed{\times 0.26 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 15.88 \text{ total length}} \\ \boxed{\times 0.18 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 12.7 \text{ total length}} \\ \boxed{\times 0.11 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 9.52 \text{ total length}} \\ \boxed{\times 0.054 \text{ (kg/m)}} \end{matrix} + \begin{matrix} \boxed{\varnothing 6.35 \text{ total length}} \\ \boxed{\times 0.021 \text{ (kg/m)}} \end{matrix}$$

Heat source unit model	Amount (kg)	Total capacity of connected indoor units	Amount (kg)
P200	0	80 or below	2.0
P250	0	81 to 160	2.5
P300	0	161 to 330	3.0
P350	0	331 to 390	3.5
P400	0	391 to 480	4.5
P450	0	481 to 630	5.0
P500	0	631 to 710	6.0
P550	1	711 to 800	8.0
P600	1	801 to 890	9.0
		891 to 1070	10.0
		1071 to 1250	12.0
		1251 or above	14.0

Example: PQHY-P350YLM



Indoor	1: P125	A: ø12.7	40 m	a: ø9.52	10 m
	2: P100	B: ø9.52	10 m	b: ø9.52	5 m
	3: P40	C: ø9.52	15 m	c: ø6.35	10 m
	4: P32	D: ø9.52	10 m	d: ø9.52	10 m
	5: P63	e: ø12.7	10 m		

The total length of liquid pipe of each size is as follows:

- ø12.7: A + e = 40 + 10 = 50 m
- ø9.52: B + C + D + a + b + d = 10 + 15 + 10 + 10 + 5 + 10 = 60 m
- ø6.35: c = 10 = 10 m

Additional refrigerant charge (kg)	=	Total length of liquid pipe sized ø19.05 x 0.26 (kg/m)	+	Total length of liquid pipe sized ø15.88 x 0.18 (kg/m)	+	Total length of liquid pipe sized ø12.7 x 0.11 (kg/m)	+	Total length of liquid pipe sized ø9.52 x 0.054 (kg/m)	+	Total length of liquid pipe sized ø6.35 x 0.021 (kg/m)	+ 0 + 3.5
		0 (m) x 0.26 (kg/m)		0 (m) x 0.18 (kg/m)		50 (m) x 0.11 (kg/m)		60 (m) x 0.054 (kg/m)		10 (m) x 0.021 (kg/m)	
	=	0	+	0	+	50 x 0.11	+	60 x 0.054	+	10 x 0.021	+ 0 + 3.5
		= 12.5 (12.45) kg									

■ Limitation of the amount of refrigerant to be charged

The above calculation result of the amount of refrigerant to be charged must become below the value in the table below.

Total index of the heat source units		P200 YLM	P250 YLM	P300 YLM	P350 YLM	P400 YLM	P450 YLM	P500 YLM	P550 YLM	P600 YLM	P400 YSLM	P450 YSLM	P500 YSLM	P550 YSLM	P600 YSLM
Maximum refrigerant charge	Factory charged	5.0kg	5.0kg	5.0kg	6.0kg	6.0kg	6.0kg	6.0kg	11.7kg	11.7kg	10.0kg	10.0kg	10.0kg	10.0kg	10.0kg
	Charged on site	21.0kg	28.0kg	29.5kg	41.5kg	50.0kg	51.5kg	53.5kg	55.5kg	57.0kg	50.0kg	51.5kg	53.5kg	54.5kg	55.5kg
	Total for system	26.0kg	33.0kg	34.5kg	47.5kg	56.0kg	57.5kg	59.5kg	67.2kg	68.7kg	60.0kg	61.5kg	63.5kg	64.5kg	65.5kg

Total index of the heat source units		P700 YSLM	P750 YSLM	P800 YSLM	P850 YSLM	P900 YSLM
Maximum refrigerant charge	Factory charged	12.0kg	12.0kg	12.0kg	12.0kg	12.0kg
	Charged on site	65.5kg	67.5kg	67.5kg	70.0kg	70.0kg
	Total for system	77.5kg	79.5kg	79.5kg	82.0kg	82.0kg

4-1. Requirement on installation site


1. No direct thermal radiation to the unit.
2. No possibility of annoying the neighbors by the sound of the unit.

Valves and refrigerant flow on the Heat source unit may generate noise.

3. Avoid the sites where strong winds blow.
4. With strength to bear the weight of the unit.
5. Drain flow from the unit is cared at heating mode.
6. Enough space for installation and service as shown at 4-2.
7. Avoid the sites where acidic solutions or chemical sprays (sulfur series) are used frequently.
8. The unit should be secure from combustible gas, oil, steam, chemical gas like acidic solution, sulfur gas and so on.

4-2. Spacing

In case of single installation, 600mm or more of back space as front space makes easier access when servicing the unit from rear side.



4-3. Caution on selecting heat source unit


Consult your dealer when the following issues on WY system are the key concern.

- **Warm air** may flow out from the indoor unit during heating Thermo-OFF.
- **Refrigerant flow sound** may occur in the rooms with low background noise such as hotel rooms, hospital rooms, bedrooms, or conference rooms.

To avoid the above issues on WY system, changing board settings on the indoor and outdoor units is required.

Ask AC&R Works for details.

4-4. Piping direction



- (A) Main circulating water pipe
- (B) Shutoff valve
- (C) Shutoff valve
- (D) Water outlet (upper)
- (E) Refrigerant pipes
- (F) Y-type strainer
- (G) Water inlet (lower)
- (H) Drain pipe

1. Insulation installation

With City Multi WY/ WR2 Series piping, as long as the temperature range of the circulating water is kept to average temperatures year-round (29.4°C[85°F] in the summer, 21.1°C[70°F] in the winter), there is no need to insulate or otherwise protect indoor piping from exposure. You should use insulation in the following situations:

- Any heat source piping.
- Indoor piping in cold-weather regions where frozen pipes are a problem.
- When air coming from the outside causes condensation to form on piping.
- Any drainage piping.

2. Water processing and water quality control

To preserve water quality, use the closed type of cooling tower for WY/ WR2. When the circulating water quality is poor, the water heat exchanger can develop scales, leading to a reduction in heat-exchange power and possible corrosion of the heat exchanger. Please pay careful attention to water processing and water quality control when installing the water circulation system.

- Removal of foreign objects or impurities within the pipes.
During installation, be careful that foreign objects, such as welding fragments, sealant particles, or rust, do not enter the pipes.
- Water Quality Processing

① Depending on the quality of the cold-temperature water used in the air conditioner, the copper piping of the heat exchanger may become corroded. We recommend regular water quality processing.

Cold water circulation systems using open heat storage tanks are particularly prone to corrosion.

When using an open-type heat storage tank, install a water-to-water heat exchanger, and use a closed-loop circuit on the air conditioner side. If a water supply tank is installed, keep contact with air to a minimum, and keep the level of dissolved oxygen in the water no higher than 1mg/ℓ.

② Water quality standard

Items	Lower mid-range temperature water system		Tendency		
	Recirculating water [20<T<60°C] [68<T<140°F]	Make-up water	Corrosive	Scale-forming	
Standard items	pH (25°C)[77°F]	7.0 ~ 8.0	7.0 ~ 8.0	○	○
	Electric conductivity (mS/m) (25°C)[77°F]	30 or less	30 or less	○	○
	(μS/cm) (25°C)[77°F]	[300 or less]	[300 or less]		
	Chloride ion (mg Cl/ℓ)	50 or less	50 or less	○	
	Sulfate ion (mg SO ₄ ²⁻ /ℓ)	50 or less	50 or less	○	
	Acid consumption (pH4.8) (mg CaCO ₃ /ℓ)	50 or less	50 or less		○
	Total hardness (mg CaCO ₃ /ℓ)	70 or less	70 or less		○
Reference items	Calcium hardness (mg CaCO ₃ /ℓ)	50 or less	50 or less		○
	Ionic silica (mg SiO ₂ /ℓ)	30 or less	30 or less		○
	Iron (mg Fe/ℓ)	1.0 or less	0.3 or less	○	○
	Copper (mg Cu/ℓ)	1.0 or less	0.1 or less	○	
	Sulfide ion (mg S ²⁻ /ℓ)	not to be detected	not to be detected	○	
	Ammonium ion (mg NH ₄ ⁺ /ℓ)	0.3 or less	0.1 or less	○	
	Residual chlorine (mg Cl/ℓ)	0.25 or less	0.3 or less	○	
Free carbon dioxide (mg CO ₂ /ℓ)	0.4 or less	4.0 or less	○		
Ryzner stability index	-	-	○	○	

Reference : Guideline of Water Quality for Refrigeration and Air Conditioning Equipment. (JRA GL02E-1994)

- ③ Please consult with a water quality control specialist about water quality control methods and water quality calculations before using anti-corrosive solutions for water quality management.
- ④ When replacing a previously installed air conditioning device (even when only the heat exchanger is being replaced), first conduct a water quality analysis and check for possible corrosion. Corrosion can occur in cold-water systems even if there has been no prior signs of corrosion. If the water quality level has dropped, please adjust water quality sufficiently before replacing the unit.

5-1. General precautions

5-1-1. Usage

- The air-conditioning system described in this Data Book is designed for human comfort.
- This product is not designed for preservation of food, animals, plants, precision equipment, or art objects. To prevent quality loss, do not use the product for purposes other than what it is designed for.
- To reduce the risk of water leakage and electric shock, do not use the product for air-conditioning vehicles or vessels.

5-1-2. Installation environment

- Do not install any unit other than the dedicated unit in a place where the voltage changes a lot, large amounts of mineral oil (e.g., cutting oil) are present, cooking oil may splash, or a large quantity of steam can be generated such as a kitchen.
- Do not install the unit in acidic or alkaline environment.
- Installation should not be performed in the locations exposed to chlorine or other corrosive gases. Avoid near a sewer.
- To reduce the risk of fire, do not install the unit in a place where flammable gas may be leaked or inflammable material is present.
- This air conditioning unit has a built-in microcomputer. Take the noise effects into consideration when deciding the installation position. Especially in a place where antenna or electronic device are installed, it is recommended that the air conditioning unit be installed away from them.
- Install the unit on a solid foundation according to the local safety measures against typhoons, wind gusts, and earthquakes to prevent the unit from being damaged, toppling over, and falling.

5-1-3. Backup system

- In a place where air conditioner's malfunctions may exert crucial influence, it is recommended to have two or more systems of single outdoor/heat source units with multiple indoor units.

5-1-4. Unit characteristics

- Heat pump efficiency depends on outdoor temperature. In the heating mode, performance drops as the outside air temperature drops. In cold climates, performance can be poor. Warm air would continue to be trapped near the ceiling and the floor level would continue to stay cold. In this case, heat pumps require a supplemental heating system or air circulator. Before purchasing them, consult your local distributor for selecting the unit and system.
- When the outdoor temperature is low and the humidity is high, the heat exchanger on the outdoor/heat source unit side tends to collect frost, which reduces its heating performance. To remove the frost, Auto-defrost function will be activated and the heating mode will temporarily stop for 3-10 minutes. Heating mode will automatically resume upon completion of defrost process.
- Air conditioner with a heat pump requires time to warm up the whole room after the heating operation begins, because the system circulates warm air in order to warm up the whole room.
- The sound levels were obtained in an anechoic room. The sound levels during actual operation are usually higher than the simulated values due to ambient noise and echoes. Refer to the section on "SOUND LEVELS" for the measurement location.
- Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes even when operating normally. Please consider to avoid location where quietness is required. For BC controller, it is recommended to unit to be installed in places such as ceilings of corridor, restrooms and plant rooms.
- The total capacity of the connected indoor units can be greater than the capacity of the outdoor/heat source unit. However, when the connected indoor units operate simultaneously, each unit's capacity may become smaller than the rated capacity.
- When the unit is started up for the first time within 12 hours after power on or after power failure, it performs initial startup operation (capacity control operation) to prevent damage to the compressor. The initial startup operation requires 90 minutes maximum to complete, depending on the operation load.

5-1-5. Relevant equipment

- Use an earth leakage breaker (ELB) with medium sensitivity, and an activation speed of 0.1 second or less.
- Consult your local distributor or a qualified technician when installing an earth leakage breaker.
- If the unit is inverter type, select an earth leakage breaker for handling high harmonic waves and surges.
- Leakage current is generated not only through the air conditioning unit but also through the power wires. Therefore, the leakage current of the main power supply is greater than the total leakage current of each unit. Take into consideration the capacity of the earth leakage breaker or leakage alarm when installing one at the main power supply. To measure the leakage current simply on site, use a measurement tool equipped with a filter, and clamp all the four power wires together. The leakage current measured on the ground wire may not accurate because the leakage current from other systems may be included to the measurement value.
- Do not install a phase advancing capacitor on the unit connected to the same power system with an inverter type unit and its equipment.
- If a large current flows due to the product malfunctions or faulty wiring, both the earth leakage breaker on the product side and the upstream overcurrent breaker may trip almost at the same time. Separate the power system or coordinate all the breakers depending on the system's priority level.

5-1-6. Unit installation

- Your local distributor or a qualified technician must read the Installation Manual that is provided with each unit carefully before performing installation work.
- Consult your local distributor or a qualified technician when installing the unit. Improper installation by an unqualified person may result in water leakage, electric shock, or fire.
- Ensure there is enough space around each unit.

5-1-7. Optional accessories

- Only use accessories recommended by Mitsubishi Electric. Consult your local distributor or a qualified technician when installing them. Improper installation by an unqualified person may result in water leakage, electric leakage, system breakdown, or fire.
- Some optional accessories may not be compatible with the air conditioning unit to be used or may not be suitable for the installation conditions. Check the compatibility when considering any accessories.
- Note that some optional accessories may affect the air conditioner's external form, appearance, weight, operating sound, and other characteristics.

5-1-8. Operation/Maintenance

- Read the Instruction Book that is provided with each unit carefully prior to use.
- Maintenance or cleaning of each unit may be risky and require expertise. Read the Instruction Book to ensure safety. Consult your local distributor or a qualified technician when special expertise is required such as when the indoor unit needs to be cleaned.

5-2. Precautions for Indoor unit

5-2-1. Operating environment

- The refrigerant (R410A) used for air conditioner is non-toxic and nonflammable. However, if the refrigerant leaks, the oxygen level may drop to harmful levels. If the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration from exceeding the safety limit even if the refrigerant should leak.
- If the units operate in the cooling mode at the humidity above 80%, condensation may collect and drip from the indoor units.

5-2-2. Unit characteristics

- The return air temperature display on the remote controller may differ from the ones on the other thermometers.
- The clock on the remote controller may be displayed with a time lag of approximately one minute every month.
- The temperature using a built-in temperature sensor on the remote controller may differ from the actual room temperature due to the effect of the wall temperature.
- Use a built-in thermostat on the remote controller or a separately-sold thermostat when indoor units installed on or in the ceiling operate the automatic cooling/heating switchover.
- The room temperature may rise drastically due to Thermo OFF in the places where the air conditioning load is large such as computer rooms.
- Be sure to use a regular filter. If an irregular filter is installed, the unit may not operate properly, and the operation noise may increase.
- The room temperature may rise over the preset temperature in the environment where the heating air conditioning load is small.

5-2-3. Unit installation

- For simultaneous cooling/heating operation type air conditioners (R2, WR2 series), the G-type BC controller cannot be connected to the 16HP outdoor/heat source unit model or above, and the G- and GA-type BC controllers cannot be connected to the 28HP model or above. The GB- and HB-type BC controllers (sub) cannot be connected to the outdoor/heat source unit directly, and be sure to use them with GA- and HA-type BC controllers (main).
- The insulation for low pressure pipe between the BC controller and outdoor/heat source unit shall be at least 20 mm thick. If the unit is installed on the top floor or in a high-temperature, high-humidity environment, thicker insulation may be necessary.
- Do not have any branching points on the downstream of the refrigerant pipe header.
- When a field-supplied external thermistor is installed or when a device for the demand control is used, abnormal stop of the unit or damage of the electromagnetic contactor may occur. Consult your local distributor for details.
- When indoor units operate a fresh air intake, install a filter in the duct (field-supplied) to remove the dust from the air.
- The 4-way or 2-way Airflow Ceiling Cassette Type units that have an outside air inlet can be connected to the duct, but need a booster fan to be installed at site. Refer to the chapter "Indoor Unit" for the available range for fresh air intake volume.
- Operating fresh air intake on the indoor unit may increase the sound pressure level.

5-3. Precautions for Fresh air intake type indoor unit

5-3-1. Usage

- This unit mainly handles the outside air load, and is not designed to maintain the room temperature. Install other air conditioners for handling the air conditioning load in the room.

5-3-2. Unit characteristics

- This unit cannot perform the drying operation. The unit will continue the fan operation and blow fresh air (air that is not air-conditioned) when the Heating Thermo-OFF or Cooling Thermo-OFF mode is selected.
- The fan may stop tentatively when the unit is connected to the simultaneous cooling/heating operation type outdoor/heat source unit (R2, WR2 series) or during the defrost cycle.
- This unit switches the Thermo ON or OFF depending on the room temperature. The outside air is directly supplied into the room during Thermo OFF. Take caution of the cold supply air due to low outside air temperature and of condensation in the room due to high humidity of the outside air.
- Outside air temperature ranges for the operation must be as follows:
Cooling: 21°C D.B./15.5°C W.B. ~ 43°C D.B./35°C W.B.
Heating: -10°C D.B. ~ 20°C D.B.
The unit is forced to operate Thermo OFF (fan operation) when the outside air temperature is as follows.
Cooling: 21°C D.B. or below; Heating: 20°C D.B. or above
- Either a remote controller (sold separately) or a remote sensor (sold separately) must be installed to monitor the room temperature.
- If only this unit is used as an indoor unit, condensation may form at the supply air grill while the unit is operated in the cooling mode. This unit cannot operate dehumidifying.
- Use the unit in the way that the airflow rate will not exceed the 110% of the rated airflow.

5-4. Precautions for Outdoor unit/Heat source unit

5-4-1. Installation environment

- Outdoor/heat source unit with salt-resistant specification is recommended to use in a place where it is subject to salt air.
- Even when the unit with salt-resistant specification is used, it is not completely protected against corrosion. Be sure to follow the directions or precautions described in Instructions Book and Installation Manual for installation and maintenance. The salt-resistant specification is referred to the guidelines published by JRAIA (JRA9002).
- Install the unit in a place where the flow of discharge air is not obstructed. If not, the short-cycling of discharge air may occur.
- Provide proper drainage around the unit base, because the condensation may collect and drip from the outdoor/heat source units. Provide water-proof protection to the floor when installing the units on the rooftop.
- In a region where snowfall is expected, install the unit so that the outlet faces away from the direction of the wind, and install a snow guard to protect the unit from snow. Install the unit on a base approximately 50 cm higher than the expected snowfall. Close the openings for pipes and wiring, because the ingress of water and small animals may cause equipment damage. If SUS snow guard is used, refer to the Installation Manual that comes with the snow guard and take caution for the installation to avoid the risk of corrosion.
- When the unit is expected to operate continuously for a long period of time at outside air temperatures of below 0°C, take appropriate measures, such as the use of a unit base heater, to prevent icing on the unit base. (Not applicable to the PUMY series)
- Install the snow guard so that the outlet/inlet faces away from the direction of the wind.
- When the snow accumulates approximately 50 cm or more on the snow guard, remove the snow from the guard. Install a roof that is strong enough to withstand snow loads in a place where snow accumulates.
- Provide proper protection around the outdoor/heat source units in places such as schools to avoid the risk of injury.
- A cooling tower and heat source water circuit should be a closed circuit that water is not exposed to the atmosphere. When a tank is installed to ensure that the circuit has enough water, minimize the contact with outside air so that the oxygen from being dissolved in the water should be 1 mg/L or less.
- Install a strainer (50 mesh or more recommended) on the water pipe inlet on the heat source unit.
- Interlock the heat source unit and water circuit pump.
- Note the followings to prevent the freeze bursting of pipe when the heat source unit is installed in a place where the ambient temperature can be 0°C or below.
 - Keep the water circulating to prevent it from freezing when the ambient temperature is 0°C or below.
 - Before a long period of non use, be sure to purge the water out of the unit.
- Salt-resistant unit is resistant to salt corrosion, but not salt-proof.
Please note the following when installing and maintaining outdoor/heat source units in marine atmosphere.
 1. Install the salt-resistant unit out of direct exposure to sea breeze, and minimize the exposure to salt water mist.
 2. Avoid installing a sun shade over the outdoor/heat source unit, so that rain will wash away salt deposits off the unit.
 3. Install the unit horizontally to ensure proper water drainage from the base of the unit. Accumulation of water in the base of the outdoor/heat source unit will significantly accelerate corrosion.
 4. Periodically wash salt deposits off the unit, especially when the unit is installed in a coastal area.
 5. Repair all noticeable scratches after installation and during maintenance.
 6. Periodically check the unit, and apply anti-rust agent and replace corroded parts as necessary.

5-4-2. Circulating water

- Follow the guidelines published by JRAIA (JRA-GL02-1994) to check the water quality of the water in the heat source unit regularly.
- A cooling tower and heat source water circuit should be a closed circuit that water is not exposed to the atmosphere. When a tank is installed to ensure that the circuit has enough water, minimize the contact with outside air so that the oxygen from being dissolved in the water should be 1 mg/L or less.

5-4-3. Unit characteristics

- When the Thermo ON and OFF is frequently repeated on the indoor unit, the operation status of outdoor/heat source units may become unstable.

5-4-4. Relevant equipment

- Provide grounding in accordance with the local regulations.

5-5. Precautions for Control-related items**5-5-1. Product specification**

- To introduce the MELANS system, a consultation with us is required in advance. Especially to introduce the electricity charge apportioning function or energy-save function, further detailed consultation is required. Consult your local distributor for details.
- Billing calculation for AE-200E/AE-50E/EW-50E/AG-150A/EB-50GU-J/TG-2000A, or the billing calculation unit is unique and based on our original method. (Backup operation is included.) It is not based on the metering method, and do not use it for official business purposes. It is not the method that the amount of electric power consumption (input) by air conditioner is calculated. Note that the electric power consumption by air conditioner is apportioned by using the ratio corresponding to the operation status (output) for each air conditioner (indoor unit) in this method.
- In the apportioned billing function for AE-200E/AE-50E/EW-50E/AG-150A and EB-50GU-J, use separate watt-hour meters for A-control units, K-control units, and packaged air conditioner for City Multi air conditioners. It is recommended to use an individual watt-hour meter for the large-capacity indoor unit (with two or more addresses).
- When using the peak cut function on the AE-200E/AE-50E/EW-50E/AG-150A or EB-50GU-J, note that the control is performed once every minute and it takes time to obtain the effect of the control. Take appropriate measures such as lowering the criterion value. Power consumption may exceed the limits if AE-200E/AE-50E/EW-50E/AG-150A or EB-50GU-J malfunctions or stops. Provide a back-up remedy as necessary.
- The controllers cannot operate while the indoor unit is OFF. (No error) Turn ON the power to the indoor unit when operating the controllers.
- When using the interlocked control function on the AE-200E/AE-50E/EW-50E/AG-150A/EB-50GU-J/PAC-YG66DCA or PAC-YG63MCA, do not use it for the control for the fire prevention or security. (This function should never be used in the way that would put people's lives at risk.) Provide any methods or circuit that allow ON/OFF operation using an external switch in case of failure.

5-5-2. Installation environment

- The surge protection for the transmission line may be required in areas where lightning strikes frequently occur.
- A receiver for a wireless remote controller may not work properly due to the effect of general lighting. Leave a space of at least 1 m between the general lighting and receiver.
- When the Auto-elevating panel is used and the operation is made by using a wired remote controller, install the wired remote controller to the place where all air conditioners controlled (at least the bottom part of them) can be seen from the wired remote controller. If not, the descending panel may cause damage or injury, and be sure to use a wireless remote controller designed for use with elevating panel (sold separately).
- Install the wired remote controller (switch box) to the place where the following conditions are met.
 - Where installation surface is flat
 - Where the remote controller can detect an accurate room temperature

The temperature sensors that detect a room temperature are installed both on the remote controller and indoor unit. When a room temperature is detected using the sensor on the remote controller, the main remote controller is used to detect a room temperature. In this case, follow the instructions below.

 - Install the controller in a place where it is not subject to the heat source. (If the remote controller faces direct sunlight or supply air flow direction, the remote controller cannot detect an accurate room temperature.)
 - Install the controller in a place where an average room temperature can be detected.
 - Install the controller in a place where no other wires are present around the temperature sensor. (If other wires are present, the remote controller cannot detect an accurate room temperature.)
- To prevent unauthorized access, always use a security device such as a VPN router when connecting AE-200E/AE-50E/EW-50E/AG-150A/EB-50GU-J or TG-2000A to the Internet.

The installer and/or air conditioning system specialist shall secure safety against refrigerant leakage according to local regulations or standards. The following standard may be applicable if no local regulation or standard is available.

6-1. Refrigerant property

R410A refrigerant is harmless and incombustible. The R410A is heavier than the indoor air in density. Leakage of the refrigerant in a room has possibility to lead to a hypoxia situation. Therefore, the critical concentration specified below shall not be exceeded even if the leakage happens.

• Critical concentration

Critical concentration hereby is the refrigerant concentration in which no human body would be hurt if immediate measures can be taken when refrigerant leakage happens.

Critical concentration of R410A: 0.44kg/m³
(The weight of refrigeration gas per 1 m³ air conditioning space.);
 * The Critical concentration is subject to ISO5149, EN378-1.

For the CITY MULTI system, the concentration of refrigerant leaked should not have a chance to exceed the critical concentration in any situation.

6-2. Confirm the Critical concentration and take countermeasure

The maximum refrigerant leakage concentration (Rmax) is defined as the result of the possible maximum refrigerant weight (Wmax) leaked into a room divided by its room capacity (V). It is referable to Fig.6-1. The refrigerant of Heat source unit here includes its original charge and additional charge at the site.

The additional charge is calculated according to the refrigerant charging calculation of each kind of Heat source unit, and shall not be over charged at the site. Procedure 6-2-1~3 tells how to confirm maximum refrigerant leakage concentration (Rmax) and how to take countermeasures against a possible leakage.




Fig. 6-1 The maximum refrigerant leakage concentration

6-2-1. Find the room capacity (V),

If a room having total opening area more than 0.15% of the floor area at a low position with another room/space, the two rooms/space are considered as one. The total space shall be added up.

6-2-2. Find the possible maximum leakage (Wmax) in the room. If a room has Indoor unit(s) from more than 1 Heat source unit, add up the refrigerant of the Heat source units.

6-2-3. Divide (Wmax) by (V) to get the maximum refrigerant leakage concentration (Rmax).

6-2-4. Find if there is any room in which the maximum refrigerant leakage concentration (Rmax) is over 0.44kg/m³.

If no, then the CITY MULTI is safe against refrigerant leakage.

If yes, following countermeasure is recommended to do at site.

Countermeasure 1: Let-out (making V bigger)

Design an opening of more than 0.15% of the floor area at a low position of the wall to let out the refrigerant whenever leaked.

e.g. make the upper and lower seams of door big enough.

Countermeasure 2: Smaller total charge (making Wmax smaller)

e.g. Avoid connecting more than 1 Heat source unit to one room.

e.g. Using smaller model size but more Heat source units.

e.g. Shorten the refrigerant piping as much as possible.

Countermeasure 3: Fresh air in from the ceiling (Ventilation)

As the density of the refrigerant is bigger than that of the air. Fresh air supply from the ceiling is better than air exhausting from the ceiling.

Fresh air supply solution refers to Fig.6-2~4.




Fig.6-2. Fresh air supply always ON




Fig.6-3. Fresh air supply upon sensor action




Fig.6-4. Fresh air supply and refrigerant shut-off upon sensor action

Note 1. Countermeasure 3 should be done in a proper way in which the fresh air supply shall be on whenever the leakage happens.

Note 2. In principle, MITSUBISHI ELECTRIC requires proper piping design, installation and air-tight testing after installation to avoid leakage happening.

In the area should earthquake happen, anti-vibration measures should be fully considered.

The piping should consider the extension due to the temperature variation.



CITY MULTI

SYSTEM DESIGN WR2 SERIES

1. Electrical work.....	204
1-1.General cautions	204
1-2.Power supply for Indoor unit and Heat source unit.....	205
1-3.Power cable specifications	206
1-4.Power supply examples.....	207
2. M-NET control.....	209
2-1.Transmission cable length limitation.....	209
2-2.Transmission cable specifications	210
2-3.System configuration restrictions.....	211
2-4.Address setting.....	215
3. Piping Design.....	227
3-1.R410A Piping material	227
3-2.Piping Design	229
3-3.Refrigerant charging calculation	233
4. Installation.....	235
4-1.Requirement on installation site	235
4-2.Spacing.....	235
4-3.Piping direction	236
5. Installation information.....	237
5-1.General precautions	237
5-2.Precautions for Indoor unit	238
5-3.Precautions for Fresh air intake type indoor unit.....	239
5-4.Precautions for Outdoor unit/Heat source unit	239
5-5.Precautions for Control-related items	240
6. Caution for refrigerant leakage	241
6-1.Refrigerant property.....	241
6-2.Confirm the Critical concentration and take countermeasure.....	241

1-1. General cautions

- ① Follow ordinance of your governmental organization for technical standard related to electrical equipment, wiring regulations, and guidance of each electric power company.
- ② Wiring for control (hereinafter referred to as transmission cable) shall be (50mm[1-5/8in.] or more) apart from power source wiring so that it is not influenced by electric noise from power source wiring. (Do not insert transmission cable and power source wire in the same conduit.)
- ③ Be sure to provide designated grounding work to Heat source unit.
- ④ Give some allowance for wiring for electrical part box of indoor and Heat source unit, because the box is sometimes removed at the time of service work.
- ⑤ Never connect 380~415V(220~240V) power source to terminal block of transmission cable. If connected, electrical parts will be damaged.
- ⑥ Use 2-core shield cable for transmission cable. If transmission cables of different systems are wired with the same multiple-core cable, the resultant poor transmitting and receiving will cause erroneous operations.
- ⑦ When extending the transmission line, make sure to extend the shield cable as well.



1-2. Power supply for Indoor unit and Heat source unit

1-2-1. Electrical characteristics of Heat source unit at cooling mode

Symbols: MCA (Max Circuit Amps)

RLA (Rated Load Amps), SC (Starting Current)

PQRY-P-Y(S)LM	Unit combination	Heat source units			Compressor		RLA(A)		
		Hz	Volts	Voltage range	MCA(A)	Output (kW)	SC(A)	Cooling 380/400/415V	Heating 380/400/415V
PQRY-P200YLM-A	-	50/60	380 400 415	Max:456 Min:342	16.1	4.8	8	6.2/5.9/5.7	6.7/6.3/6.1
PQRY-P250YLM-A	-				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
PQRY-P300YLM-A	-				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
PQRY-P350YLM-A	-				23.1	9.5		12.0/11.4/11.0	12.7/12.0/11.6
PQRY-P400YLM-A	-				27.6	10.7		13.5/12.8/12.4	14.1/13.4/12.9
PQRY-P450YLM-A	-				32.9	11.6		15.6/14.8/14.3	16.5/15.7/15.1
PQRY-P500YLM-A	-				39.2	13.0		18.8/17.9/17.2	19.2/18.3/17.6
PQRY-P550YLM-A	-				40.5	15.0		21.1/20.1/19.3	20.7/19.6/18.9
PQRY-P600YLM-A	-				40.5	16.1		24.4/23.2/22.3	24.4/23.2/22.4
PQRY-P400YSLM-A	PQRY-P200YLM-A				16.1	4.8		6.2/5.9/5.7	6.7/6.3/6.1
	PQRY-P200YLM-A				16.1	4.8		6.2/5.9/5.7	6.7/6.3/6.1
PQRY-P450YSLM-A	PQRY-P200YLM-A				16.1	4.8		6.2/5.9/5.7	6.7/6.3/6.1
	PQRY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
PQRY-P500YSLM-A	PQRY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
	PQRY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
PQRY-P550YSLM-A	PQRY-P250YLM-A				16.1	6.2		8.2/7.8/7.5	8.5/8.1/7.8
	PQRY-P300YLM-A				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
PQRY-P600YSLM-A	PQRY-P300YLM-A				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
	PQRY-P300YLM-A				18.6	7.7		10.1/9.6/9.3	10.5/10.0/9.6
PQRY-P700YSLM-A	PQRY-P350YLM-A				23.1	9.5		12.0/11.4/11.0	12.7/12.0/11.6
	PQRY-P350YLM-A	23.1	9.5	12.0/11.4/11.0	12.7/12.0/11.6				
PQRY-P750YSLM-A	PQRY-P350YLM-A	23.1	9.5	12.0/11.4/11.0	12.7/12.0/11.6				
	PQRY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
PQRY-P800YSLM-A	PQRY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
	PQRY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
PQRY-P850YSLM-A	PQRY-P400YLM-A	27.6	10.7	13.5/12.8/12.4	14.1/13.4/12.9				
	PQRY-P450YLM-A	32.9	11.6	15.6/14.8/14.3	16.5/15.7/15.1				
PQRY-P900YSLM-A	PQRY-P450YLM-A	32.9	11.6	15.6/14.8/14.3	16.5/15.7/15.1				
	PQRY-P450YLM-A	32.9	11.6	15.6/14.8/14.3	16.5/15.7/15.1				

S.D. WR2

1-3. Power cable specifications

Thickness of wire for main power supply, capacities of the switch and system impedance

	Model	Minimum wire thickness (mm ²)			Ground-fault interrupter *1	Local switch (A)		Breaker for wiring (A) (Non-fuse breaker)	Max. Permissible System Impedance
		Main cable	Branch	Ground		Capacity	Fuse		
Heat source unit	PQRY-P200YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQRY-P250YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQRY-P300YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQRY-P350YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	25	25	30	*2
	PQRY-P400YLM-A	4.0	-	4.0	30A 100mA 0.1sec. or less	32	32	30	0.26Ω
	PQRY-P450YLM-A	6.0	-	6.0	40A 100mA 0.1sec. or less	40	40	40	0.22Ω
	PQRY-P500YLM-A	6.0	-	6.0	40A 100mA 0.1sec. or less	40	40	40	0.18Ω
	PQRY-P550YLM-A	10.0	-	10.0	60A 100mA 0.1sec. or less	63	63	60	0.17Ω
Total operating current of the indoor unit	F0 = 16A or less *3	1.5	1.5	1.5	20A current sensitivity *4	16	16	20	(apply to IEC61000-3-3)
	F0 = 25A or less *3	2.5	2.5	2.5	30A current sensitivity *4	25	25	30	(apply to IEC61000-3-3)
	F0 = 32A or less *3	4.0	4.0	4.0	40A current sensitivity *4	32	32	40	(apply to IEC61000-3-3)

*1 The Ground-fault interrupter should support Inverter circuit.

The Ground-fault interrupter should combine using of local switch or wiring breaker.

*2 Meet technical requirements of IEC61000-3-3.

*3 Please take the larger of F1 or F2 as the value for F0.

F1 = Total operating maximum current of the indoor units × 1.2

F2 = {V1 × (Quantity of Type1)/C} + {V1 × (Quantity of Type2)/C} + {V1 × (Quantity of Type3)/C} + {V1 × (Quantity of Others)/C}

Indoor unit		V1	V2
Type1	PLFY-VBM, PMFY-VBM, PEFY-VMS1, PCFY-VKM, PKFY-VHM, PKFY-VKM, PFFY-VKM, PFFY-VLRMM	18.6	2.4
Type2	PEFY-VMA	38	1.6
Type3	PEFY-VMHS	13.8	4.8
Others	Other indoor unit	0	0

C: Multiple of tripping current at tripping time 0.01s

Please pick up "C" from the tripping characteristic of the breaker.


<Example of "F2" calculation>

*Condition PEFY-VMS1 × 4 + PEFY-VMA × 1, C = 8 (refer to right sample chart)

F2 = 18.6 × 4/8 + 38 × 1/8

= 14.05

→16 A breaker (Tripping current = 8 × 16 A at 0.01s)



*4 Current sensitivity is calculated using the following formula.

G1 = (V2 × Quantity of Type1) + (V2 × Quantity of Type2) + (V2 × Quantity of Type3) + (V2 × Quantity of Others) + (V3 × Wire length [km])

G1	Current sensitivity
30 or less	30 mA 0.1sec or less
100 or less	100 mA 0.1sec or less

Wire thickness	V3
1.5 mm ²	48
2.5 mm ²	56
4.0 mm ²	66

1. Use dedicated power supplies for the outdoor unit and indoor unit. Ensure OC and OS are wired individually.
2. Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
3. The wire size is the minimum value for metal conduit wiring. If the voltage drops, use a wire that is one rank thicker in diameter. Make sure the power-supply voltage does not drop more than 10%. Make sure that the voltage imbalance between the phases is 2% or less.
4. Specific wiring requirements should adhere to the wiring regulations of the region.
5. Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 245 IEC57). For example, use wiring such as YZW.
6. A switch with at least 3 mm contact separation in each pole shall be provided by the Air Conditioner installer.

WARNING

- ◆ Be sure to use specified wires for connections and ensure no external force is imparted to terminal connections. If connections are not fixed firmly, heating or fire may result.
- ◆ Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current.

CAUTION

- ◆ The breakers for current leakage should support Inverter circuit. (e.g. Mitsubishi Electric's NV-S series or equivalent). If no earth leakage breaker is installed, it may cause an electric shock.
- ◆ Breakers for current leakage should combine using of switch.
- ◆ Do not use anything other than a breaker with the correct capacity. Using a breaker of too large capacity may cause malfunction or fire.
- ◆ If a large electric current flows due to malfunction or faulty wiring, earth-leakage breakers on the unit side and on the upstream side of the power supply system may both operate. Depending on the importance of the system, separate the power supply system or take protective coordination of breakers.

Note


- ◆ This device is intended for the connection to a power supply system with a maximum permissible system impedance shown in the above table at the interface point (power service box) of the user's supply.
- ◆ The user must ensure that this device is connected only to a power supply system which fulfils the requirement above. If necessary, the user can ask the public power supply company for the system impedance at the interface point.
- ◆ This equipment complies with IEC 61000-3-12 provided that the short-circuit power Ssc is greater than or equal to Ssc(*2) at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power Ssc greater than or equal to Ssc(*2).

Ssc(*2)

Model	PQRY-P200YLM-A	PQRY-P250YLM-A	PQRY-P300YLM-A	PQRY-P350YLM-A	PQRY-P400YLM-A	PQRY-P450YLM-A	PQRY-P500YLM-A	PQRY-P550YLM-A	PQRY-P600YLM-A
Ssc (MVA)	1.25	1.25	1.44	1.79	2.14	2.55	3.04	3.14	3.14



1-4. Power supply examples

1-4-1.PQRY-P200-600YLM



Note:

- 1 The transmission cable is not-polarity double-wire.
- 2 Symbol Ⓢ means a screw terminal for wiring.
- 3 The shield wire of transmission cable should be connected to the grounding terminal at Heat source unit. All shield wire of M-NET transmission cable among Indoor units should be connected to the S terminal at Indoor unit or all shield wire should be connected together. The broken line at the scheme means shield wire.
- 4 When the Heat source unit connected with system controller, power-supply to TB7 of the heat source unit(s) is needed. The connector change from CN41 to CN40 at one of the heat source units will enable the heat source unit to supply power to TB7, or an extra power supplying unit PAC-SC51KUA should be used. The transmission cable (above 1.25mm², shielded, CVVS/CPEVS/MVVS) among Heat source units and system controllers is called centralized control transmission cable. The shield wire of the centralized control transmission cable must be grounded at the Heat source unit whose CN41 is changed to CN40. When the power supplying unit PAC-SC51KUA is used, connect the shielded cable to the ground terminal on the PAC-SC51KUA.
- 5 MA R/C transmission cable (0.3-1.25mm²) must be less than 200m in length, while ME R/C transmission cable (0.3-1.25mm²) must be less than 10m in length. But transmission cable to the ME R/C can be extend using a M-NET cable (>=1.25mm²) when the length is counted in the M-NET length.
- 6 MA remote controller and ME remote controller should not be grouped together. When a PAR-3X MAA series (X indicates 1, 2, ...) is connected to a group, no other MA remote controllers can be connected to the same group.
- 7 If using 1 or 2 (main/sub) MA remote controller to control more than 1 Indoor unit, use MA transmission cable to connect all the TB15 terminals of the Indoor units. It is called "Grouping". If using 1 or 2 (main/sub) ME remote controller control more than 1 indoor unit, set address to Indoor unit and ME remote controller. For the method, refer to 2-4. "Address Setting".
- 8 Indoor board consumes power from TB3. The power balance should be considered according to System Design 2-3 "System configuration restrictions".
- 9 If Transmission booster is needed, be sure to connect the shield wires to the both sides to the booster.
- 10 The critical current for choosing power source equipment is approximate 1.4 times of total rated current of the Heat source unit(s) or Indoor unit(s).
- 11 When System controller (SC) is connected to the system, turn the SW5-1 on.
- 12 The phases of electricity power must be confirmed to be right used. Phase-reverse, or phase-missing could break the controllers.






Symbol	Model	Ground-fault interrupter *1, *2, *4	Local switch		Wiring breaker*4 (NFB) <A>	Minimum Wire thickness		
			BKC <A>	OCP*3, *4 <A>		Power wire <mm²>	Earth wire <mm²>	
GFI	Ground-fault interrupter	PQRY-P200YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
LW	Local switch	PQRY-P250YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
BKC	Breaker capacity	PQRY-P300YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
OCP	Over-current protector	PQRY-P350YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
WB	Wiring breaker	PQRY-P400YLM-A	30A 100mA 0.1sec. or less	32	32	30	4	4
NFB	Non-fuse breaker	PQRY-P450YLM-A	40A 100mA 0.1sec. or less	40	40	40	6	6
HU	Heat source unit	PQRY-P500YLM-A	40A 100mA 0.1sec. or less	40	40	40	6	6
IU	Indoor unit	PQRY-P550YLM-A	60A 100mA 0.1sec. or less	63	63	60	10	10
SC	System controller	PQRY-P600YLM-A	60A 100mA 0.1sec. or less	63	63	60	10	10

*1 The Ground-fault interrupter should support Inverter circuit. (e.g. Mitsubishi Electric's NV-S series or equivalent).
 *2 Ground-fault interrupter should combine using of local switch or wiring breaker.
 *3 It shows data for B-type fuse of the breaker for current leakage.
 *4 If a large electric current flows due to malfunction or faulty wiring, earth-leakage breakers on the unit side and on the centralized controller side may both operate.
 Depending on the importance of the system, separate the power supply system or take protective coordination of breakers.

S.D. WR2

1-4-2.PQRY-P400-900YSLM



Symbol	Model	Ground-fault interrupter *1, *2, *4	Local switch		Wiring breaker*4 (NFB) <A>	Minimum Wire thickness	
			BKC <A>	OCP*3, *4 <A>		Power wire <mm ² >	Earth wire <mm ² >
GFI	PQRY-P200YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
LW	PQRY-P250YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
BKC	PQRY-P300YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
OCP	PQRY-P350YLM-A	30A 100mA 0.1sec. or less	25	25	30	4	4
WB	PQRY-P400YLM-A	30A 100mA 0.1sec. or less	32	32	30	4	4
NFB	PQRY-P450YLM-A	40A 100mA 0.1sec. or less	40	40	40	6	6

*1 The Ground-fault interrupter should support Inverter circuit. (e.g. Mitsubishi Electric's NV-S series or equivalent).

*2 Ground-fault interrupter should combine using of local switch or wiring breaker.

*3 It shows data for B-type fuse of the breaker for current leakage.

*4 If a large electric current flows due to malfunction or faulty wiring, earth-leakage breakers on the unit side and on the centralized controller side may both operate.

Depending on the importance of the system, separate the power supply system or take protective coordination of breakers.


- Note:
- The transmission cable is not-polarity double-wire.
 - Symbol © means a screw terminal for wiring.
 - The shield wire of transmission cable should be connected to the grounding terminal at Heat source unit. All shield wire of M-Net transmission cable among Indoor units should be connected to the S terminal at Indoor unit or all shield wire should be connected together. The broken line at the scheme means shield wire.
 - When the Heat source unit connected with system controller, power-supply to TB7 of the heat source unit(s) is needed. The connector change from CN41 to CN40 at one of the heat source units will enable the heat source unit to supply power to TB7, or an extra power supplying unit PAC-SC51KUA should be used. The transmission cable (above 1.25mm², shielded, CVVS/CPEVS/MVVS) among Heat source units and system controllers is called centralized control transmission cable. The shield wire of the centralized control transmission cable must be grounded at the Heat source unit whose CN41 is changed to CN40. When the power supplying unit PAC-SC51KUA is used, connect the shielded cable to the ground terminal on the PAC-SC51KUA.
 - MA R/C transmission cable (0.3-1.25mm²) must be less than 200m in length, while ME R/C transmission cable (0.3-1.25mm²) must be less than 10m in length. But transmission cable to the ME R/C can be extended using a M-NET cable ($\geq 1.25\text{mm}^2$) when the length is counted in the M-NET length.
 - MA remote controller and ME remote controller should not be grouped together. When a PAR-3X MAA series (X indicates 1, 2, ...) is connected to a group, no other MA remote controllers can be connected to the same group.
 - If using 1 or 2 (main/sub) MA remote controller to control more than 1 Indoor unit, use MA transmission cable to connect all the TB15 terminals of the Indoor units. It is called "Grouping".
If using 1 or 2 (main/sub) ME remote controller control more than 1 indoor unit, set address to Indoor unit and ME remote controller. For the method, refer to 2-4. "Address Setting".
 - Indoor board consumes power from TB3. The power balance should be considered according to System Design 2-3 "System configuration restrictions".
 - If Transmission booster is needed, be sure to connect the shield wires to the both sides to the booster.
 - The critical current for choosing power source equipment is approximate 1.4 times of total rated current of the Heat source unit(s) or Indoor unit(s).
 - When System controller (SC) is connected to the system, turn the SW5-1 on.
 - The phases of electricity power must be confirmed to be right used. Phase-reverse, or phase-missing could break the controllers.

2-1. Transmission cable length limitation

2-1-1. Using MA Remote controller

Long transmission cable causes voltage down, therefore, the length limitation should be obeyed to secure proper transmission.

Max. length via Heat source (M-NET cable)	$L1+L2+L3, L1+L2+L4+L5, L3+L4+L5$	$\leq 500\text{m}[1640\text{ft.}]$	1.25mm^2 [AWG16] or thicker
Max. length to Heat source (M-NET cable)	$L1+L6, L3, L4, L2+L4+L6, L5$	$\leq 200\text{m}[656\text{ft.}]$	1.25mm^2 [AWG16] or thicker
Max. length from MA to Indoor	$a1+a2, a1+a2+a3+a4$	$\leq 200\text{m}[656\text{ft.}]$	$0.3\text{-}1.25\text{mm}^2$ [AWG22-16]
24VDC to AG-150A	n	$\leq 50\text{m}[164\text{ft.}]$	$0.75\text{-}2.0\text{mm}^2$ [AWG18-14]




OC, OS: Heat source unit controller; IC: Indoor unit controller; MA: MA remote controller

2-1-2. Using ME Remote controller

Long transmission cable causes voltage down, therefore, the length limitation should be obeyed to secure proper transmission.

Max. length via Heat source (M-NET cable)	$L1+L2+L3+L4, L1+L2+L6+L7, L1+L2+L3+L5, L3+L4+L6+L7$	$\leq 500\text{m}[1640\text{ft.}]$	1.25mm^2 [AWG16] or thicker
Max. length to Heat source (M-NET cable)	$L1+L8, L3+L4, L6, L2+L6+L8, L7, L3+L5$	$\leq 200\text{m}[656\text{ft.}]$	1.25mm^2 [AWG16] or thicker
Max. length from ME to Indoor	$e1, e2+e3, e4$	$\leq 10\text{m}[32\text{ft.}] * 1$	$0.3\text{-}1.25\text{mm}^2$ [AWG22-16] * 1
24VDC to AG-150A	n	$\leq 50\text{m}[164\text{ft.}]$	$0.75\text{-}2.0\text{mm}^2$ [AWG18-14]

*1. If the length from ME to Indoor exceed 10m, use 1.25mm^2 [AWG16] shielded cable, but the total length should be counted into Max. length via Heat source.



OC, OS: Heat source unit controller; IC: Indoor unit controller; ME: ME remote controller

2-2. Transmission cable specifications

	Transmission cables (Li)	M-NET remote controller cables (ei)	MA Remote controller cables (ai)
Type of cable	Shielding wire (2-core) CVVS, CPEVS or MVVS	Sheathed 2-core cable (unshielded) CVV	
Cable size	More than 1.25 mm ² [AWG16]	0.3 ~ 1.25 mm ² [AWG22~16]	0.3 ~ 1.25 mm ² [AWG22 ~16]*1
Remarks	Max length: within 200 m	When 10 m [32ft] is exceeded, use cables with the same specification as transmission cables.	Max length: 200 m [656ft]

*1 To wire PAR-3X MAA series (X indicates 1, 2...) and Simple
MA remote controller use a wire with a diameter of 0.3 mm² [AWG22]

CVVS, MVVS: PVC insulated PVC sheathed shielded control cable
CPEVS: PE insulated PVC sheathed shielded communication cable
CVV: PVC insulated PVC sheathed control cable

2-3. System configuration restrictions

2-3-1. Common restrictions for the CITYMULTI system

For each Heat source unit, the maximum connectable quantity of Indoor unit is specified at its Specifications table.

- A) 1 Group of Indoor units can have 1-16 Indoor units;
*OA processing unit GUF-RD(H) is considered as Indoor unit.
- B) Maximum 2 remote controllers for 1 Group;
*MA/ME remote controllers cannot be present together in 1group.
*When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.
- C) 1 LOSSNAY unit can interlock maximum 16 Indoor units; 1 Indoor unit can interlock only 1 LOSSNAY unit.
- D) Maximum 3 System controllers are connectable when connecting to TB3 of the Heat source unit.
- E) 4 System controllers or more are connectable when connecting to TB7 of the Heat source unit, if the transmission power is supplied by the power supply unit PAC-SC51KUA. Details refer to (C) below.
*System controller connected as described in D) and E) would have a risk that the failure of connected Heat source unit would stop power supply to the System controller.

2-3-2. Ensuring proper communication power and the number of connected units for M-NET

In order to ensure proper communication among Outdoor/Heat source unit, Indoor unit, LOSSNAY, OA processing unit GUF-RD(H), and Controllers, the transmission power situation for the M-NET should be observed. In some cases, Transmission booster should be used. Taking the power consumption of Indoor unit sized P15-P140 as 1, the equivalent power consumption or supply of others are listed at Table 1 and Table 2.

Both the transmission line for centralized controller and indoor-outdoor transmission line must meet the conditions listed below. (Both conditions a) and b) must be met.)

- a) [Total equivalent power consumption] ≤ [The equivalent power supply]
- b) [Total equivalent number of units] ≤ [40]

Table 1 The equivalent power consumption and the equivalent number of units

Category	Model	The equivalent power consumption	The equivalent number of units
Indoor, OA unit	Sized P15-P140 GUF-50, 100	1	1
Indoor unit	Sized P200, P250	7	2
BC controller	CMB	2	1
PWFY	P100VM-E-BU	6	1
	P100VM-E1-AU P100VM-E2-AU	1	1
	P200VM-E1-AU P200VM-E2-AU	5	1
MA remote controller/LOSSNAY	PAR-31MAAE PAC-YT52CRA PAR-FA32MA LGH-RX5-E PZ-60DR-E PZ-43SMF-E	0	0
ME remote controller	PAR-U02MEDA PAC-IF01AHC-J	0.5	1
System controller	AE-200E AE-50E EW-50E	0	0
	AG-150A EB-50GU-J	0.5	1
	AT-50B	1.5	5
	PAC-YG60MCA PAC-YG66DCA PAC-YG63MCA	0.25	1
ON/OFF controller	PAC-YT40ANRA	1	1
MN converter	CMS-MNG-E	2	1
Outdoor/Heat source unit	TB7 power consumption	0	0

Table 2 The equivalent power supply

Category	Model	The equivalent power supply
Transmission Booster	PAC-SF46EPA	25
Power supply unit	PAC-SC51KUA	5
Expansion controller	PAC-YG50ECA	6
BM ADAPTER	BAC-HD150	6
System controller	AE-200E/AE-50E	0 *1
	EW-50E	1.5 *1
Outdoor/Heat source unit	Connector TB3 and TB7 total *	32
	Connector TB7 only	6


*If PAC-SC51KUA is used to supply power at TB7 side, no power supply need from Outdoor/Heat source unit at TB7, Connector TB3 itself will therefore have 32. Not applicable to the PUMY model.

*1 AE-200E/AE-50E/EW-50E has a built-in function to supply power to the M-NET transmission line. The amount of power that an AE-200E or an AE-50E can supply is equivalent to the power required by an MN converter (CMS-MNG-E) that is used for maintenance. An MN converter is connectable to EW-50E only when the equivalent power consumption is less than 1.5.

With the equivalent power consumption values and the equivalent number of units in Table 1 and Table 2, PAC-SF46EPA can be designed into the air-conditioner system to ensure proper system communication according to (A), (B), (C).

- (A) Firstly, count from TB3 at TB3 side the total equivalent number of units of Indoor units, OA processing units, ME remote controller, and System controllers. If the total equivalent number of units reaches 40, a PAC-SF46EPA should be set. In this case, Indoor units sized P200 and 250 are counted as 2, AT-50B is counted as 5, but MA remote controller(s), PZ-60DR-E, and PZ-43SMF-E are NOT counted.
- (B) Secondly, count from TB7 side to TB3 side the total transmission power consumption. If the total power consumption reaches 32, a PAC-SF46EPA should be set. Yet, if a PAC-SC51KUA or another controller with a built-in power supply, such as PAC-YG50ECA, is used to supply power at TB7 side, count from TB3 side only.
- (C) Thirdly, count from TB7 at TB7 side the total transmission power consumption, If the total power consumption reaches 6, a PAC-SF46EPA should be set. Also, count from TB7 at TB7 side the total equivalent number of units of System controllers, and so on. If the total equivalent number of units reaches 40, a PAC-SF46EPA should be set.

■ System example



2-3-3. Ensuring proper power supply to System controller

The power to System controller (excluding AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) is supplied via M-NET transmission line. M-NET transmission line at TB7 side is called Centralized control transmission line while one at TB3 side is called Indoor-Heat source transmission line. There are 3 ways to supply power to the System controller.


- A) Connecting to TB3 of the Heat source unit and receiving power from the Heat source unit.
- B) Connecting to TB7 of the Heat source unit and receiving power from the Heat source unit.
- C) Connecting to TB7 of the Heat source unit but receiving power from power supply unit PAC-SC51KUA.

* System controllers (AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) have a built-in function to supply power to the M-NET transmission lines, so no power needs to be supplied to the M-NET transmission lines from the Heat source units or from PAC-SC51KUA.

2-3-3-A. When connecting to TB3 of the Heat source unit and receiving power from the Heat source unit.

Maximum 3 System controllers can be connected to TB3. If there is more than 1 Heat source unit, it is necessary to replace power supply switch connector CN41 with CN40 on one Heat source unit.


Fig. 2-3-3-A



2-3-3-B. When connecting to TB7 of the Heat source unit and receiving power from the Heat source unit.

Maximum 6 System controllers can be connected to TB7 and receiving power from the Heat source unit. It is necessary to replace power supply switch connector CN41 with CN40 on one Heat source unit.

Fig. 2-3-3-B




2-3-3-C. When connecting to TB7 of the Heat source unit but receiving power from PAC-SC51KUA.

When using PAC-SC51KUA to supply transmission power, the power supply connector CN41 on the Heat source units should be kept as it is. It is also a factory setting.

1 PAC-SC51KUA supports maximum 1 AG-150A or 1 EB-50GU-J unit due to the limited power 24VDC at its TB3. However, 1 PAC-SC51KUA supplies transmission power at its TB2 equal to 5 Indoor units, which is referable at Table 2. If System controller, ON/OFF controller connected to TB7 consume transmission power more than 5 (Indoor units), Transmission booster PAC-SF46EPA is needed. PAC-SF46EPA supplies transmission power equal to 25 Indoor units.

Fig. 2-3-3-C



CAUTION

■ AG-150A/EB-50GU-J*1 are recommended to connect to TB7 because it performs back-up to a number of data.

In an air conditioner system has more than 1 Heat source units, AG-150A/EB-50GU-J receiving transmission power at TB3 or TB7 on one of the Heat source units would have a risk that the connected Heat source unit failure would stop power supply to AG-150A/EB-50GU-J, and disrupt the whole system.

When applying apportioned electric power function, AG-150A/EB-50GU-J are necessary to connected to TB7 and has its own power supply unit PAC-SC51KUA.


Note: Power supply unit PAC-SC51KUA is for AG-150A/EB-50GU-J.

*1: AG-150A is an example model of system controllers.

■ How to connect system controllers (AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) to a given system System controllers (AE-200E, AE-50E, EW-50E, BAC-HD150, LM-AP) have a built-in function to supply power to the M-NET transmission lines, so no power needs to be supplied to the M-NET transmission lines from the Heat source units or from PAC-SC51KUA.

Leave the power supply connector on the Heat source unit connected to CN41 as it is. Refer to 2-3-2 for information about the power-supply capacity of each system controller (EW-50E, BAC-HD150, LM-AP) to the low-level system controllers.

Fig. 2-3-3-D



2-3-4. Power supply to LM-AP

1-phase 220-240VAC power supply is needed.

The power supply unit PAC-SC51KUA is not necessary when connecting only the LM-AP. Yet, make sure to change the power supply changeover connector CN41 to CN40 on the LM-AP.

2-3-5. Power supply to expansion controller

1-phase 100-240VAC power supply is needed.

The power supply unit PAC-SC51KUA is not necessary.

The expansion controller supplies power through TB3, which equals 6 indoor units. (refer to Table 2)

2-3-6. Power supply to BM ADAPTER

1-phase 100-240VAC power supply is needed.

The power supply unit PAC-SC51KUA is not necessary when only BM ADAPTER is connected.

Yet, make sure to move the power jumper from CN41 to CN40 on the BM ADAPTER.

2-3-7. Power supply to AE-200E/AE-50E/EW-50E

1-phase 100-240VAC power supply is needed.


The power supply unit PAC-SC51KUA is not necessary when connecting only the AE-200E/AE-50E/EW-50E.

2-4. Address setting

2-4-1. Switch operation

In order to constitute CITY MULTI in a complete system, switch operation for setting the unit address No. and connection No. is required.

- ① Address No. of Heat source unit, indoor unit and remote controller.
The address No. is set at the address setting board.
In the case of WR2 system, it is necessary to set the same No. at the branch No. switch of indoor unit as that of the BC controller connected. (When connecting two or more branches, use the lowest branch No.)



② Caution for switch operations

- Be sure to shut off power source before switch setting. If operated with power source on, switch can not operate properly.
- No units with identical unit address shall exist in one whole air conditioner system. If set erroneously, the system can not operate.

③ MA remote controller

- When connecting only one remote controller to one group, it is always the main remote controller. When connecting two remote controllers to one group, set one remote controller as the main remote controller and the other as the sub remote controller.
- The factory setting is "Main".

PAR-3X MAA series (X indicates 1, 2...)

The MA remote controller does not have the switches listed above.
Refer to the installation manual for the function setting.

PAC-YT52CRA





































Setting the dip switches

There are switches on the back of the top case. Remote controller Main/Sub and other function settings are performed using these switches. Ordinarily, only change the Main/Sub setting of SW1.
(The factory settings are ON for SW1, 2, and 3 and OFF for SW4.)

SW No.	SW contents Main	ON	OFF	Comment
1	Remote controller Main/Sub setting	Main	Sub	Set one of the two remote controllers at one group to "ON".
2	Temperature display units setting	Celsius	Fahrenheit	When the temperature is displayed in [Fahrenheit], set to "OFF".
3	Cooling/heating display in AUTO mode	Yes	No	When you do not want to display "Cooling" and "Heating" in the AUTO mode, set to "OFF".
4	Indoor temperature display	Yes	No	When you want to display the indoor temperature, set to "ON".

S.D. WR2

2-4-2. Rule of setting address

Unit	Address setting	Example	Note
Indoor unit	01 ~ 50	 	Use the most recent address within the same group of indoor units. Make the indoor units address connected to the BC controller (Sub) larger than the indoor units address connected to the BC controller (Main). If applicable, set the sub BC controllers in an PQR system in the following order: (1) Indoor unit to be connected to the BC controller (Main) (2) Indoor unit to be connected to the BC controller (No.1 Sub) (3) Indoor unit to be connected to the BC controller (No.2 Sub) Set the address so that (1)<(2)<(3)
Heat source unit	51 ~ 99, 100 (Note1)	 	The smallest address of indoor unit in same refrigerant system + 50 Assign sequential address numbers to the heat source units in one refrigerant circuit system. OC and OS are automatically detected. (Note 2) *Please reset one of them to an address between 51 and 99 when two addresses overlap. *The address automatically becomes "100" if it is set as "01~ 50"
BC controller (Main)	52 ~ 99, 100	 	The address of heat source unit + 1 *Please reset one of them to an address between 51 and 99 when two addresses overlap. *The address automatically becomes "100" if it is set as "01~ 50"
BC controller (Sub)	52 ~ 99, 100	 	Lowest address within the indoor units connected to the BC controller (Sub) plus 50.
Local remote controller	ME Remote controller (Main)	101 ~ 150 Fixed  	The smallest address of indoor unit in the group + 100 *The place of "100" is fixed to "1"
	ME Remote controller (Sub)	151 ~ 199, 200 Fixed  	The address of main remote controller + 50 *The address automatically becomes "200" if it is set as "00"
System controller	ON/OFF remote controller	000, 201 ~ 250   	The smallest group No. to be managed + 200 * The smallest group No. to be managed is changeable.
	AE-200E/AE-50E AG-150A AT-50B EB-50GU-J EW-50E	000, 201 ~ 250   	
	PAC-YG50ECA	000, 201 ~ 250   	* Settings are made on the initial screen of AG-150A.
	BAC-HD150	000, 201 ~ 250   	* Settings are made with setting tool of BM ADAPTER.
	LMAP04-E	201 ~ 250 Fixed  	
PI, AI, DIDO	PAC-YG60MCA	01 ~ 50  	
	PAC-YG63MCA	01 ~ 50  	
	PAC-YG66DCA	01 ~ 50  	
Lossnay, OA processing unit	01 ~ 50  	After setting the addresses of all the indoor units, assign an arbitrary address.	
PAC-IF01AHC	201 ~ 250 Fixed  		

Note1: To set the address to "100", set it to "50"

Note2: Heat source units OC and OS in one refrigerant circuit system are automatically detected.

OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.

2-4-3. System examples

Factory setting


Original switch setting of the heat sources, indoors, controllers, LM-AP, and BM ADAPTER at shipment is as follows.

- Heat source unit : Address: 00, CN41: ON (Jumper), DipSW5-1: OFF
- Indoor unit : Address: 00
- BC controller : Address: 00
- ME remote controller : Address: 101
- LM-AP : Address: 247, CN41: ON (Jumper), DipSW1-2: OFF
- BM ADAPTER : Address: 000, CN41: ON (Jumper)
- AE-200E/AE-50E/EW-50E : Address: 000, CN21: ON (Jumper)

Setting at the site

- DipSW5-1(Heat source) : When the System Controller is used, all the Dip SW5-1 at the heat source units should be set to "ON". * Dip SW5-1 remains OFF when only LM-AP is used.
- DipSW1-2(LM-AP) : When the LM-AP is used together with System Controller, DipSW1-2 at the LM-AP should be set to "ON".
- CN40/CN41 : Change jumper from CN41 to CN 40 at heat source control board will activate central transmission power supply to TB7;
(Change jumper at only one heat source unit when activating the transmission power supply without using a power supply unit.)
Change jumper from CN41 to CN 40 at LM-AP/BM ADAPTER will activate transmission power supply to LM-AP/BM ADAPTER itself;
Power supply unit is recommended to use for a system having more than 1 heat source unit, because the central transmission power supply from TB7 of one of heat source units is risking that the heat source unit failure may let down the whole central control system.
- CN21(AE-200E/AE-50E/EW-50E) : Activates the power supply to M-NET transmission line from AE-200E/AE-50E/EW-50E (CN21: ON (power supplied), OFF (power not supplied))

2-4-3-1. MA remote controller, Single-refrigerant-system, No System Controller




*1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.

NOTE:

1. Heat source units OC and OS in one refrigerant circuit system are automatically detected. OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.
2. No address setting is needed.
3. For a system having more than 32 indoor unit (P15-P140), confirm the need of Booster at 2-3 "System configuration restrictions".
4. Indoor units should be set with a branch number.
5. Address setting is required if a sub BC controller is connected.
6. When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-2. MA remote controller, Single-refrigerant-system, System Controller




*1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.

*SC can be connected to TB3 side or TB7 side;
Should SC connected to TB7 side, change Jumper from CN41 to CN40 at the Heat source unit module so as to supply power to the SC.

NOTE:

1. Heat source units OC and OS in one refrigerant circuit system are automatically detected.
OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.
2. Address should be set to Indoor units and central controller.
3. For a system having more than 32 indoor unit (P15-P140), confirm the need of Booster at 2-3 "System configuration restrictions".
4. Indoor units should be set with a branch number.
5. When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-3. MA remote controller, Multi-refrigerant-system, System Controller at TB7/TB3 side, Booster for long M-NET wiring





- *1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel
- *2 System controller should connect to TB7 at the Heat source unit and use power supply unit together in Multi-Refrigerant-System.
For AG-150A, 24VDC should be used with the PAC-SC51KUA.
For AE-200E, AE-50E, and EW-50E the power supply unit PAC-SC51KUA is unused.
- *3 When multiple system controllers are connected in the system, set the controller with more functions than others as a "main" controller and others as "sub".
AE-200E, AE-50E, EW-50E, BAC-HD150, and LM-AP are for exclusive use as a "main" system controller and cannot be used as a "sub" system controller.
Make the setting to only one of the system controllers for "prohibition of operation from local remote controller".
- *4 The power supply unit is not necessary for AE-200E, AE-50E, EW-50E, BAC-HD150, and LM-AP.


NOTE:

1. Heat source units OC and OS in one refrigerant circuit system are automatically detected.
OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.
2. Address should be set to Indoor units, LOSSNAY and system controller.
3. M-NET power is supplied by the Heat source unit at TB3, while Indoor unit and ME remote controller consume the M-NET power for transmission use. The power balance is needed to consider for long M-NET wiring. Details refer to 2-3 "System configuration restrictions".
4. Indoor units should be set with a branch number.
5. Assign an address to each of the sub BC controllers which equals the sum of the smallest address of the indoor units that are connected to each sub BC controller and 50.
6. When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

S.D. WR2



2-4-3-6. ME remote controller, Multi-refrigerant-system, System Controller at TB7 side, LOSSNAY, Booster for long M-NET wiring



- *1 System controller should connect to TB7 at the Heat source unit and use power supply unit together in Multi-Refrigerant-System. For AG-150A, 24VDC should be used with the PAC-SC51KUA. For AE-200E, AE-50E, and EW-50E the power supply unit PAC-SC51KUA is unused.
- *2 When multiple system controllers are connected in the system, set the controller with more functions than others as a "main" controller and others as "sub". AG-150A, AE-200E, AE-50E, EW-50E, BAC-HD150, and LM-AP are for exclusive use as a "main" system controller and cannot be used as a "sub" system controller. Make the setting to only one of the system controllers for "prohibition of operation from local remote controller".


NOTE:

1. Heat source units OC and OS in one refrigerant circuit system are automatically detected. OC and OS are ranked in descending order of capacity. If units are the same capacity, they are ranked in ascending order of their address.
2. M-NET power is supplied by the Heat source unit at TB3, while Indoor unit and ME RC consume the M-NET power for transmission use. The power balance is needed to consider for long M-NET wiring. Details refer to 2-3 "System configuration restrictions".
3. Indoor units should be set with a branch number.
4. Assign an address to each of the sub BC controllers which equals the sum of the smallest address of the indoor units that are connected to each sub BC controller and 50. When the address assigned to sub BC controller overlaps those of any other units including heat source units (OC/OS) or main BC controller, sub BC controller will be given priority to have the address.


2-4-3-7. Example: BC, BC sub

NOTE

- Indoor units should be set with a branch number.
- BC (main) address = O/U address + 1
- BC (sub) address = Lowest address within the indoor units connected to the BC controller (sub) + 50
- If applicable, set the sub BC controllers in an PQR system in the following order
 - (1) Indoor unit to be connected to the BC controller (Main)
 - (2) Indoor unit to be connected to the BC controller (No.1 Sub)
 - (3) Indoor unit to be connected to the BC controller (No.2 Sub)
 Set the address so that (1)<(2)<(3)




2-4-3-8. TG-2000A(*1)+AE-200E/AE-50E/EW-50E
 AE-200E can control max. 50 indoor units;
 TG-2000A can control max. 40 of AE-200E/AE-50E/EW-50E;*2
 TG-2000A can control max. 2000 indoor units.



*1 TG-2000A (Ver.6.5 or later) supports AE-200E/AE-50E (Ver.7.10 or later).
 Contact your local distributor for which version of TG-2000A supports EW-50E.
 *2 When AE-200E connected with AE-50E is connected, the number of AE-50E will be the maximum controllable number.
 TG-2000A can control up to 40 AE-200E/AE-50E or AE-200E without AE-50E connection.
 *3 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.
 *4 When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-9. AE-200E+AE-50E/EW-50E

AE-200E can control max. 200 indoor units/via AE-50E/EW-50E.




*1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.

*2 When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-10. LM-AP

LM-AP can transmit for max. 50 indoor units;
 If system controller (SC) is used, DipSW1-2 at LM-AP and DipSW5-1 at Heat source unit should set to "ON".
 Change Jumper from CN41 to CN40 to activate power supply to LM-AP itself for those LM-AP connected without system controller (SC).

LM-AP can transmit for max. 50 indoor units in single-refrigerant-system or multi-refrigerant-system.




*1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.

*2 When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-11. BM ADAPTER

BM ADAPTER can transmit for max. 50 indoor units;
 Change Jumper from CN41 to CN40 to activate power supply to BM ADAPTER itself for those BM ADAPTER connected without the power supply unit.


BM ADAPTER can transmit for max. 50 indoor units in single-refrigerant-system or multi-refrigerant-system.



For other equipments (Lighting, security, elevator etc.)

- *1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.
- *2 When a PAR-3X MAA series (X indicates 1, 2...) is connected to a group, no other MA remote controllers can be connected to the same group.

2-4-3-12. BM ADAPTER+AE-200E/AE-50E/EW-50E



NOTE

- It is not necessary to connect the M-NET transmission line to the TB3 on BM ADAPTER. Leave the power jumper of BM ADAPTER connected to CN41.
- *1 For Wireless R/C and Signal receiver unit (SRU), channel 1, 2 and 3 are selectable and should be set to same channel.
- *2 Consult your dealer for restrictions when connecting both AE-200E/AE-50E/EW-50E and BM ADAPTER.
- *3 When a PAR-3X MAA series (X indicates 1, 2, ...) is connected to a group, no other MA remote controllers can be connected to the same group.
- *4 In a system that uses AE-200E and/or AE-50E/EW-50E, each BM-ADAPTER must be connected to the M-NET line.

3-1. R410A Piping material

Refrigerant pipe for CITY MULTI shall be made of phosphorus deoxidized copper, and has two types.

- A. Type-O: Soft copper pipe (annealed copper pipe), can be easily bent with human's hand.
- B. Type-1/2H pipe: Hard copper pipe (Straight pipe), being stronger than Type-O pipe of the same radical thickness.

The maximum operation pressure of R410A air conditioner is 4.30 MPa [623psi]. The refrigerant piping should ensure the safety under the maximum operation pressure. MITSUBISHI ELECTRIC recommends pipe size as Table 3-1, or You shall follow the local industrial standard. Pipes of radical thickness 0.7mm or less shall not be used.

Table 3-1. Copper pipe size and radial thickness for R410A CITY MULTI.



Size (mm)	Size (inch)	Radial thickness (mm)	Radial thickness (mil)	Pipe type
ø6.35	ø1/4"	0.8	[32]	Type-O
ø9.52	ø3/8"	0.8	[32]	Type-O
ø12.7	ø1/2"	0.8	[32]	Type-O
ø15.88	ø5/8"	1.0	[40]	Type-O
ø19.05	ø3/4"	1.2	[48]	Type-O
ø19.05	ø3/4"	1.0	[40]	Type-1/2H or H
ø22.2	ø7/8"	1.0	[40]	Type-1/2H or H
ø25.4	ø1"	1.0	[40]	Type-1/2H or H
ø28.58	ø1-1/8"	1.0	[40]	Type-1/2H or H
ø31.75	ø1-1/4"	1.1	[44]	Type-1/2H or H
ø34.93	ø1-3/8"	1.2	[48]	Type-1/2H or H
ø41.28	ø1-5/8"	1.4	[56]	Type-1/2H or H

* For pipe sized ø19.05 (3/4") for R410A air conditioner, choice of pipe type is up to you.

* The figures in the radial thickness column are based on the Japanese standards and provided only as a reference. Use pipes that meet the local standards.

Flare

Due to the relative higher operation pressure of R410A compared to R22, the flare connection should follow dimensions mentioned below so as to achieve enough the air-tightness.

Flare pipe	Pipe size	A (For R410A) (mm[in.])	Flare nut	Pipe size	B (For R410A) (mm[in.])
	ø6.35 [1/4"]	9.1		ø6.35 [1/4"]	17.0
	ø9.52 [3/8"]	13.2		ø9.52 [3/8"]	22.0
	ø12.70 [1/2"]	16.6		ø12.70 [1/2"]	26.0
	ø15.88 [5/8"]	19.7		ø15.88 [5/8"]	29.0
	ø19.05 [3/4"]	24.0		ø19.05 [3/4"]	36.0


S.D. WR2

Procedures for installing the branched pipes

Refer to the instructions that came with the branched pipe kit (separately sold) for details.

[1] Branches on the indoor-unit side

■ Joint




Horizontal installation



Vertical installation



(The branched pipes must face up.)
Indoor-unit side (branched pipe)



Outdoor/heat source-unit side (main pipe)

- Restrictions for installing the joint described here only apply to CMY-Y202S-G2 and CMY-Y302S-G2 in the gas line.
- CMY-Y202S-G2 and CMY-Y302S-G2 in the gas line must be installed horizontally (see figure above) or with the branched pipes facing up.
- If the size of the refrigerant pipe that is selected by following the instructions under 3-2. Piping Design does not match the size of the joint, use a reducer to connect them. A reducer is included in the kit.


■ Header



- No restrictions apply to the installation of the header.
- If the size of the refrigerant pipe that is selected by following the instructions under 3-2. Piping Design does not match the size of the header, cut the pipe to an appropriate size using a pipe cutter, or use a reducer to connect them.
- If the number of header branches exceeds the number of pipes to be connected, cap the unused header branches. Caps are included in the kit.

[2] Branches on the outdoor/heat source-unit side

Note. Refer to the figure below for the installation position of the twinning pipe.



Slope of the twinning pipes are at an angle within $\pm 15^\circ$ to the horizontal plane.

- Inclination of the branched pipes
The inclination of the branched pipes must be $\pm 15^\circ$ or less against the horizontal plane. Excessive inclination of the branched pipes may damage the unit.
- Minimum length of the straight section of the pipe before the branched pipes
Always use the pipes supplied in the branched pipe kit, and make sure the straight section of the pipe immediately before it connects to the branched pipe is at least 500 mm. Failure to do so may damage the unit.

3-2. Piping Design

3-2-1. PQRY-P200-600YLM Piping

IF 16 ports or less are in use, I.e., if only one BC controller is in use with no sub BC controller

- Note1. No Header usable on PQRY system.
- Note2. Indoor unit sized P100-P250 should be connected to BC controller via Y shape joint CMY-R160-J1 ;
- Note3. Indoor unit sized P100-P250 does NOT share BC controller ports with other Indoor units ;
- Note4. As bents cause pressure loss on transportation of refrigerant, fewer bents design is better ;
Piping length needs to consider the actual length and equivalent length which bents are counted.
Equivalent piping length (m)=Actual piping length+“M” x Number of bent.
- Note5. Set DIP-SW 4-6 to ON of BC controller, in case of connected Indoor unit sized P100-P140 with 2 ports.
- Note6. It is also possible to connect Indoor unit sized P100-P140 with 1 port (set DIP-SW 4-6 to OFF).
However, the cooling capacity decreases a little (For details, refer to the chapter HEAT SOURCE UNITS, WR2 SERIES, 7-4. Correction by port counts of the BC controller).
- Note7. Individual indoor units grouped together to connect to the BC controller via one port cannot operate individually in heating and cooling modes at the same time. I.e., they must all function in either heating or cooling together.
- Note8. Indoor capacity is described as its model size. For example, PEFY-P63VML-E, its capacity is P63.
- Note9. Total down-stream Indoor capacity is the summary of the model size of Indoors down-stream.
For example, PEFY-P63VML-E + PEFY-P32VML-E : Total Indoor capacity = P63 + P32 = P95.




Fig. 3-2-1AA




Fig. 3-2-1A Piping scheme

Piping length		(m [ft.])		Bent equivalent length "M"	
Item	Piping in the figure	Max. length	Max. equivalent length	Heat source Model M (m/bent [ft./bent])	
Total piping length	A+B+C+D+E+a+b+c+d+e+f+g+h	*1	-	P200YLM	0.35 [1.15']
Farthest IU from HU	A+D+E+h	165 [541']	190 [623']	P250YLM	0.42 [1.38']
Distance between HU and BC	A	110 [360'] *1	110 [360'] *1	P300YLM	0.42 [1.38']
Farthest IU from BC controller	D+E+h	40 [131'] *2	40 [131'] *2	P350YLM	0.50 [1.64']
Height between HU and IU (HU above IU)	H	50 [164']	-	P400YLM	0.50 [1.64']
Height between HU and IU (HU under IU)	H'	40 [131']	-	P450YLM	0.50 [1.64']
Height between IU and BC	h1	15 [49'] (10 [32']) *3	-	P500YLM	0.50 [1.64']
Height between IU and IU	h2	15 [49'] (10 [32']) *3	-	P550YLM	0.50 [1.64']
				P600YLM	0.50 [1.64']

HU : Heat source Unit ; IU : Indoor Unit ; BC : BC controller


*1. Refer to the section 3-2-4.

*2. Farthest Indoor from BC controller "D+E+h" can exceed 40m [131ft.] till 60m [197ft.] if no Indoor sized P200, P250 connected.

Details refer to Fig.3-2-1-1

*3. Distance of Indoor sized P200, P250 from BC must be less than 10m [32ft.], if any.

Fig. 3-2-1-1 Piping length and height between IU and BC controller



Piping "A" size selection rule (mm [in.])

Heat source Model	Pipe(High pressure)	Pipe(Low pressure)
P200YLM	ø15.88 [5/8"]	ø19.05 [3/4"]
P250-300YLM	ø19.05 [3/4"]	ø22.20 [7/8"]
P350-500YLM	ø22.20 [7/8"]	ø28.58 [1-1/8"]
P550YLM	ø22.20 [7/8"]*	ø28.58 [1-1/8"]
P600YLM	ø22.20 [7/8"]*	ø34.93 [1-3/8"]

* When the piping length is 65 m or longer, use the ø28.58 [1-1/8"] pipe for the part that exceeds 65 m.

Piping "B", "C", "D", "E" size selection rule (mm [in.])

Total down-stream Indoor capacity	Pipe(Liquid)	Pipe(Gas)
P140 or less	ø9.52 [3/8"]	ø15.88 [5/8"]
P141-P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P201-P250	ø9.52 [3/8"]	ø22.20 [7/8"]

Piping "a", "b", "c", "d", "e", "f", "g", "h" size selection rule (mm [in.])

Indoor Unit size	Pipe(Liquid)	Pipe(Gas)
P15 to P50, GUF-50RD(H)	ø6.35 [1/4"]	ø12.70 [1/2"]
P63 to P140, GUF-100RD(H)	ø9.52 [3/8"]	ø15.88 [5/8"]
P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P250	ø9.52 [3/8"]	ø22.20 [7/8"]

3-2-2. IF more than 16 ports are in use, or if there is more than one BC controller in use for one Heat source unit

- Note1. No Header usable on PQRY system.
- Note2. Indoor unit sized P100-P250 should be connected to BC controller via Y shape joint CMY-R160-J1 ;
- Note3. Indoor unit sized P100-P250 does NOT share BC controller ports with other Indoor units ;
- Note4. As bends cause pressure loss on transportation of refrigerant, fewer bends design is better ;
Piping length needs to consider the actual length and equivalent length which bends are counted.
Equivalent piping length (m)=Actual piping length* M x Number of bent.
- Note5. Set DIP-SW 4-6 to ON of BC controller, in case of connected Indoor unit sized P100-P140 with 2 ports.
- Note6. It is also possible to connect Indoor unit sized P100-P140 with 1 port (set DIP-SW 4-6 to OFF).
However, the cooling capacity decreases a little (For details, refer to the chapter HEAT SOURCE UNITS, WR2 SERIES, 7-4. Correction by port counts of the BC controller).
- Note7. Individual indoor units grouped together to connect to the BC controller via one port cannot operate individually in heating and cooling modes at the same time. I.e., they must all function in either heating or cooling together.
- Note8. For sub BC controller CMB-P-V-GB1 the connectable indoor unit capacities may sum to equal that of a P350 unit or less. However, if two sub controllers are used the TOTAL sum of connectable units connected to BOTH sub controllers must also not exceed that of a P350 unit.
For sub BC controller CMB-P1016V-HB1 the connectable indoor unit capacities may sum to equal that of a P350 unit or less. However, if two sub controllers are used the TOTAL sum of connectable units connected to BOTH sub controllers must also not exceed that of a P450 unit.
- Note9. Indoor capacity is described as its model size. For example, PEFY-P63VML-E, its capacity is P63.
- Note10. Total down-stream Indoor capacity is the summary of the model size of Indoors down-stream.
For example, PEFY-P63VML-E + PEFY-P32VML-E : Total Indoor capacity = P63 + P32 = P95.




Fig. 3-2-2AA




Fig. 3-2-2A Piping scheme

Piping length

Item	Piping in the figure	Max. length	Max. equivalent length
Total piping length	A+B+C+D+E+F+G+H+a+b+c+d+e+f+g+h+j+k	*1	-
Farthest IU from HU	A+F+H+k	165 [541']	190 [623']
Distance between HU and BC	A	110 [360'] *1	110 [360'] *1
Farthest IU from BC controller	D+E+h or F+H+k	40 [131'] *2	40 [131'] *2
Height between HU and IU (HU above IU)	H	50 [164']	-
Height between HU and IU (HU under IU)	H'	40 [131']	-
Height between IU and BC	h1	15 [49'] (10 [32']) *3	-
Height between IU and IU	h2	15 [49'] (10 [32']) *3	-
Height between BC(Main or Sub) and BC(Sub)	h3	15 [49'] (10 [32']) *4	-


Bent equivalent length "M"

Heat source Model M (m/bent [ft./bent])	
P200YLM	0.35 [1.15']
P250YLM	0.42 [1.38']
P300YLM	0.42 [1.38']
P350YLM	0.50 [1.64']
P400YLM	0.50 [1.64']
P450YLM	0.50 [1.64']
P500YLM	0.50 [1.64']
P550YLM	0.50 [1.64']
P600YLM	0.50 [1.64']

HU: Heat source Unit; IU: Indoor Unit; BC: BC controller

- *1. Refer to the section 3-2-4.
- *2. Farthest Indoor from BC controller "D+E+h or F+H+k" can exceed 40m [131ft.] till 60m [197ft.] if no Indoor sized P200, P250 connected.
Details refer to Fig.3-2-2-1
- *3. Distance of Indoor sized P200, P250 from BC must be less than 10m [32ft.], if any.
- *4. When using 2 Sub BC controllers, max. height "h3" should be considered.

Fig. 3-2-2-1 Piping length and height between IU and BC controller



Piping "A" size selection rule

Heat source Model	Pipe(High pressure)	Pipe(Low pressure)
P200YLM	ø15.88 [5/8"]	ø19.05 [3/4"]
P250-300YLM	ø19.05 [3/4"]	ø22.20 [7/8"]
P350-500YLM	ø22.20 [7/8"]	ø28.58 [1-1/8"]
P550YLM	ø22.20 [7/8"]*	ø28.58 [1-1/8"]
P600YLM	ø22.20 [7/8"]*	ø34.93 [1-3/8"]

* When the piping length is 65 m or longer, use the ø28.58 [1-1/8"] pipe for the part that exceeds 65 m.

Piping "B", "C", "D", "E" size selection rule

Total down-stream Indoor capacity	Pipe(Liquid)	Pipe(Gas)
P140 or less	ø9.52 [3/8"]	ø15.88 [5/8"]
P141-P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P201-P250	ø9.52 [3/8"]	ø22.20 [7/8"]

Piping "F", "G", "H" size selection rule

Total down-stream Indoor capacity	Pipe(Liquid)	Pipe(HP Gas)	Pipe(LP Gas)
P200 or less	ø9.52 [3/8"]	ø15.88 [5/8"]	ø19.05 [3/4"]
P201 to P300	ø9.52 [3/8"]	ø19.05 [3/4"]	ø22.20 [7/8"]
P301 to P350	ø12.70 [1/2"]	ø19.05 [3/4"]	ø28.58 [1-1/8"]
P351 to P400	ø12.70 [1/2"]	ø22.20 [7/8"]	ø28.58 [1-1/8"]
P401 to P450	ø15.88 [5/8"]	ø22.20 [7/8"]	ø28.58 [1-1/8"]

HP : High pressure, LP:Low pressure

Piping "a", "b", "c", "d", "e", "f", "g", "h", "j", "k" size selection rule

Indoor Unit size	Pipe(Liquid)	Pipe(Gas)
P15 to P50, GUF-50RD(H)	ø6.35 [1/4"]	ø12.70 [1/2"]
P63 to P140, GUF-100RD(H)	ø9.52 [3/8"]	ø15.88 [5/8"]
P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P250	ø9.52 [3/8"]	ø22.20 [7/8"]

3-2-3. IF more than 16 ports are in use, or if there is more than one BC controller in use for two heat source units

- Note1. No Header usable on PORY system.
- Note2. Indoor unit sized P100-P250 should be connected to BC controller via Y shape joint CMY-R160-J1 ;
- Note3. Indoor unit sized P100-P250 does NOT share BC controller ports with other Indoor units ;
- Note4. As bends cause pressure loss on transportation of refrigerant, fewer bends design is better ;
Piping length needs to consider the actual length and equivalent length which bends are counted.
Equivalent piping length (m)=Actual piping length+M* Number of bent.
- Note5. Set DIP-SW 4-6 to ON of BC controller, in case of connected Indoor unit sized P100-P140 with 2 ports.
- Note6. It is also possible to connect Indoor unit sized P100-P140 with 1 port (set DIP-SW 4-6 to OFF).
However, the cooling capacity decreases a little (For details, refer to the chapter HEAT SOURCE UNITS, WR2 SERIES, 7-4. Correction by port counts of the BC controller).
- Note7. Individual indoor units grouped together to connect to the BC controller via one port cannot operate individually in heating and cooling modes at the same time. I.e., they must all function in either heating or cooling together.
- Note8. For sub BC controller CMB-P-V-GB1 the connectable indoor unit capacities may sum to equal that of a P350 unit or less. However, if two sub controllers are used the TOTAL sum of connectable units connected to BOTH sub controllers must also not exceed that of a P350 unit.
For sub BC controller CMB-P1016V-HB1 the connectable indoor unit capacities may sum to equal that of a P350 unit or less. However, if two sub controllers are used the TOTAL sum of connectable units connected to BOTH sub controllers must also not exceed that of a P450 unit.
- Note9. Indoor capacity is described as its model size. For example, PEFY-P63VML-E, its capacity is P63.
- Note10. Total down-stream Indoor capacity is the summary of the model size of Indoors down-stream.
For example, PEFY-P63VML-E + PEFY-P32VML-E : Total Indoor capacity = P63 + P32 = P95.




Fig. 3-2-3AA





Fig. 3-2-3A Piping scheme

Item	Piping in the figure	Max. length	Max. equivalent length	Bent equivalent length "M"	
				(m [ft.])	
Total piping length	J+K+L+A+B+C+D+E+F+G+H+a+b+c+d+e+f+g+h+j+k	*1	-	Heat source Model M (m/bent [ft./bent])	
Farthest IU from HU	J(K)+A+F+H+k	165 [541']	190 [623']	P400YSLM	0.50 [1.64']
Distance between HU and BC	J(K)+A	110 [360'] *1	110 [360'] *1	P450YSLM	0.50 [1.64']
Farthest IU from BC controller	D+E+h or F+G+j or F+H+k	40 [131'] *2	40 [131'] *2	P500YSLM	0.50 [1.64']
Height between HU and IU (HU above IU)	H	50 [164']	-	P600YSLM	0.50 [1.64']
Height between HU and IU (HU under IU)	H'	40 [131']	-	P700YSLM	0.70 [2.29']
Height between IU and BC	h1	15 [49'] (10 [32']) *3	-	P750YSLM	0.70 [2.29']
Height between IU and IU	h2	15 [49'] (10 [32']) *3	-	P800YSLM	0.70 [2.29']
Height between BC(Main or Sub) and BC(Sub)	h3	15 [49'] (10 [32']) *4	-	P850YSLM	0.80 [2.62']
Distance between Main unit and Sub unit	J+K or L	5 [16']	-	P900YSLM	0.80 [2.62']
Height between Main unit and Sub unit	h4	0.1 [0.3']	-		

- HU: Heat source Unit; IU: Indoor Unit; BC: BC controller
- *1. Refer to the section 3-2-4.
- *2. Farthest Indoor from BC controller "D+E+h or F+G+j or F+H+k" can exceed 40m [131ft.] till 60m [197ft.] if no Indoor sized P200, P250 connected. Details refer to Fig.3-2-3-1
- *3. Distance of Indoor sized P200, P250 from BC must be less than 10m [32ft.], if any.
- *4. When using 2 Sub BC controllers, max. height "h3" should be considered.

Fig. 3-2-3-1 Piping length and height between IU and BC controller



Piping "A" size selection rule (mm [in.])

Heat source Model	Pipe(High pressure)	Pipe(Low pressure)
P400-500YSLM	ø22.20 [7/8"]	ø28.58 [1-1/8"]
P550YSLM	ø22.20 [7/8"]*	ø28.58 [1-1/8"]
P600YSLM	ø22.20 [7/8"]*	ø34.93 [1-3/8"]
P700-800YSLM	ø28.58 [1-1/8"]	ø34.93 [1-3/8"]
P850-900YSLM	ø28.58 [1-1/8"]	ø41.28 [1-5/8"]

* When the piping length is 65 m or longer, use the ø28.58 [1-1/8"] pipe for the part that exceeds 65 m.

Piping "B", "C", "D", "E" size selection rule (mm [in.])

Total down-stream Indoor capacity	Pipe(Liquid)	Pipe(Gas)
P140 or less	ø9.52 [3/8"]	ø15.88 [5/8"]
P141-P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P201-P250	ø9.52 [3/8"]	ø22.20 [7/8"]

Piping "F", "G", "H" size selection rule (mm [in.])

Total down-stream Indoor capacity	Pipe(Liquid)	Pipe(HP Gas)	Pipe(LP Gas)
P200 or less	ø9.52 [3/8"]	ø15.88 [5/8"]	ø19.05 [3/4"]
P201 to P300	ø9.52 [3/8"]	ø19.05 [3/4"]	ø22.20 [7/8"]
P301 to P350	ø12.70 [1/2"]	ø19.05 [3/4"]	ø28.58 [1-1/8"]
P351 to P400	ø12.70 [1/2"]	ø22.20 [7/8"]	ø28.58 [1-1/8"]
P401 to P450	ø15.88 [5/8"]	ø22.20 [7/8"]	ø28.58 [1-1/8"]

HP: High pressure, LP: Low pressure

Piping "J", "K", "L" size selection rule (mm [in.])

Heat source Model	Pipe(High pressure)	Pipe(Low pressure)
P400YSLM	ø15.88 [5/8"]	ø19.05 [3/4"]
P450-600YSLM	ø19.05 [3/4"]	ø22.20 [7/8"]
P700-900YSLM	ø22.20 [7/8"]	ø28.58 [1-1/8"]


Piping "a", "b", "c", "d", "e", "f", "g", "h", "j", "k" size selection rule (mm [in.])

Indoor Unit size	Pipe(Liquid)	Pipe(Gas)
P15 to P50	ø6.35 [1/4"]	ø12.70 [1/2"]
P63 to P140	ø9.52 [3/8"]	ø15.88 [5/8"]
P200	ø9.52 [3/8"]	ø19.05 [3/4"]
P250	ø9.52 [3/8"]	ø22.20 [7/8"]

3-2-4. Total piping length restrictions


S.D. WR2

[PQRY-P200, 250, 300YLM-A]




[PQRY-P350, 400, 450, 500, 550, 600YLM-A]

[PQRY-P400, 450, 500, 550, 600, 700, 750, 800, 850, 900YSLM-A]



3-3. Refrigerant charging calculation

Sample connection (with 3 BC controller and 6 indoor units) (PQR-Y-P700YSLM)



Amount of additional refrigerant to be charged

Refrigerant for extended pipes (field piping) is not factory-charged to the heat source unit. Add an appropriate amount of refrigerant for each pipes on site. Record the size of each high pressure pipe and liquid pipe, and the amount of refrigerant that was charged on the heat source unit for future reference.

Calculating the amount of additional refrigerant to be charged

The amount of refrigerant to be charged is calculated with the size of the on-site-installed high pressure pipes and liquid pipes, and their length. Calculate the amount of refrigerant to be charged according to the formula below. Round up the calculation result to the nearest 0.1kg. (i.e., 16.03 kg = 16.1 kg)

<Amount of additional refrigerant to be charged>

Calculating the amount of additional refrigerant to be charged

Units "m" and "kg"

<Formula>

When the piping length from the heat source unit to the farthest indoor unit is 30.5 m (100 ft) or shorter

Amount of additional charge (kg)	=	High-pressure pipe ø28.58 total length × 0.36 (kg/m)	+	High-pressure pipe ø22.2 total length × 0.23 (kg/m)	+	High-pressure pipe ø19.05 total length × 0.16 (kg/m)	+	High-pressure pipe ø15.88 total length × 0.11 (kg/m)	+	Liquid pipe ø15.88 total length × 0.2 (kg/m)
	+	Liquid pipe ø12.7 total length × 0.12 (kg/m)	+	Liquid pipe ø9.52 total length × 0.06 (kg/m)	+	Liquid pipe ø6.35 total length × 0.024 (kg/m)				

+	BC controller	Amount (to be added for standard or main BC controller)	+	Main BC controller	Amount
	Standard/Main	3.0kg		HA-type	2.0kg

+	Number of sub BC controllers	Amount (to be added for sub BC controller)	+	Total capacity of connected indoor units	Amount (to be added for indoor unit)
	1	1.0kg		80 or below	2.0kg
	2	2.0kg		81 to 160	2.5kg
				161 to 330	3.0kg
				331 to 390	3.5kg
				391 to 480	4.5kg
				481 to 630	5.0kg
				631 to 710	6.0kg
				711 to 800	8.0kg
				801 to 890	9.0kg
				891 to 1070	10.0kg
				1071 to 1250	12.0kg
				1251 or above	14.0kg

+	Heat source unit model	Amount (to be added for heat source unit)
	Single	P550 1.0kg
		P600 1.0kg

S.D. WR2

• When the piping length from the heat source unit to the farthest indoor unit is longer than 30.5 m (100 ft)

Amount of additional charge (kg)	=	High-pressure pipe ø28.58 total length × 0.33 (kg/m)	+	High-pressure pipe ø22.2 total length × 0.21 (kg/m)	+	High-pressure pipe ø19.05 total length × 0.14 (kg/m)	+	High-pressure pipe ø15.88 total length × 0.1 (kg/m)	+	Liquid pipe ø15.88 total length × 0.18 (kg/m)
		Liquid pipe ø12.7 total length × 0.11 (kg/m)	+	Liquid pipe ø9.52 total length × 0.054 (kg/m)	+	Liquid pipe ø6.35 total length × 0.021 (kg/m)				

+	BC controller	Amount (to be added for standard or main BC controller)	+	Main BC controller	Amount

+	Number of sub BC controllers	Amount (to be added for sub BC controller)	+	Total capacity of connected indoor units	Amount (to be added for indoor unit)
	2	2.0kg		81 to 160	2.5kg
				161 to 330	3.0kg
				331 to 390	3.5kg
				391 to 480	4.5kg
				481 to 630	5.0kg
				631 to 710	6.0kg
				711 to 800	8.0kg
				801 to 890	9.0kg
				891 to 1070	10.0kg
				1071 to 1250	12.0kg
				1251 or above	14.0kg

+	Heat source unit model	Amount (to be added for heat source unit)		
			Single	P550
			P600	1.0kg

Amount of factory charged refrigerant **Sample calculation**

heat source unit Model	Charged amount
P200 P250 P300	5.0 kg
P350 P400 P450 P500	6.0 kg
P550 P600	11.7 kg

Indoor	1: 50	A: ø28.58	40m	a: ø6.35	10m
	2: 250	B: ø9.52	10m	b: ø9.52	5m
	3: 15	C: ø12.70	20m	c: ø6.35	5m
	4: 20	D: ø9.52	5m	d: ø6.35	10m
	5: 140	E: ø9.52	5m	e: ø9.52	5m
	6: 200	F: ø22.20	3m	f: ø9.52	5m
		G: ø22.20	1m		

The total length of each liquid line is as follows:

ø28.58: A = 40 m
 ø22.20: F + G = 4 m
 ø12.70: C = 20 m
 ø9.52: B + D + E + b + e + f = 35 m
 ø6.35: a + c + d = 25 m
 Therefore,
 <Calculation example>
 Additional refrigerant charge
 = 40 × 0.33 + 4 × 0.21 + 20 × 0.11 + 35 × 0.054 + 25 × 0.021 + 3
 + 2 + 2 + 6
 = 31.7 (31.655) kg

Limitation of the amount of refrigerant to be charged

The above calculation result of the amount of refrigerant to be charged must become below the value in the table below.

Total index of the heat source units		P200 YLM	P250 YLM	P300 YLM	P350 YLM	P400 YLM	P450 YLM	P500 YLM	P550 YLM	P600 YLM	P400 YSLM	P450 YSLM	P500 YSLM	P550 YSLM	P600 YSLM
Maximum refrigerant charge	Factory charged	5.0kg	5.0kg	5.0kg	6.0kg	6.0kg	6.0kg	6.0kg	11.7kg	11.7kg	10.0kg	10.0kg	10.0kg	10.0kg	10.0kg
	Charged on site	27.0kg	32.0kg	33.0kg	52.0kg	52.0kg	53.0kg	55.0kg	57.0kg	58.0kg	52.0kg	53.0kg	55.0kg	61.5kg	64.5kg
	Total for system	32.0kg	37.0kg	38.0kg	58.0kg	58.0kg	59.0kg	61.0kg	68.7kg	69.7kg	62.0kg	63.0kg	65.0kg	71.5kg	74.5kg

Total index of the heat source units		P700 YSLM	P750 YSLM	P800 YSLM	P850 YSLM	P900 YSLM
Maximum refrigerant charge	Factory charged	12.0kg	12.0kg	12.0kg	12.0kg	12.0kg
	Charged on site	72.0kg	74.0kg	74.0kg	76.0kg	76.0kg
	Total for system	84.0kg	86.0kg	86.0kg	88.0kg	88.0kg

4-1. Requirement on installation site

1. No direct thermal radiation to the unit.
2. No possibility of annoying the neighbors by the sound of the unit.


Valves and refrigerant flow on the Heat source unit may generate noise.

3. Avoid the sites where strong winds blow.
4. With strength to bear the weight of the unit.
5. Drain flow from the unit is cared at heating mode.
6. Enough space for installation and service as shown at 4-2.
7. Avoid the sites where acidic solutions or chemical sprays (sulfur series) are used frequently.
8. The unit should be secure from combustible gas, oil, steam, chemical gas like acidic solution, sulfur gas and so on.

4-2. Spacing


In case of single installation, 600mm or more of back space as front space makes easier access when servicing the unit from rear side.

Unit: mm (in.)



4-3. Piping direction

S.D. WR2



- (A) Main circulating water pipe
- (B) Shutoff valve
- (C) Shutoff valve
- (D) Water outlet (upper)
- (E) Refrigerant pipes
- (F) Y-type strainer
- (G) Water inlet (lower)
- (H) Drain pipe

1. Insulation installation

With City Multi WY/ WR2 Series piping, as long as the temperature range of the circulating water is kept to average temperatures year-round (29.4°C[85°F] in the summer, 21.1°C[70°F] in the winter), there is no need to insulate or otherwise protect indoor piping from exposure. You should use insulation in the following situations:

- Any heat source piping.
- Indoor piping in cold-weather regions where frozen pipes are a problem.
- When air coming from the outside causes condensation to form on piping.
- Any drainage piping.

2. Water processing and water quality control

To preserve water quality, use the closed type of cooling tower for WY/ WR2. When the circulating water quality is poor, the water heat exchanger can develop scales, leading to a reduction in heat-exchange power and possible corrosion of the heat exchanger. Please pay careful attention to water processing and water quality control when installing the water circulation system.

- Removal of foreign objects or impurities within the pipes.
During installation, be careful that foreign objects, such as welding fragments, sealant particles, or rust, do not enter the pipes.
- Water Quality Processing
 - ① Depending on the quality of the cold-temperature water used in the air conditioner, the copper piping of the heat exchanger may become corroded. We recommend regular water quality processing. Cold water circulation systems using open heat storage tanks are particularly prone to corrosion. When using an open-type heat storage tank, install a water-to-water heat exchanger, and use a closed-loop circuit on the air conditioner side. If a water supply tank is installed, keep contact with air to a minimum, and keep the level of dissolved oxygen in the water no higher than 1mg/ℓ.

② Water quality standard

Items	Lower mid-range temperature water system		Tendency	
	Recirculating water [20<T<60°C] [68<T<140°F]	Make-up water	Corrosive	Scale-forming
pH (25°C)[77°F]	7.0 ~ 8.0	7.0 ~ 8.0	○	○
Electric conductivity (mS/m) (25°C)[77°F] (μS/cm) (25°C)[77°F]	30 or less [300 or less]	30 or less [300 or less]	○	○
Chloride ion (mg Cl/ℓ)	50 or less	50 or less	○	
Sulfate ion (mg SO ₄ ²⁻ /ℓ)	50 or less	50 or less	○	
Acid consumption (pH4.8) (mg CaCO ₃ /ℓ)	50 or less	50 or less		○
Total hardness (mg CaCO ₃ /ℓ)	70 or less	70 or less		○
Calcium hardness (mg CaCO ₃ /ℓ)	50 or less	50 or less		○
Ionic silica (mg SiO ₂ /ℓ)	30 or less	30 or less		○
Iron (mg Fe/ℓ)	1.0 or less	0.3 or less	○	○
Copper (mg Cu/ℓ)	1.0 or less	0.1 or less	○	
Sulfide ion (mg S ²⁻ /ℓ)	not to be detected	not to be detected	○	
Ammonium ion (mg NH ₄ ⁺ /ℓ)	0.3 or less	0.1 or less	○	
Residual chlorine (mg Cl/ℓ)	0.25 or less	0.3 or less	○	
Free carbon dioxide (mg CO ₂ /ℓ)	0.4 or less	4.0 or less	○	
Ryzner stability index	-	-	○	○

Reference : Guideline of Water Quality for Refrigeration and Air Conditioning Equipment. (JRA GL02E-1994)

- ③ Please consult with a water quality control specialist about water quality control methods and water quality calculations before using anti-corrosive solutions for water quality management.
- ④ When replacing a previously installed air conditioning device (even when only the heat exchanger is being replaced), first conduct a water quality analysis and check for possible corrosion. Corrosion can occur in cold-water systems even if there has been no prior signs of corrosion. If the water quality level has dropped, please adjust water quality sufficiently before replacing the unit.

5-1. General precautions

5-1-1. Usage

- The air-conditioning system described in this Data Book is designed for human comfort.
- This product is not designed for preservation of food, animals, plants, precision equipment, or art objects. To prevent quality loss, do not use the product for purposes other than what it is designed for.
- To reduce the risk of water leakage and electric shock, do not use the product for air-conditioning vehicles or vessels.

5-1-2. Installation environment

- Do not install any unit other than the dedicated unit in a place where the voltage changes a lot, large amounts of mineral oil (e.g., cutting oil) are present, cooking oil may splash, or a large quantity of steam can be generated such as a kitchen.
- Do not install the unit in acidic or alkaline environment.
- Installation should not be performed in the locations exposed to chlorine or other corrosive gases. Avoid near a sewer.
- To reduce the risk of fire, do not install the unit in a place where flammable gas may be leaked or inflammable material is present.
- This air conditioning unit has a built-in microcomputer. Take the noise effects into consideration when deciding the installation position. Especially in a place where antenna or electronic device are installed, it is recommended that the air conditioning unit be installed away from them.
- Install the unit on a solid foundation according to the local safety measures against typhoons, wind gusts, and earthquakes to prevent the unit from being damaged, toppling over, and falling.

5-1-3. Backup system

- In a place where air conditioner's malfunctions may exert crucial influence, it is recommended to have two or more systems of single outdoor/heat source units with multiple indoor units.

5-1-4. Unit characteristics

- Heat pump efficiency depends on outdoor temperature. In the heating mode, performance drops as the outside air temperature drops. In cold climates, performance can be poor. Warm air would continue to be trapped near the ceiling and the floor level would continue to stay cold. In this case, heat pumps require a supplemental heating system or air circulator. Before purchasing them, consult your local distributor for selecting the unit and system.
- When the outdoor temperature is low and the humidity is high, the heat exchanger on the outdoor/heat source unit side tends to collect frost, which reduces its heating performance. To remove the frost, Auto-defrost function will be activated and the heating mode will temporarily stop for 3-10 minutes. Heating mode will automatically resume upon completion of defrost process.
- Air conditioner with a heat pump requires time to warm up the whole room after the heating operation begins, because the system circulates warm air in order to warm up the whole room.
- The sound levels were obtained in an anechoic room. The sound levels during actual operation are usually higher than the simulated values due to ambient noise and echoes. Refer to the section on "SOUND LEVELS" for the measurement location.
- Depending on the operation conditions, the unit generates noise caused by valve actuation, refrigerant flow, and pressure changes even when operating normally. Please consider to avoid location where quietness is required. For BC controller, it is recommended to unit to be installed in places such as ceilings of corridor, restrooms and plant rooms.
- The total capacity of the connected indoor units can be greater than the capacity of the outdoor/heat source unit. However, when the connected indoor units operate simultaneously, each unit's capacity may become smaller than the rated capacity.
- When the unit is started up for the first time within 12 hours after power on or after power failure, it performs initial startup operation (capacity control operation) to prevent damage to the compressor. The initial startup operation requires 90 minutes maximum to complete, depending on the operation load.

5-1-5. Relevant equipment

- Use an earth leakage breaker (ELB) with medium sensitivity, and an activation speed of 0.1 second or less.
- Consult your local distributor or a qualified technician when installing an earth leakage breaker.
- If the unit is inverter type, select an earth leakage breaker for handling high harmonic waves and surges.
- Leakage current is generated not only through the air conditioning unit but also through the power wires. Therefore, the leakage current of the main power supply is greater than the total leakage current of each unit. Take into consideration the capacity of the earth leakage breaker or leakage alarm when installing one at the main power supply. To measure the leakage current simply on site, use a measurement tool equipped with a filter, and clamp all the four power wires together. The leakage current measured on the ground wire may not accurate because the leakage current from other systems may be included to the measurement value.
- Do not install a phase advancing capacitor on the unit connected to the same power system with an inverter type unit and its equipment.
- If a large current flows due to the product malfunctions or faulty wiring, both the earth leakage breaker on the product side and the upstream overcurrent breaker may trip almost at the same time. Separate the power system or coordinate all the breakers depending on the system's priority level.

5-1-6. Unit installation

- Your local distributor or a qualified technician must read the Installation Manual that is provided with each unit carefully before performing installation work.
- Consult your local distributor or a qualified technician when installing the unit. Improper installation by an unqualified person may result in water leakage, electric shock, or fire.
- Ensure there is enough space around each unit.

5-1-7. Optional accessories

- Only use accessories recommended by Mitsubishi Electric. Consult your local distributor or a qualified technician when installing them. Improper installation by an unqualified person may result in water leakage, electric leakage, system breakdown, or fire.
- Some optional accessories may not be compatible with the air conditioning unit to be used or may not be suitable for the installation conditions. Check the compatibility when considering any accessories.
- Note that some optional accessories may affect the air conditioner's external form, appearance, weight, operating sound, and other characteristics.

5-1-8. Operation/Maintenance

- Read the Instruction Book that is provided with each unit carefully prior to use.
- Maintenance or cleaning of each unit may be risky and require expertise. Read the Instruction Book to ensure safety. Consult your local distributor or a qualified technician when special expertise is required such as when the indoor unit needs to be cleaned.

5-2. Precautions for Indoor unit**5-2-1. Operating environment**

- The refrigerant (R410A) used for air conditioner is non-toxic and nonflammable. However, if the refrigerant leaks, the oxygen level may drop to harmful levels. If the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration from exceeding the safety limit even if the refrigerant should leak.
- If the units operate in the cooling mode at the humidity above 80%, condensation may collect and drip from the indoor units.

5-2-2. Unit characteristics

- The return air temperature display on the remote controller may differ from the ones on the other thermometers.
- The clock on the remote controller may be displayed with a time lag of approximately one minute every month.
- The temperature using a built-in temperature sensor on the remote controller may differ from the actual room temperature due to the effect of the wall temperature.
- Use a built-in thermostat on the remote controller or a separately-sold thermostat when indoor units installed on or in the ceiling operate the automatic cooling/heating switchover.
- The room temperature may rise drastically due to Thermo OFF in the places where the air conditioning load is large such as computer rooms.
- Be sure to use a regular filter. If an irregular filter is installed, the unit may not operate properly, and the operation noise may increase.
- The room temperature may rise over the preset temperature in the environment where the heating air conditioning load is small.

5-2-3. Unit installation

- For simultaneous cooling/heating operation type air conditioners (R2, WR2 series), the G-type BC controller cannot be connected to the 16HP outdoor/heat source unit model or above, and the G- and GA-type BC controllers cannot be connected to the 28HP model or above. The GB- and HB-type BC controllers (sub) cannot be connected to the outdoor/heat source unit directly, and be sure to use them with GA- and HA-type BC controllers (main).
- The insulation for low pressure pipe between the BC controller and outdoor/heat source unit shall be at least 20 mm thick. If the unit is installed on the top floor or in a high-temperature, high-humidity environment, thicker insulation may be necessary.
- Do not have any branching points on the downstream of the refrigerant pipe header.
- When a field-supplied external thermistor is installed or when a device for the demand control is used, abnormal stop of the unit or damage of the electromagnetic contactor may occur. Consult your local distributor for details.
- When indoor units operate a fresh air intake, install a filter in the duct (field-supplied) to remove the dust from the air.
- The 4-way or 2-way Airflow Ceiling Cassette Type units that have an outside air inlet can be connected to the duct, but need a booster fan to be installed at site. Refer to the chapter "Indoor Unit" for the available range for fresh air intake volume.
- Operating fresh air intake on the indoor unit may increase the sound pressure level.

5-3. Precautions for Fresh air intake type indoor unit

5-3-1. Usage

- This unit mainly handles the outside air load, and is not designed to maintain the room temperature. Install other air conditioners for handling the air conditioning load in the room.

5-3-2. Unit characteristics

- This unit cannot perform the drying operation. The unit will continue the fan operation and blow fresh air (air that is not air-conditioned) when the Heating Thermo-OFF or Cooling Thermo-OFF mode is selected.
- The fan may stop tentatively when the unit is connected to the simultaneous cooling/heating operation type outdoor/heat source unit (R2, WR2 series) or during the defrost cycle.
- This unit switches the Thermo ON or OFF depending on the room temperature. The outside air is directly supplied into the room during Thermo OFF. Take caution of the cold supply air due to low outside air temperature and of condensation in the room due to high humidity of the outside air.
- Outside air temperature ranges for the operation must be as follows:
Cooling: 21°C D.B./15.5°C W.B. ~ 43°C D.B./35°C W.B.
Heating: -10°C D.B. ~ 20°C D.B.
The unit is forced to operate Thermo OFF (fan operation) when the outside air temperature is as follows.
Cooling: 21°C D.B. or below; Heating: 20°C D.B. or above
- Either a remote controller (sold separately) or a remote sensor (sold separately) must be installed to monitor the room temperature.
- If only this unit is used as an indoor unit, condensation may form at the supply air grill while the unit is operated in the cooling mode. This unit cannot operate dehumidifying.
- Use the unit in the way that the airflow rate will not exceed the 110% of the rated airflow.

5-4. Precautions for Outdoor unit/Heat source unit

5-4-1. Installation environment

- Outdoor/heat source unit with salt-resistant specification is recommended to use in a place where it is subject to salt air.
- Even when the unit with salt-resistant specification is used, it is not completely protected against corrosion. Be sure to follow the directions or precautions described in Instructions Book and Installation Manual for installation and maintenance. The salt-resistant specification is referred to the guidelines published by JRAIA (JRA9002).
- Install the unit in a place where the flow of discharge air is not obstructed. If not, the short-cycling of discharge air may occur.
- Provide proper drainage around the unit base, because the condensation may collect and drip from the outdoor/heat source units. Provide water-proof protection to the floor when installing the units on the rooftop.
- In a region where snowfall is expected, install the unit so that the outlet faces away from the direction of the wind, and install a snow guard to protect the unit from snow. Install the unit on a base approximately 50 cm higher than the expected snowfall. Close the openings for pipes and wiring, because the ingress of water and small animals may cause equipment damage. If SUS snow guard is used, refer to the Installation Manual that comes with the snow guard and take caution for the installation to avoid the risk of corrosion.
- When the unit is expected to operate continuously for a long period of time at outside air temperatures of below 0°C, take appropriate measures, such as the use of a unit base heater, to prevent icing on the unit base. (Not applicable to the PUMY series)
- Install the snow guard so that the outlet/inlet faces away from the direction of the wind.
- When the snow accumulates approximately 50 cm or more on the snow guard, remove the snow from the guard. Install a roof that is strong enough to withstand snow loads in a place where snow accumulates.
- Provide proper protection around the outdoor/heat source units in places such as schools to avoid the risk of injury.
- A cooling tower and heat source water circuit should be a closed circuit that water is not exposed to the atmosphere. When a tank is installed to ensure that the circuit has enough water, minimize the contact with outside air so that the oxygen from being dissolved in the water should be 1 mg/L or less.
- Install a strainer (50 mesh or more recommended) on the water pipe inlet on the heat source unit.
- Interlock the heat source unit and water circuit pump.
- Note the followings to prevent the freeze bursting of pipe when the heat source unit is installed in a place where the ambient temperature can be 0°C or below.
 - Keep the water circulating to prevent it from freezing when the ambient temperature is 0°C or below.
 - Before a long period of non use, be sure to purge the water out of the unit.
- Salt-resistant unit is resistant to salt corrosion, but not salt-proof.
Please note the following when installing and maintaining outdoor/heat source units in marine atmosphere.
 1. Install the salt-resistant unit out of direct exposure to sea breeze, and minimize the exposure to salt water mist.
 2. Avoid installing a sun shade over the outdoor/heat source unit, so that rain will wash away salt deposits off the unit.
 3. Install the unit horizontally to ensure proper water drainage from the base of the unit. Accumulation of water in the base of the outdoor/heat source unit will significantly accelerate corrosion.
 4. Periodically wash salt deposits off the unit, especially when the unit is installed in a coastal area.
 5. Repair all noticeable scratches after installation and during maintenance.
 6. Periodically check the unit, and apply anti-rust agent and replace corroded parts as necessary.

5-4-2. Circulating water

- ♦ Follow the guidelines published by JRAIA (JRA-GL02-1994) to check the water quality of the water in the heat source unit regularly.
- ♦ A cooling tower and heat source water circuit should be a closed circuit that water is not exposed to the atmosphere. When a tank is installed to ensure that the circuit has enough water, minimize the contact with outside air so that the oxygen from being dissolved in the water should be 1 mg/L or less.

5-4-3. Unit characteristics

- ♦ When the Thermo ON and OFF is frequently repeated on the indoor unit, the operation status of outdoor/heat source units may become unstable.

5-4-4. Relevant equipment

- ♦ Provide grounding in accordance with the local regulations.

5-5. Precautions for Control-related items**5-5-1. Product specification**

- ♦ To introduce the MELANS system, a consultation with us is required in advance. Especially to introduce the electricity charge apportioning function or energy-save function, further detailed consultation is required. Consult your local distributor for details.
- ♦ Billing calculation for AE-200E/AE-50E/EW-50E/AG-150A/EB-50GU-J/TG-2000A, or the billing calculation unit is unique and based on our original method. (Backup operation is included.) It is not based on the metering method, and do not use it for official business purposes. It is not the method that the amount of electric power consumption (input) by air conditioner is calculated. Note that the electric power consumption by air conditioner is apportioned by using the ratio corresponding to the operation status (output) for each air conditioner (indoor unit) in this method.
- ♦ In the apportioned billing function for AE-200E/AE-50E/EW-50E/AG-150A and EB-50GU-J, use separate watt-hour meters for A-control units, K-control units, and packaged air conditioner for City Multi air conditioners. It is recommended to use an individual watt-hour meter for the large-capacity indoor unit (with two or more addresses).
- ♦ When using the peak cut function on the AE-200E/AE-50E/EW-50E/AG-150A or EB-50GU-J, note that the control is performed once every minute and it takes time to obtain the effect of the control. Take appropriate measures such as lowering the criterion value. Power consumption may exceed the limits if AE-200E/AE-50E/EW-50E/AG-150A or EB-50GU-J malfunctions or stops. Provide a back-up remedy as necessary.
- ♦ The controllers cannot operate while the indoor unit is OFF. (No error)
Turn ON the power to the indoor unit when operating the controllers.
- ♦ When using the interlocked control function on the AE-200E/AE-50E/EW-50E/AG-150A/EB-50GU-J/PAC-YG66DCA or PAC-YG63MCA, do not use it for the control for the fire prevention or security. (This function should never be used in the way that would put people's lives at risk.) Provide any methods or circuit that allow ON/OFF operation using an external switch in case of failure.

5-5-2. Installation environment

- ♦ The surge protection for the transmission line may be required in areas where lightning strikes frequently occur.
- ♦ A receiver for a wireless remote controller may not work properly due to the effect of general lighting. Leave a space of at least 1 m between the general lighting and receiver.
- ♦ When the Auto-elevating panel is used and the operation is made by using a wired remote controller, install the wired remote controller to the place where all air conditioners controlled (at least the bottom part of them) can be seen from the wired remote controller. If not, the descending panel may cause damage or injury, and be sure to use a wireless remote controller designed for use with elevating panel (sold separately).
- ♦ Install the wired remote controller (switch box) to the place where the following conditions are met.
 - ♦ Where installation surface is flat
 - ♦ Where the remote controller can detect an accurate room temperature
The temperature sensors that detect a room temperature are installed both on the remote controller and indoor unit. When a room temperature is detected using the sensor on the remote controller, the main remote controller is used to detect a room temperature. In this case, follow the instructions below.
 - ♦ Install the controller in a place where it is not subject to the heat source.
(If the remote controller faces direct sunlight or supply air flow direction, the remote controller cannot detect an accurate room temperature.)
 - ♦ Install the controller in a place where an average room temperature can be detected.
 - ♦ Install the controller in a place where no other wires are present around the temperature sensor.
(If other wires are present, the remote controller cannot detect an accurate room temperature.)
- ♦ To prevent unauthorized access, always use a security device such as a VPN router when connecting AE-200E/AE-50E/EW-50E/AG-150A/EB-50GU-J or TG-2000A to the Internet.

The installer and/or air conditioning system specialist shall secure safety against refrigerant leakage according to local regulations or standards. The following standard may be applicable if no local regulation or standard is available.

6-1. Refrigerant property

R410A refrigerant is harmless and incombustible. The R410A is heavier than the indoor air in density. Leakage of the refrigerant in a room has possibility to lead to a hypoxia situation. Therefore, the critical concentration specified below shall not be exceeded even if the leakage happens.

• Critical concentration

Critical concentration hereby is the refrigerant concentration in which no human body would be hurt if immediate measures can be taken when refrigerant leakage happens.

Critical concentration of R410A: 0.44kg/m³
(The weight of refrigeration gas per 1 m³ air conditioning space.);

* The Critical concentration is subject to ISO5149, EN378-1.

For the CITY MULTI system, the concentration of refrigerant leaked should not have a chance to exceed the critical concentration in any situation.

6-2. Confirm the Critical concentration and take countermeasure

The maximum refrigerant leakage concentration (Rmax) is defined as the result of the possible maximum refrigerant weight (Wmax) leaked into a room divided by its room capacity (V). It is referable to Fig.6-1. The refrigerant of Heat source unit here includes its original charge and additional charge at the site.

The additional charge is calculated according to the refrigerant charging calculation of each kind of Heat source unit, and shall not be over charged at the site. Procedure 6-2-1~3 tells how to confirm maximum refrigerant leakage concentration (Rmax) and how to take countermeasures against a possible leakage.




Fig. 6-1 The maximum refrigerant leakage concentration

6-2-1. Find the room capacity (V),

If a room having total opening area more than 0.15% of the floor area at a low position with another room/space, the two rooms/space are considered as one. The total space shall be added up.

6-2-2. Find the possible maximum leakage (Wmax) in the room. If a room has Indoor unit(s) from more than 1 Heat source unit, add up the refrigerant of the Heat source units.

6-2-3. Divide (Wmax) by (V) to get the maximum refrigerant leakage concentration (Rmax).

6-2-4. Find if there is any room in which the maximum refrigerant leakage concentration (Rmax) is over 0.44kg/m³.

If no, then the CITY MULTI is safe against refrigerant leakage.

If yes, following countermeasure is recommended to do at site.

Countermeasure 1: Let-out (making V bigger)

Design an opening of more than 0.15% of the floor area at a low position of the wall to let out the refrigerant whenever leaked.

e.g. make the upper and lower seams of door big enough.

Countermeasure 2: Smaller total charge (making Wmax smaller)

e.g. Avoid connecting more than 1 Heat source unit to one room.

e.g. Using smaller model size but more Heat source units.

e.g. Shorten the refrigerant piping as much as possible.

Countermeasure 3: Fresh air in from the ceiling (Ventilation)

As the density of the refrigerant is bigger than that of the air. Fresh air supply from the ceiling is better than air exhausting from the ceiling.

Fresh air supply solution refers to Fig.6-2~4.




Fig.6-2. Fresh air supply always ON




Fig.6-3. Fresh air supply upon sensor action




Fig.6-4. Fresh air supply and refrigerant shut-off upon sensor action

Note 1. Countermeasure 3 should be done in a proper way in which the fresh air supply shall be on whenever the leakage happens.

Note 2. In principle, MITSUBISHI ELECTRIC requires proper piping design, installation and air-tight testing after installation to avoid leakage happening.

In the area should earthquake happen, anti-vibration measures should be fully considered.

The piping should consider the extension due to the temperature variation.



for a greener tomorrow

Eco Changes is the Mitsubishi Electric Group's environmental statement, and expresses the Group's stance on environmental management. Through a wide range of businesses, we are helping contribute to the realization of a sustainable society.

⚠ Warning

- Do not use refrigerant other than the type indicated in the manuals provided with the unit and on the nameplate.
 - Doing so may cause the unit or pipes to burst, or result in explosion or fire during use, during repair, or at the time of disposal of the unit.
 - It may also be in violation of applicable laws.
 - MITSUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.
- Our air-conditioning equipments and heat pumps contain a fluorinated greenhouse gas, R410A.

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
www.MitsubishiElectric.com